
01.01.zz (Device firmware)

Operating Instructions Levelflex FMP51, FMP52, FMP54 FOUNDATION Fieldbus

Guided wave radar










Table of contents

1	Important document information 6	5	5 1	36
1.1	Document function	5 6	1 3	39
1.2	Symbols	1 n /		50
	1.2.1 Safety symbols 6		1 3	50
	1.2.2 Electrical symbols 6		6.2.2 Shortening the probe	50
	1.2.3 Tool symbols		6.2.3 FMP54 with gas phase	
	1.2.4 Symbols for		compensation: Mounting the probe	
	certain types of information	7		52
	1.2.5 Symbols in graphics		3	53
	1.2.6 Symbols at the device		6.2.5 Mounting the "Sensor remote"	
1.3	Supplementary documentation			54
1.4	Terms and abbreviations		3	56
1.5	Registered trademarks		6.2.7 Turning the display	
	J	6.3	Post-installation check	58
2	Basic safety instructions 12	/	Electrical connection	59
2.1	Requirements for the personnel	/ . 1	Connection conditions	59
2.2	Designated use	2		59
2.3	Workplace safety		3	61
2.4	Operational safety		1	62
2.5	Product safety			63
	2.5.1 CE mark			63
	2.5.2 EAC conformity			64
2.6	Safety Instructions (XA)		7.2.1 Opening connection compartment	
	2.6.1 Ex-marking in case of connected		cover	64
	FHX50 remote display 18	3	7.2.2 Connecting	65
			7.2.3 Plug-in spring-force terminals	65
3	Product description 19)	7.2.4 Closing connection compartment	
3.1	Product design)	cover	66
	3.1.1 Levelflex FMP51/FMP52/FMP54/	7.3	Post-connection check	66
	FMP55)		
	3.1.2 Electronics housing 20		Operation options	68
	J		-	
4	Incoming acceptance and product	8.1	Overview	
7			8.1.1 Local operation	bb
	identification 21	_	8.1.2 Operation with remote display and	60
4.1	Incoming acceptance		operating module FHX50	
4.2	Product identification		<u> </u>	69
	4.2.1 Nameplate	0.4	Structure and function of the operating	71
	1			71
5	Storage, Transport 23		8.2.1 Structure of the operating menu8.2.2 User roles and related access	71
	<i>5</i> , 1			73
5.1	Storage conditions			73
5.2	Transport product to the measuring point 23	8.3	,	78
		(.0	1 1 2	78
6	Mounting		1 7 11	81
6.1	Mounting requirements		1 3	82
J.1	6.1.1 Suitable mounting position 24	I	8.3.4 Opening the context menu	
	6.1.2 Applications with restricted		8.3.5 Envelope curve on the display and	J 1
	mounting space	;	1 1 3	85
	6.1.3 Notes on the mechanical load of the		operating module	ری
	probe	3		
	6.1.4 Notes on the process connection 30			
	6.1.5 Mounting cladded flanges 35			
	J			

9	Integration into a FOUNDATION		12.2.4 Configuring the Analog Input	111
	Fieldbus network 86		Blocks	
9.1	Device Description (DD) 86	12.3	Scaling of the measured value in an AI Block	111
9.2	Integration into the FOUNDATION Fieldbus	1	Language selection	112
	network		Checking the reference distance	112
9.3	Device identification and addressing 86		Configuration of a level measurement	114
9.4	Block model		Configuration of an interface measurement .	115
	9.4.1 Blocks of the device software 87	12.8	Configuration of the on-site display	117
	9.4.2 Block configuration when device is		12.8.1 Factory settings of the on-site	445
) [delivered		display for level measurements	117
9.5	Assignment of the measured values (CHANNEL) in an AI Block 88		12.8.2 Factory settings of the on-site	118
9.6	Index tables of Endress+Hauser parameters 89	12.9	display for interface measurements Configuration management	118
7.0	9.6.1 Setup Transducer Block		Configuration of the event behavior	110
	9.6.2 Advanced Setup Transducer Block 90		according to the FOUNDATION Fieldbus	
	9.6.3 Display Transducer Block 91		specification FF912	119
	9.6.4 Diagnostic Transducer Block 92		12.10.1 Groups of events	120
	9.6.5 Expert Configuration Transducer		12.10.2 Allocation parameters	
	Block		12.10.3 Configurable area	125
	9.6.6 Expert Information Transducer		12.10.4 Transmission of the event messages	100
	Block	12 11	to the bus	126
	9.6.8 Service Information Transducer		unauthorized changes	126
	Block		anathonized changes	120
	9.6.9 Data Transfer Transducer Block 96	13	Diagnostics and troubleshooting	127
9.7	Methods		_	
		13.1	General trouble shooting	
10	Commissioning via wizard 99		13.1.2 Parametrization errors	127
	J	13.2	Diagnostic information on local display	
11	Commissioning via operating	12,12	13.2.1 Diagnostic message	
			13.2.2 Calling up remedial measures	132
	menu		Diagnostic event in the operating tool \ldots	133
11.1	Installation and function check 100		Diagnostic messages in the DIAGNOSTIC	
11.2	Setting the operating language 100		Transducer Block (TRDDIAG)	
11.3 11.4	Checking the reference distance		Diagnostic list	
11.5	Configuration of an interface measurement . 104		Event logbook	
11.6	Recording the reference curve 106		13.6.2 Filtering the event logbook	
11.7	Configuration of the on-site display 107		13.6.3 Overview of information events	
	11.7.1 Factory settings of the on-site	13.7	Firmware history	
	display for level measurements 107			
	11.7.2 Factory settings of the on-site	14	Maintenance	138
	display for interface measurements 107	14.1	Exterior cleaning	138
110	11.7.3 Adjustment of the on-site display 107 Configuration management 108	11.1	Exterior cleaning	100
11.8 11.9	Configuration management	15	Repairs	139
11.7	unauthorized changes 109		-	
	anaunonica changes	15.1	General information on repairs	
12	Commissioning (block-based		15.1.1 Repair concept	139 139
			15.1.2 Replacement of an electronics	エンフ
	operation)		module	139
12.1	Function check		15.1.4 Replacement of a device	139
12.2	Block configuration	15.2	Spare parts	140
	12.2.1 Preparatory steps	15.3	Return	
	12.2.2 Configuring the Resource Block 110	15.4	Disposal	140
	12.2.3 Configuring the Transducer Blocks 110			

16	Accessories	141
16.1	Device-specific accessories	141
	16.1.1 Weather protection cover	141
	16.1.2 Mounting bracket for the electronics	1 / 5
	housing	142
	16.1.3 Extension rod / centering HMP40	143
	16.1.4 Mounting kit, isolated	144
	16.1.5 Centering star	145 147
	16.1.6 Remote display FHX50	147
	16.1.8 Bluetooth module for HART devices	149
16.2	Communication-specific accessories	150
16.3	Service-specific accessories	150
16.4	System components	150
10.1	System components	1)(
17	Operating menu	151
17.1	Overview of the operating menu (display	
17.1	module)	151
17.2	Overview of the operating menu (operating	1)1
17.2	tool)	158
17.3	"Setup" menu	165
17.5	17.3.1 "Mapping" wizard	178
	17.3.2 "Analog input 1 to 5" submenu	179
	17.3.3 "Advanced setup" submenu	181
17.4	"Diagnostics" menu	230
	17.4.1 "Diagnostic list" submenu	232
	17.4.2 "Event logbook" submenu	233
	17.4.3 "Device information" submenu	234
	17.4.4 "Measured values" submenu	236
	17.4.5 "Analog input 1 to 5" submenu	238
	17.4.6 "Data logging" submenu	241
	17.4.7 "Simulation" submenu	244
	17.4.8 "Device check" submenu	249
	17.4.9 "Heartbeat" submenu	251
Inde	cr	252
	K	7.7/

1 Important document information

1.1 Document function

These Operating Instructions contain all the information that is required in various phases of the life cycle of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.

1.2 Symbols

1.2.1 Safety symbols


Symbol	Meaning
⚠ DANGER	DANGER! This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.
A WARNING	WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.
▲ CAUTION	CAUTION! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.
NOTICE	NOTE! This symbol contains information on procedures and other facts which do not result in personal injury.

1.2.2 Electrical symbols

Symbol	Meaning
	Direct current
~	Alternating current
$\overline{\sim}$	Direct current and alternating current
-	Ground connection A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.
	Protective Earth (PE) A terminal which must be connected to ground prior to establishing any other connections.
	The ground terminals are situated inside and outside the device: Inner ground terminal: Connects the protectiv earth to the mains supply. Outer ground terminal: Connects the device to the plant grounding system.

1.2.3 Tool symbols

Symbol	Meaning
A0013442	Torx screwdriver
A0011220	Flat blade screwdriver



1.2.4 Symbols for certain types of information

Symbol	Meaning
✓	Permitted Procedures, processes or actions that are permitted.
V	Preferred Procedures, processes or actions that are preferred.
X	Forbidden Procedures, processes or actions that are forbidden.
i	Tip Indicates additional information.
<u> </u>	Reference to documentation.
	Reference to page.
	Reference to graphic.
>	Notice or individual step to be observed.
1., 2., 3	Series of steps.
L_	Result of a step.
?	Help in the event of a problem.
	Visual inspection.

1.2.5 Symbols in graphics

Symbol	Meaning
1, 2, 3	Item numbers
1., 2., 3	Series of steps
A, B, C,	Views
A-A, B-B, C-C,	Sections
<u>/EX</u>	Hazardous area Indicates a hazardous area.
×	Safe area (non-hazardous area) Indicates the non-hazardous area.

1.2.6 Symbols at the device

Symbol	Meaning
A → 📵	Safety instructions Observe the safety instructions contained in the associated Operating Instructions.
	Temperature resistance of the connection cables Specifies the minimum value of the temperature resistance of the connection cables.

1.3 Supplementary documentation

Document	Purpose and content of the document
Technical Information TIO1001F (FMP51, FMP52, FMP54)	Planning aid for your device The document contains all the technical data on the device and provides an overview of the accessories and other products that can be ordered for the device.
Brief Operating Instructions KA01107F (FMP51/FMP52/ FMP54, FOUNDATION Fieldbus)	Guide that takes you quickly to the 1st measured value The Brief Operating Instructions contain all the essential information from incoming acceptance to initial commissioning.
Description of Device Parameters GP01015F (FMP5x, FOUNDATION Fieldbus)	Reference for your parameters The document provides a detailed explanation of each individual parameter in the operating menu. The description is aimed at those who work with the device over the entire life cycle and perform specific configurations.
Special documentation SD00326F	Functional Safety Manual The document is part of the Operating Instructions and serves as a reference for application-specific parameters and notes.
Special documentation SD01872F	Manual for Heartbeat Verification and Heartbeat Monitoring The document contains descriptions of the additional parameters and technical data which are available with the Heartbeat Verification and Heartbeat Monitoring application packages.

- For an overview of the scope of the associated Technical Documentation, refer to the following:
 - The *W@M Device Viewer*: Enter the serial number from the nameplate (www.endress.com/deviceviewer)
 - The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2-D matrix code (QR code) on the nameplate.

1.4 Terms and abbreviations

Term/abbreviation	Explanation
BA	Document type "Operating Instructions"
KA	Document type "Brief Operating Instructions"
TI	Document type "Technical Information"
SD	Document type "Special Documentation"
XA	Document type "Safety Instructions"
PN	Nominal pressure
MWP	Maximum Working Pressure The MWP can also be found on the nameplate.
ToF	Time of Flight
FieldCare	Scalable software tool for device configuration and integrated plant asset management solutions
DeviceCare	Universal configuration software for Endress+Hauser HART, PROFIBUS, FOUNDATION Fieldbus and Ethernet field devices
DTM	Device Type Manager
DD	Device Description for HART communication protocol
$\epsilon_{\rm r}$ (DC value)	Relative dielectric constant
Operating tool	The term "operating tool" is used in place of the following operating software: FieldCare / DeviceCare, for operation via HART communication and PC SmartBlue (app), for operation using an Android or iOS smartphone or tablet.
BD	Blocking Distance; no signals are analyzed within the BD.
PLC	Programmable Logic Controller
CDI	Common Data Interface
PFS	Pulse Frequence Status (Switching output)
MBP	Manchester Bus Powered
PDU	Protocol Data Unit

1.5 Registered trademarks

FOUNDATIONTM Fieldbus

Registered trademark of the FieldComm Group, Austin, Texas, USA

Bluetooth®

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Endress+Hauser is under license. Other trademarks and trade names are those of their respective owners.

Apple[®]

Apple, the Apple logo, iPhone, and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.

Android®

Android, Google Play and the Google Play logo are trademarks of Google Inc.

KALREZ®, VITON®

Registered trademark of DuPont Performance Elastomers L.L.C., Wilmington, USA

TEFLON[®]

Registered trademark of E.I. DuPont de Nemours & Co., Wilmington, USA

TRI CLAMP®

Registered trademark of Alfa Laval Inc., Kenosha, USA

NORD-LOCK®

Registered trademark of Nord-Lock International AB

FISHER®

Registered trademark of Fisher Controls International LLC, Marshalltown, USA

MASONEILAN®

Registered trademark of Dresser, Inc., Addison, USA

2 Basic safety instructions

2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- ► Trained, qualified specialists must have a relevant qualification for this specific function and task.
- ► Are authorized by the plant owner/operator.
- ► Are familiar with federal/national regulations.
- ▶ Before starting work, read and understand the instructions in the manual and supplementary documentation as well as the certificates (depending on the application).
- ▶ Follow instructions and comply with basic conditions.

The operating personnel must fulfill the following requirements:

- ► Are instructed and authorized according to the requirements of the task by the facility's owner-operator.
- ► Follow the instructions in this manual.

2.2 Designated use

Application and measured materials

The measuring device described in these Operating Instructions is intended only for level and interface measurement of liquids. Depending on the version ordered the device can also measure potentially explosive, flammable, poisonous and oxidizing materials.

Observing the limit values specified in the "Technical data" and listed in the Operating Instructions and supplementary documentation, the measuring device may be used for the following measurements only:

- ► Measured process variable: Level and/or interface
- ► Calculated process variable: Volume oder mass in arbitrarily shaped vessels (calculated from the level by the linearization functionality)

To ensure that the measuring device remains in proper condition for the operation time:

- ► Use the measuring device only for measured materials against which the processwetted materials are adequately resistant.
- Observe the limit values in "Technical data".

Incorrect use

The manufacturer is not liable for damage caused by improper or non-designated use.

Verification for borderline cases:

► For special measured materials and cleaning agents, Endress+Hauser is glad to provide assistance in verifying the corrosion resistance of wetted materials, but does not accept any warranty or liability.

Residual risk

The electronics housing and its built-in components such as display module, main electronics module and I/O electronics module may heat to 80 $^{\circ}$ C (176 $^{\circ}$ F) during operation through heat transfer from the process as well as power dissipation within the electronics. During operation the sensor may assume a temperature near the temperature of the measured material.

Danger of burns due to heated surfaces!

► For high process temperatures: Install protection against contact in order to prevent burns.

2.3 Workplace safety

For work on and with the device:

► Wear the required personal protective equipment according to federal/national regulations.

With divisible probe rods, medium may penetrate into the joints between the indivual parts of the rod. This medium may escape when loosening the joints. In the case of dangerous (e.g. aggressive or toxic) media this may cause injuries.

▶ When loosening the joints between the individual parts of the probe rod: Wear appropriate protective equipment according to the medium.

2.4 Operational safety

Risk of injury.

- ▶ Operate the device in proper technical condition and fail-safe condition only.
- ▶ The operator is responsible for interference-free operation of the device.

Conversions to the device

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers.

▶ If, despite this, modifications are required, consult with the manufacturer.

Repair

To ensure continued operational safety and reliability,

- ► Carry out repairs on the device only if they are expressly permitted.
- ▶ Observe federal/national regulations pertaining to repair of an electrical device.
- ▶ Use original spare parts and accessories from the manufacturer only.

Hazardous area

To eliminate a danger for persons or for the facility when the device is used in the hazardous area (e.g. explosion protection, pressure vessel safety):

- ▶ Based on the nameplate, check whether the ordered device is permitted for the intended use in the hazardous area.
- ► Observe the specifications in the separate supplementary documentation that is an integral part of these Instructions.

2.5 Product safety

This measuring device is designed in accordance with good engineering practice to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate. It meets general safety standards and legal requirements.

NOTICE

Loss of degree of protection by opening of the device in humid environments

▶ If the device is opened in a humid environment, the degree of protection indicated on the nameplate is no longer valid. This may also impair the safe operation of the device.

2.5.1 **CE mark**

The measuring system meets the legal requirements of the applicable EC guidelines. These are listed in the corresponding EC Declaration of Conformity together with the standards applied.

Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.

2.5.2 EAC conformity

The measuring system meets the legal requirements of the applicable EAC guidelines. These are listed in the corresponding EAC Declaration of Conformity together with the standards applied.

Endress+Hauser confirms successful testing of the device by affixing to it the EAC mark.

2.6 Safety Instructions (XA)

Depending on the approval, the following Safety Instructions (XA) are supplied with the device. They are an integral part of the Operating Instructions.

Feature 010	Approval	Available for	Feature 020: "Power Supply; Output"				
			A ¹⁾ B ²⁾ C ³⁾ E ⁴⁾ /G ⁵⁾ K ⁶⁾ /L				
BA	ATEX II 1G Ex ia IIC T6 Ga	FMP51FMP52FMP54	XA00496F	XA01125F	XA01126F	XA00516F	-
ВВ	ATEX II 1/2G Ex ia IIC T6 Ga/Gb	FMP51FMP52FMP54	XA00496F	XA01125F	XA01126F	XA00516F	-
ВС	ATEX II 1/2G Ex d[ia] IIC T6 Ga/Gb	FMP51FMP52FMP54	XA00499F	XA00499F	XA00499F	XA00519F	XA01133F
BD	ATEX II 1/3G Ex ic[ia] IIC T6 Ga/Gc	FMP51FMP52FMP54	XA00497F	XA01127F	XA01128F	XA00517F	-
BE	ATEX II 1D Ex t IIIC Da	FMP54	XA00501F	XA00501F	XA00501F	XA00521F	XA00501F
BF	ATEX II 1/2D Ex t IIIC Da/Db	FMP54	XA00501F	XA00501F	XA00501F	XA00521F	XA00501F
BG	ATEX II 3G Ex nA IIC T6 Gc	FMP51FMP52FMP54	XA00498F	XA01130F	XA01131F	XA00518F	XA01132F
ВН	ATEX II 3G Ex ic IIC T6 Gc	FMP51FMP52FMP54	XA00498F	XA01130F	XA01131F	XA00518F	-
BL	ATEX II 1/3G Ex nA[ia] IIC T6 Ga/Gc	FMP51FMP52FMP54	XA00497F	XA01127F	XA01128F	XA00517F	XA01129F
B2	ATEX II 1/2G Ex ia IIC T6 Ga/Gb, 1/2D Ex ia IIIC Da/Db	FMP51FMP52FMP54	XA00502F	XA00502F	XA00502F	XA00522F	-
В3	ATEX II 1/2G Ex d[ia] IIC T6 Ga/Gb, 1/2 D Ex t IIIC Da/Db	FMP51FMP52FMP54	XA00503F	XA00503F	XA00503F	XA00523F	XA01136F
B4	ATEX II 1/2G Ex ia IIC T6 Ga/Gb, Ex d[ia] IIC T6 Ga/Gb	FMP51FMP52FMP54	XA00500F	XA01134F	XA01135F	XA00520F	-
CD	CSA C/US DIP Cl.II,III Div.1 Gr.E-G	FMP54	XA00529F	XA00529F	XA00529F	XA00570F	XA00529F
C2	CSA C/US IS Cl.I,II,III Div.1 Gr.A-G, NI Cl.1 Div.2, Ex ia	FMP51FMP52FMP54	XA00530F	XA00530F	XA00530F	XA00571F	XA00530F
C3	CSA C/US XP Cl.I,II,III Div.1 Gr.A-G, NI Cl.1 Div.2, Ex d	FMP51FMP52FMP54	XA00529F	XA00529F	XA00529F	XA00570F	XA00529F
FB	FM IS Cl.I,II,III Div.1 Gr.A-G, AEx ia, NI Cl.1 Div.2	FMP51FMP52FMP54	XA00531F	XA00531F	XA00531F	XA00573F	XA00531F
FD	FM XP Cl.I,II,III Div.1 Gr.A-G, AEx d, NI Cl.1 Div.2	FMP51FMP52FMP54	XA00532F	XA00532F	XA00532F	XA00572F	XA00532F
FE	FM DIP Cl.II,III Div.1 Gr.E-G	FMP54	XA00532F	XA00532F	XA00532F	XA00572F	XA00532F
GA	EAC Ex ia IIC T6 Ga	FMP51FMP52FMP54	XA01380F	XA01380F	XA01380F	XA01381F	XA01380F

Feature 010	Approval	Available for	Feature 020: "Power Supply; Output"				
			A 1)	B ²⁾	C ₃₎	E ⁴⁾ /G ⁵⁾	K 6)/L 7)
GB	EAC Ex ia IIC T6 Ga/Gb	FMP51FMP52FMP54	XA01380F	XA01380F	XA01380F	XA01381F	XA01380F
GC	EAC Ex d[ia] IIC T6 Ga/Gb	FMP51FMP52FMP54	XA01382F	XA01382F	XA01382F	XA01383F	XA01382F
IA	IEC Ex ia IIC T6 Ga	FMP51FMP52FMP54	XA00496F	XA01125F	XA01126F	XA00516F	-
IB	IEC Ex ia IIC T6 Ga/Gb	FMP51FMP52FMP54	XA00496F	XA01125F	XA01126F	XA00516F	-
IC	IEC Ex d[ia] IIC T6 Ga/Gb	FMP51FMP52FMP54	XA00499F	XA00499F	XA00499F	XA00519F	XA01133I
ID	IEC Ex ic[ia] IIC T6 Ga/Gc	FMP51FMP52FMP54	XA00497F	XA01127F	XA01128F	XA00517F	-
IE	IEC Ex t IIIC Da	FMP54	XA00501F	XA00501F	XA00501F	XA00521F	XA00501F
IF	IEC Ex t IIIC Da/Db	FMP54	XA00501F	XA00501F	XA00501F	XA00521F	XA00501F
IG	IEC Ex nA IIC T6 Gc	FMP51FMP52FMP54	XA00498F	XA01130F	XA01131F	XA00518F	XA01132F
IH	IEC Ex ic IIC T6 Gc	FMP51FMP52FMP54	XA00498F	XA01130F	XA01131F	XA00518F	-
IL	IEC Ex nA[ia] IIC T6 Ga/Gc	FMP51FMP52FMP54	XA00497F	XA01127F	XA01128F	XA00517F	XA01129F
I2	IEC Ex ia IIC T6 Ga/Gb, Ex ia IIIC Da/Db	FMP51FMP52FMP54	XA00502F	XA00502F	XA00502F	XA00522F	-
I3	IEC Ex d [ia] IIC T6 Ga/Gb, Ex t IIIC Da/Db	FMP51FMP52FMP54	XA00503F	XA00503F	XA00503F	XA00523F	XA01136F
I4	IEC Ex II 1/2G Ex ia IIC T6 Ga/Gb, Ex d[ia] IIC T6 Ga/Gb	FMP51FMP52FMP54	XA00500F	XA01134F	XA01135F	XA00520F	-
JC	JPN Ex d[ia] IIC T4 Ga/Gb	FMP51FMP52	-	-	XA01718F	-	-
JD	JPN Ex d[ia] IIC T1 Ga/Gb	FMP54	-	-	XA01718F	-	-
JE	JPN Ex d[ia] IIC T2 Ga/Gb	FMP54	-	-	XA01718F	-	-
KA	KC Ex ia IIC T6 Ga	FMP51FMP52FMP54	XA01169F	-	XA01169F	-	-
KB	KC Ex ia IIC T6 Ga/Gb	FMP51FMP52FMP54	XA01169F	-	XA01169F	-	-
KC	KC Ex d[ia] IIC T6	FMP51FMP52FMP54	-	-	XA01170F	-	-
MA	INMETRO Ex ia IIC T6 Ga	FMP51FMP52FMP54	XA01038F	XA01038F	XA01038F	-	XA01038F

Feature 010	Approval	Available for	Feature 020: "Power Supply; Output"				
			A 1)	B ²⁾	C ₃₎	E ⁴⁾ /G ⁵⁾	K ⁶⁾ /L ⁷⁾
MC	INMETRO Ex d[ia] IIC T6 Ga/Gb	FMP51FMP52FMP54	XA01041F	XA01041F	XA01041F	-	XA01041F
ME	INMETRO Ex t IIIC Da	FMP54	XA01043F	XA01043F	XA01043F	-	XA01043F
МН	INMETRO Ex ic IIC T6 Gc	FMP51FMP52FMP54	XA01040F	XA01040F	XA01040F	-	XA01040F
NA	NEPSI Ex ia IIC T6 Ga	FMP51FMP52FMP54	XA00634F	XA00634F	XA00634F	XA00640F	XA00634F
NB	NEPSI Ex ia IIC T6 Ga/Gb	FMP51FMP52FMP54	XA00634F	XA00634F	XA00634F	XA00640F	XA00634F
NC	NEPSI Ex d[ia] IIC T6 Ga/Gb	FMP51FMP52FMP54	XA00636F	XA00636F	XA00636F	XA00642F	XA00636F
NF	NEPSI DIP A20/21 T8590oC IP66	FMP54	XA00637F	XA00637F	XA00637F	XA00643F	XA00637F
NG	NEPSI Ex nA II T6 Gc	FMP51FMP52FMP54	XA00635F	XA00635F	XA00635F	XA00641F	XA00635F
NH	NEPSI Ex ic IIC T6 Gc	FMP51FMP52FMP54	XA00635F	XA00635F	XA00635F	XA00641F	XA00635F
N2	NEPSI Ex ia IIC T6 Ga/Gb, Ex iaD 20/21 T8590℃	FMP51FMP52FMP54	XA00638F	XA00638F	XA00638F	XA00644F	XA00638F
N3	NEPSI Ex d[ia] IIC T6 Ga/Gb, DIP A20/21 T8590°C IP66	FMP51FMP52FMP54	XA00639F	XA00639F	XA00639F	XA00645F	XA00639F
8A	FM/CSA IS+XP Cl.I,II,III Div.1 Gr.A-G	FMP51FMP52FMP54	XA00531F XA00532F	XA00531F XA00532F	XA00531F XA00532F	XA00572F XA00573F	

- 1) A: 2-wire; 4-20mA HART
- 2) B: 2-wire; 4-20mA HART, switch output
- 3) C: 2-wire; 4-20mA HART, 4-20mA
- 4) E: 2-wire; FOUNDATION Fieldbus, switch output
- 5) G: 2-wire; PROFIBUS PA, switch output
- 6) K: 4-wire 90-253VAC; 4-20mA HART
- 7) L: 4-wire 10,4-48VDC; 4-20mA HART



2.6.1 Ex-marking in case of connected FHX50 remote display

If the device is prepared for the remote display FHX50 (product structure: feature 030: Display, Operation", option L or M), the Ex marking of some certificates changes according to the following table $^{1)}$:

Feature 010 ("Approval")	Feature 030 ("Display, Operation")	Ex-marking
BE	L, M or N	ATEX II 1D Ex ta [ia] IIIC T ₅₀₀ xx°C Da
BF	L, M or N	ATEX II 1/2 D Ex ta [ia Db] IIIC Txx°C Da/Db
BG	L, M or N	ATEX II 3G Ex nA [ia Ga] IIC T6 Gc
ВН	L, M or N	ATEX II 3G Ex ic [ia Ga] IIC T6 Gc
B3	L, M or N	ATEX II 1/2G Ex d [ia] IIC T6 Ga/Gb, ATEX II 1/2D Ex ta [ia Db] IIIC Txx°C Da/Db
IE	L, M or N	IECEx Ex ta [ia] IIIC T500 xx°C Da
IF	L, M or N	IECEx ta [ia Db] IIIC Txx°C Da/Db
IG	L, M or N	IECEx Ex nA [ia Ga] IIC T6 Gc
IH	L, M or N	IECEx Ex ic [ia Ga] IIC T6 Gc
I3	L, M or N	IECEx Ex d [ia] IIC T6 Ga/Gb, IECEx Ex ta [ia Db] IIIC Txx°C Da/Db


18

¹⁾ The marking of certificates not mentioned in this table are not affected by the FHX50.

3 Product description

3.1 Product design


3.1.1 Levelflex FMP51/FMP52/FMP54/FMP55



■ 1 Design of the Levelflex

- 1 Electronics housing
- 2 Process connection (here as an example: flange)
- 3 Rope probe
- 4 End-of-probe weight
- 5 Rod probe
- 6 Coax probe

3.1.2 **Electronics housing**



₽ 2 Design of the electronics housing

- 1 ${\it Electronics\ compartment\ cover}$
- Display module 2
- Main electronics module 3
- Cable glands (1 or 2, depending on instrument version)
- Nameplate
 I/O electronics module
- Terminals (pluggable spring terminals) Connection compartment cover
- 8
- Grounding terminal

20

4 Incoming acceptance and product identification

4.1 Incoming acceptance

Upon receipt of the goods check the following:


- Are the order codes on the delivery note and the product sticker identical?
- Are the goods undamaged?
- Do the nameplate data match the ordering information on the delivery note?
- If required (see nameplate): Are the Safety Instructions (XA) present?
- If one of these conditions is not satisfied, contact your Endress+Hauser Sales Center.

4.2 Product identification

The following options are available for identification of the measuring device:

- Nameplate specifications
- Order code with breakdown of the device features on the delivery note
- Enter serial numbers from nameplates in *W@M Device Viewer* (www.endress.com/deviceviewer): All information about the measuring device is displayed.
- Enter the serial number from the nameplates into the *Endress+Hauser Operations App* or scan the 2-D matrix code (QR code) on the nameplate with the *Endress+Hauser Operations App*: all the information for the measuring device is displayed.

4.2.1 Nameplate



■ 3 Nameplate of the Levelflex; Dimensions: mm (in)

- 1 Device name
- 2 Address of manufacturer
- 3 Order code
- 4 Serial number (Ser. no.)
- 5 Extended order code (Ext. ord. cd.)
- 6 Process pressure
- 7 Gas phase compensation: reference distance
- 8 Certificate symbol
- 9 Certificate and approval relevant data
- 10 Degree of protection: e.g. IP, NEMA
- 11 Document number of the Safety Instructions: e.g. XA, ZD, ZE
- 12 2-D matrix code (QR code)
- 13 Modification mark
- 14 Manufacturing date: year-month
- 15 Permitted temperature range for cable
- 16 Device revision (Dev.Rev.)
- 17 Additional information about the device version (certificates, approvals, communication): e.g. SIL, PROFIBUS
- 18 Firmware version (FW)
- 19 CE mark, C-Tick
- 20 DeviceID
- 21 Material in contact with process
- 22 Permitted ambient temperature (T_a)
- 23 Size of the thread of the cable glands
- 24 Length of probe
- 25 Signal outputs
- 26 Operating voltage

Only 33 digits of the extended order code can be indicated on the nameplate. If the extended order code exceeds 33 digits, the rest will not be shown. However, the complete extended order code can be viewed in the operating menu of the device in the **Extended order code 1 to 3** parameter.

5 Storage, Transport

5.1 Storage conditions

- Permitted storage temperature: -40 to +80 °C (-40 to +176 °F)
- Use the original packaging.

5.2 Transport product to the measuring point

▲ WARNING

Housing or probe may be damaged or break away.

Risk of injury!

- ► Transport the measuring device to the measuring point in its original packaging or at the process connection.
- ▶ Do not fasten lifting devices (hoisting slings, lifting eyes etc.) at the housing or the probe but at the process connection. Take into account the mass center of the device in order to avoid unintended tilting.
- ► Comply with the safety instructions, transport conditions for devices over 18kg (39.6lbs) (IEC61010).




A0013920

6 Mounting

6.1 Mounting requirements

6.1.1 Suitable mounting position



■ 4 Mounting requirements for Levelflex

Mounting distances

■ Distance (A) between wall and rod or rope probe:

- for smooth metallic walls: > 50 mm (2 in)
- for plastic walls: > 300 mm (12 in) to metallic parts outside the vessel
- for concrete walls: > 500 mm (20 in), otherwise the available measuring range may be reduced.
- Distance (B) between rod or rope probe and internal fittings in the vessel: > 300 mm (12 in)
- When using more than one Levelflex:
 - Minimum distance between the sensor axes: 100 mm (3.94 in)
- Distance (C) from end of probe to bottom of the vessel:
 - Rope probe: > 150 mm (6 in)
 - Rod probe: > 10 mm (0.4 in)
 - Coax probe: > 10 mm (0.4 in)

For coax probes the distance to the wall and to internal fittings is arbitrary.


Additional conditions

- When mounting in the open, a weather protection cover (1) may be installed to protect the device against extreme weather conditions.
- In metallic vessels: Preferably do not mount the probe in the center of the vessel (2), as this would lead to increased interference echoes.
 - If a central mounting position can not be avoided, it is crucial to perform an interference echo suppresion(mapping) after the commissioning of the device.
- Do not mount the probe in the filling curtain (3).
- Avoid buckling the rope probe during installation or operation (e.g. through product movement against silo wall) by selecting a suitable mounting location.
- With suspended rope probes (probe end not fixed at the bottom) the distance between the probe rope and internal fittings in the tank must not fall below 300 mm (12") during the entire process. A sporadic contact between the probe weight and the cone of the vessel, however, does not influence the measurement as long as the dielectric constant of the medium is at least DC = 1.8.
- When mounting the electronics housing into a recess (e.g. in a concrete ceiling), observe a minimum distance of 100 mm (4 inch) between the cover of the terminal compartment / electronics compartment and the wall. Otherwise the connection compartment / electronics compartment is not accessible after installation.

6.1.2 Applications with restricted mounting space

Mounting with remote sensor


The device version with a remote sensor is suited for applications with restricted mounting space. In this case the electronics housing is mounted at a separate position from which it is easier accessible.



A001479

- A Angled plug at the probe
- B Angled plug at the electronics housing
- C Length of the remote cable as ordered
- Product structure, feature 600 "Probe Design":
 - Option MB "Sensor remote, 3m/9ft cable"
 - Option MC "Sensor remote, 6m/18ft cable"
 - Option MB "Sensor remote, 9m/27ft cable"
- The remote cable is supplied with these device versions Minimum bending radius: 100 mm (4 inch)
- A mounting bracket for the electronics housing is supplied with these device versions. Mounting options:
 - Wall mounting
 - Pipe mounting; diameter: 42 to 60 mm (1-1/4 to 2 inch)
- The connection cable has got one straight and one angled plug (90°). Depending on the local conditions the angled plug can be connected at the probe or at the electronics housing.
- Probe, electronics and connection cable are adjusted to match each other. They are marked by a common serial number. Only components with the same serial number shall be connected to each other.


Divisible probes



A0021647

If there is little mounting space (distance to the ceiling), it is advisable to use divisible rod probes (ϕ 16 mm).

- max. probe length 10 m (394 in)
- max. sideways capacity 30 Nm
- probes are separable several times with the following lengths of the individual parts:
 - 500 mm (20 in)
 - 1000 mm (40 in)
- torque: 15 Nm



6.1.3 Notes on the mechanical load of the probe

Tensile load limit of rope probes

Sensor	Feature 060	Probe	Tensile load limit [kN]
FMP51	LA, LB, LC, LD MB, MD, ME, MF	Rope 4mm (1/6") 316	5
FMP52	OA, OB, OC, OD	Rope 4mm (1/6") PFA>316	2
FMP54	LA, LB	Rope 4mm (1/6") 316	10

Bending strength of rod probes

Sensor	Feature 060	Probe	Bending strength [Nm]
FMP51	AA, AB	Rod 8mm (1/3") 316L	10
	AC, AD	Rod 12mm (1/2") 316L	30
	AL, AM	Rod 12mm (1/2") AlloyC	30
	BA, BB, BC, BD	Rod 16mm (0.63") 316L divisible	30
FMP52	CA, CB	Rod 16mm (0.63") PFA>316L	30
FMP54	AE, AF	Rod 16mm (0.63") 316L	30
	BA, BB, BC, BD	Rod 16mm (0.63") 316L divisible	30

Bending load (torque) through fluid flow

The formula for calculating the bending torque M impacting on the probe:

$$M = c_w \cdot \rho/2 \cdot v^2 \cdot d \cdot L \cdot (L_N - 0.5 \cdot L)$$

with:

 c_w : Friction factor

 ρ [kg/m³]: Density of the medium

v [m/s]: Velocity of the medium perpendicular to the probe rod

d [m]: Diameter of the probe rod

L [m]: Level

LN [m]: Probe length


Calculation example

Friction factor c_{w} 0,9 (on the assumption of a turbulent current - high


Reynolds number)

Density ρ [kg/m³] 1000 (e.g. water)

Probe diameter d [m] 0,008 $L = L_N \mbox{ (worst case)} \label{eq:local_problem}$



28




Bending strength of coax probes

Sensor	Feature 060	Process connection	Probe	Bending strength [Nm]
FMP51	UA, UB	Thread G¾ oder NPT¾	Coax 316L, Ø 21,3 mm	60
		■ Thread G1½ or NPT1½ ■ Flange	Coax 316L, Ø 42,4 mm	300
	UC, UD	Flange	Coax AlloyC, Ø 42,4 mm	300
FMP54	UA, UB	■ Thread G1½ or NPT1½ ■ Flange	Coax 316L, Ø 42,4 mm	300

6.1.4 Notes on the process connection

Threaded connection



 \blacksquare 5 Mounting with threaded connection; flush with the container ceiling

Seal


The thread as well as the type of seal comply to DIN 3852 Part 1, screwed plug form A.

They can be sealed with the following types of sealing rings:

- Thread G3/4": According to DIN 7603 with the dimensions 27 x 32 mm
- Thread G1-1/2": According to DIN 7603 with the dimensions 48 x 55 mm

Please use a sealing ring according to this standard in the form A, C or D and of a material that is resistant to the application.

Nozzle mounting



H Length of the center rod or the rigid part of the rope probe

- Permissible nozzle height ²⁾: ≤ 150 mm (6 in).
 For a larger height the near range measuring capability may be reduced.
 Larger nozzle heights may be possible in special cases (see sections "Center rod for FMP51 and FMP52" and "Rod extension/centering HMP40 for FMP54").
- The end of the nozzle should be flush with the tank ceiling in order to avoid ringing effects.
- With thermally insulated vessels the nozzle should also be insulated in order to prevent condensate formation.

²⁾ Larger nozzle heights on request

Center rod for FMP51 and FMP52

For rope probes it may be necessary to use a version with center rod in order to prevent the probe rod from coming into contact with the nozzle wall. Probes with center rod are available for FMP51 and FMP52.

Probe	Max. nozzle height (= length of the center rod)	Option to be selected in feature 060 ("Probe")
FMP51	150 mm	LA, LC
	6 inch	LB, LD
	300 mm	MB, ME
	12 inch	MD, MF
FMP52	150 mm	OA
	6 inch	ОС
	300 mm	ОВ
	12 inch	OD

32

Rod extension/centering HMP40 for FMP54


For FMP54 with rope probes the rod extension/centering HMP 40 is available as an accessory. It has to be used if otherwise the probe rope comes into contact with the lower edge of the nozzle.

This accessory consists of the extension rod corresponding to the nozzle height, on which a centering disk is also mounted if the nozzles are narrow or when working in bulk solids. This component is delivered separately from the device. Please order the probe length correspondingly shorter.

Centering disks with small diameters (DN40 and DN50) may only be used if there is no significant build-up in the nozzle above the disk. The nozzle must not become clogged by the product.

Installation in nozzles ≥ DN300

If installation in \geq 300mm/12" nozzles is unavoidable, installation must be carried out in accordance with the following sketch.



- Lower edge of the nozzle Approx. flush with the lower edge of the nozzle (\pm 50 mm/2") 2
- 3 Plate
- *Pipe* Φ 150 to 180 mm (6 to 7 inch)

Nozzle diameter	Plate diameter
300 mm (12")	280 mm (11")
≥ 400 mm (16")	≥ 350 mm (14")


6.1.5 Mounting cladded flanges

- For cladded flanges of FMP52, observe the following:
 - Use flange screws according to the number of flange holes.
 - Tighten the screws with the required torque (see table).
 - Retighten the screws after 24 hours or after the first temperature cycle.
 - Depending on process pressure and process temperature check and retighten the screws at regular intervals.
- Usually, the PTFE flange cladding also serves as a seal between the nozzle and the device flange.

Flange size	Number of screws	Recommended torque [Nm]		
		minimum	maximum	
EN				
DN40/PN40	4	35	55	
DN50/PN16	4	45	65	
DN50/PN40	4	45	65	
DN80/PN16	8	40	55	
DN80/PN40	8	40	55	
DN100/PN16	8	40	60	
DN100/PN40	8	55	80	
DN150/PN16	8	75	115	
DN150/PN40	8	95	145	
ASME				
1½"/150lbs	4	20	30	
1½"/300lbs	4	30	40	
2"/150lbs	4	40	55	
2"/300lbs	8	20	30	
3"/150lbs	4	65	95	
3"/300lbs	8	40	55	
4"/150lbs	8	45	70	
4"/300lbs	8	55	80	
6"/150lbs	8	85	125	
6"/300lbs	12	60	90	
jis	'		1	
10K 40A	4	30	45	
10K 50A	4	40	60	
10K 80A	8	25	35	
10K 100A	8	35	55	
10K 100A	8	75	115	

6.1.6 Securing the probe

Securing rope probes




A0012609

- A Sag of the rope: ≥ 1 cm per 1m of the probe length (0.12 inch per 1 ft of the probe length)
- B Reliably grounded end of probe
- C Reliably isolated end of probe
- 1: Mounting and contact with a bolt
- 2 Mounting kit isolated
- The end of the probe needs to be secured under the following conditions: if otherwise the probe sporadically comes into contact with the wall of the vessel, the outlet cone, internal fittings or other parts of the installation.
- The end of probe can be secured at its internal thread rope 4 mm (1/6"), 316: M 14
- The fixing must be either reliably grounded or reliably insulated. If it is not possible to mount the probe weight with a reliably insulated connection, it can be secured using an isolated eyelet, which is available as an accessory.
- In the case of a grounded fixing the search for a positive end-of-probe signal must be activated. Otherwise an automatic probe length correction is impossible.
 Navigation: Expert → Sensor → EOP evaluation → EOP search mode
 Setting: Positive EOP option
- In order to prevent an extremely high tensile load (e.g. due to thermal expansion) and the risk of rope crack, the rope has to be slack. Make the rope longer than the required measuring range such that there is a sag in the middle of the rope that is $\geq 1 \text{cm}/(1 \text{ m rope length})$ [0.12 inch/(1 ft rope length)].

Tensile load limit of rope probes: $\rightarrow \blacksquare 28$

Securing rod probes

- For WHG approvals: For probe lengths \geq 3 m (10 ft) a support is required.
- In general, rod probes must be supported if there is a horizontal flow (e.g. from an agitator) or in the case of strong vibrations.
- Rod probes may only be supported at the end of the probe.



- Probe rod, uncoated
- 2 Sleeve bored tight to ensure electrical contact between the rod and sleeve!
- 3 Short metal pipe, e.g. welded in place
- 4 Probe rod, coated
- 5 Plastic sleeve, e.g. PTFE, PEEK or PPS
- 6 Short metal pipe, e.g. welded in place

φ probe	Φa [mm (inch)]	Φ b [mm (inch)]
8 mm (1/3")	< 14 (0.55)	8.5 (0.34)
12 mm (1/2")	< 20 (0.78)	12.5 (0.52)
16 mm (0.63in)	< 26 (1.02)	16.5 (0.65)

NOTICE

Poor grounding of the end of probe may cause measuring errors.

▶ Apply a narrow sleeve which has good electrical contact to the probe.


NOTICE

Welding may damage the main electronics module.

▶ Before welding: Ground the probe and dismount electronics.

Securing coax probes

For WHG approvals: For probe lengths \geq 3 m (10 ft) a support is required.



A001260


Coax probes can be supported at any point of the outer tube.

38

6.1.7 Special mounting conditions

Bypasses and stilling wells

In bypass and stilling well applications it is recommended to use a centering disks or stars.



A001261

- 6 Dimensions: mm (in)
- A Mounting in a stilling well
- B Mounting in a bypass
- C Center washer or centering star
- 1 Metallic center washer (316L) for level measurement
- 2 Fixing screw; torque: 25 Nm ± 5 Nm
- Non-metallic centering star (PEEK, PFA) for interface measurement
- 4 Minimum distance between end of probe and lower edge of the bypass; see table below

Allocation of probe type and center washer or centering star to pipe diameter

Feature 610 - Accessory mounted					
Application	Option Type of probe Center washer Centering star			Pipe	
			φ d [mm (in)]	Material	φ D [mm (in)]
Level measurement	OA	Rod probe	75 (2,95)	316L	DN80/3" to DN100/4"
	OB	Rod probe	45 (1,77)	316L	DN50/2" to DN65/21/2"
	OC	Rope probe	75 (2,95)	316L	DN80/3" to DN100/4"
Level or interface	OD	Rod probe	4895 (1,893,74)	PEEK 1)	≥ 50 mm (2")
measurement	OE	Rod probe	37 (1,46)	PFA ²⁾	≥ 40 mm (1.57")

- 1) Operation temperature: -60 to +250 °C (-76 to 482 °F)
- 2) Operation temperature: -200 to +250 °C (-328 to +482 °F)

Minimum distance between end of probe and lower edge of the bypass


Type of probe	Minimum distance
Rope	10 mm (0.4 in)
Rod	10 mm (0.4 in)
Coax	10 mm (0.4 in)

- Pipe diameter: > 40 mm (1.6") for rod probes
- Rod probe installation can take place up to a diameter size of 150 mm (6 in). In the event of larger diameters, a coax probe is recommended.
- Side disposals, holes or slits and welded joints that protrude up to approx. 5 mm (0.2") inwards do not influence the measurement.
- The pipe may not exhibit any steps in diameter.
- The probe must be 100 mm longer than the lower disposal.
- Within the measuring range, the probe must not get into contact with the pipe wall. If necessary, secure the probe by retaining or tensioning. All rope probes are prepared for tensioning in containers (tensioning weight with anchor hole).
- If a metallic center washer is mounted at the end of the probe, it enables a reliable recognition of the end-of-probe signal (see feature 610 of the product structure).
 Note: For interface measurements only use the nonmetallic centering star made of PEEK or PFA (feature 610, options OD or OE).
- Coax probes can always be applied if there is enough mounting space.
- For bypasses with condensate formation (water) and a medium with low dielectric constant (e.g. hydrocarbons):

In the course of time the bypass is filled with condensate up to the lower disposal and for low levels the the level echo is superimposed by the condensate echo. Thus in this range the condensate level is measured instead of the correct level. Only higher levels are measured correctly. To prevent this, position the lower disposal 100 mm (4 in) below the lowest level to be measured and apply a metallic centering disk at the height of the lower edge of the lower disposal.


- With heat insulated tanks the bypass should also be insulated in order to prevent condensate formation.
- For information on bypass solutions from Endress+Hauser please contact your Endress+Hauser sales representative.

Installation in horizontal and upright cylindrical tanks



- Any distance from wall, as long as occasional contact is prevented.When installing in tanks with a lot of internals or internals situated close to the probe: use a coax probe.


Underground tanks



. . .

Use a coax probe for nozzles with large diameters in order to avoid reflections at the nozzle wall.

Installation at an angle




A0014145

- For mechanical reasons, the probe should be installed as vertically as possible.
- With inclined installations the probe length has to be adjusted in dependence to the installation angle.

 - Up to LN = 1 m (3.3 ft): α = 30° Up to LN = 2 m (6.6 ft): α = 10° Up to LN = 4 m (13.1 ft): α = 5°

Non-metallic vessels




- 1 Non-metallic vessel
- 2 Metal sheet or metal flange

To ensure reliable measurements in non-metallic vessels:

- Select an instrument version with metal flange (minimum size DN50/2").
- Or: mount a metal sheet with a diameter of at least 200 mm (8 in) to the probe at the process connection. Its orientation must be perpendicular to the probe.
- A metallic surface is not required for coax probes.

Plastic or glass tanks: Mounting the probe externally at the wall



A001/4150

- 1 Plastic or glass tank
- 2 Metall sheet with threaded sleeve
- 3 No free space between tank wall and probe!

Requirements

- The dielectric constant of the medium must be at least DC > 7.
- The tank wall must be non-conductvie.
- Maximum wall thickness (a):
 - Plastic: < 15 mm (0.6")
 - Glass: < 10 mm (0.4")
- There may be no metallic reinforcements fixed to the tank.

Mounting conditions:

- The probe must be mounted directly to the tank wall (no open space)
- A plastic half pipe with a diameter of approx. 200 mm (8"), or some other protective unit, must be affixed externally to the probe to prevent any influences on the measurement.
- If the tank diameter is less than 300 mm (12"): A metallic grounding sheet must be installed at the opposite side of the tank. The sheet must be conductively connected to the process connection and cover about the half of the vessel's circumference.
- If the tank diameter exceeds 300 mm (12"):

 A metal sheet with a diameter of at least 200 mm (8") must be mounted to the probe at the process connection. Its orientation must be perpendicular to the probe (see above).

Calibration for external probe mounting

If the probe is mounted externally at the wall of the tank, the speed of signal propagation will be reduced. There are two possibilities to compensate for this effect.

Compensation with the gas phase compensation factor

The effect of the dielectric wall can be compared to the effect of a dielectric gas phase. Thus it can be compensated for in the same manner. The compensation factor if given by the quotient of the actual probe length LN and the probe length meausred when the tank is empty.

The device looks for the end of probe signal in the subtracted curve. Thus, the value of the measured probe length depends on the mapping. In order to obtain an exact value, it is advisable to determine the probe length manually using the envelope curve display in FieldCare.

Step	Parameter	Action
1	Expert \rightarrow Sensor \rightarrow Gas phase compensation \rightarrow GPC mode	Select the Const. GPC factor option.
2	Expert \rightarrow Sensor \rightarrow Gas phase compensation \rightarrow Const. GPC factor	Enter quotient: "(Actual probe length)/(Measured probe length)".

Compensation via the calibration parameters


If an acutal gas phase has to be compensated for, the gas phase compensation functionality is no longer available for a correction of the external mounting. In this case the calibration parameters (**Empty calibration** and **Full calibration**) must be adjusted and a value longer than the actual probe length has to be entered into the **Present probe** length parameter. The correction factor for these three parameters is given by the quotient of the probe length measured when the tank is empty and the acutal probe length LN.

The device looks for the end of probe signal in the subtracted curve. Thus, the value of the measured probe length depends on the mapping. In order to obtain an exact value, it is advisable to determine the probe length manually using the envelope curve display in FieldCare.


Step	Parameter	Action
1	Setup → Empty calibration	Increase parameter value by "(Measured probe length)/(Actual probe length)".
2	Setup → Full calibration	Increase parameter value by "(Measured probe length)/(Actual probe length)".
3	Setup \rightarrow Advanced setup \rightarrow Probe settings \rightarrow Probe length correction \rightarrow Confirm probe length	Select the Manual input option.
4	Setup \rightarrow Advanced setup \rightarrow Probe settings \rightarrow Probe length correction \rightarrow Present probe length	Enter measured probe length.

Vessels with heat insulation


If process temperatures are high, the device must be included in normal tank insulation to prevent the electronics heating up as a result of heat radiation or convection. The insulation may not exceed beyond the points labeled "MAX" in the drawings.



- **№** 7 Process connection with thread - FMP51
- Tank insulation
- 2 Compact device
- Sensor remote (feature 600)




- € 8 Process connection with flange - FMP51, FMP52
- Tank insulation
- 2 Compact device
- Sensor remote (feature 600)



A001465

 \blacksquare 9 Process connection with thread - FMP54, sensor version XT and HT

- 1 Tank insulation
- 2 Compact device
- 3 Sensor remote (feature 600)
- * The XT version is not recommended for saturated steam above 200 $^{\circ}$ C (392 $^{\circ}$ F). Use the HT version instead.



A00146

 \blacksquare 10 Process connection with flange - FMP54, sensor version XT and HT


- 1 Tank insulation
- 2 Compact device
- 3 Sensor remote (feature 600)
- * The XT version is not recommended for saturated steam above 200 $^{\circ}$ C (392 $^{\circ}$ F). Use the HT version instead.

Replacing a displacer system in an existing displacer chamber

FMP51 and FMP54 are a perfect replacement for a conventional displacer system in an existing displacer chamber. Endress+Hauser offers flanges that suit Fisher and Masoneilan displacer chamber for this purpose (special product for FMP51; feature 100, options LNJ, LPJ, LQJ for FMP54). Thanks to menu-guided local operation, commissioning the Levelflex only takes a few minutes. Replacement is also possible when partially filled, and wet calibration is not required.

Your benefits:

- No moving parts, thus zero-maintenance operation.
- Not sensitive to process influences such as temperature, density, turbulence and vibrations
- The rod probes can be shortened or replaced easily. In this way, the probe can be easily adjusted on site.



1 Flange of the displacer chamber

Planning instructions:

- In normal cases, use a rod probe. When installing into a metallic displacer chamber up to 150 mm, you have all the advantages of a coax probe.
- It must be ensured that the probe does not come into contact with the side wall. Where necessary, use a center washer or centering star at the lower end of the probe (feature 610 of the product structure).
- The center washer or centering star must be adapted as accurately as possible to the internal diameter of the displacer chamber to also ensure perfect operation in the area of the probe end.

Additional information on interface measurement

- In the case of oil and water the centering disk or centering star should be positioned at the lower edge of the lower disposal (water level).
- \blacksquare The pipe may not exhibit any steps in diameter. Use the coax probe where necessary.
- In the case of rod probes, it must be ensured that the probe does not come into contact with the wall. If necessary, use a center washer or centering star at the end of the probe.
- A plastic centering star has to be used for interface measurement (feature 610, options OD and OE).

6.2 Mounting the device

6.2.1 Required mounting tools

- For mounting thread 3/4": Hexagonal wrench 36 mm
- For mounting thread 1-1/2": Hexagonal wrench 55 mm
- To shorten rod or coax probes: Saw
- To shorten rope probes:
 - Allen key AF 3 mm (for 4mm ropes) or AF 4 mm (for 6 mm ropes)
 - Saw or bolt cutter
- For flanges and other process connections: appropriate mounting tools
- To turn the housing: Hexagonal wrench 8 mm

6.2.2 Shortening the probe

Shortening rod probes


Rod probes must be shortened if the distance to the container floor or outlet cone is less than 10 mm (0.4 in). The rods of a rod probe are shortened by sawing at the bottom end.

Rod probes of FMP52 can **not** be shortened as they are coated.

Shortening rope probes

Rope probes must be shortened if the distance to the container floor or outlet cone is less than 150 mm (6 in).

Rope probes of FMP52 can **not** be shortened as they are coated.



 Rope material
 A
 B
 C
 Torque for set screws

 316
 4 mm (0.16 in)
 40 mm (1.6 in)
 3 mm
 5 Nm (3.69 lbf ft)

- 1. Using an Allen key, loosen the set screws at the end-of-probe weight or the clamping sleeve of the centering disk. Note: The set screws have got a clamping coating in order to prevent accidental loosening. Thus an increased torque might be necessary to loosen them.
- 2. Remove released rope from the weight or sleeve.
- 3. Measure off new rope length.
- 4. Wrap adhesive tape around the rope at the point to be shortened to prevent it from fanning out.
- 5. Saw off the rope at a right angle or cut it off with a bolt cutter.
- 6. Insert the rope completely into the weight or sleeve.
- 7. Screw the set screws into place. Due to the clamping coating of the setscrews application of a screw locking fluid is not necessary.

Shortening coax probes

Coax probes must be shortened if the distance to the container floor or outlet cone is less than 10 mm (0.4 in).


Coax probes can be shortened max. 80 mm (3.2 in) from the end. They have centering units inside, which fix the rod centrally in the pipe. The centerings are held with borders on the rod. Shortening is possible up to approx. 10 mm (0.4 in) below the centering unit.

The coax probe is shortened by sawing the pipe at the bottom end.

Entering the new probe length

After shortening the probe:

1. Go to the **Probe settings** submenu and perform a probe length correction.



A0014241

1 Field for the new probe length

For documentation purposes, enter the new probe length into the Quick Setup which can be found in the electronics housing behind the display module.

6.2.3 FMP54 with gas phase compensation: Mounting the probe rod

This section is only valid for FMP54 with gas phase compensation (product structure: feature 540 "Application Package", option EF or EG).


Coax probes

Coax probes with reference reflection are completely mounted and adjusted on delivery. After mounting they are ready for use. Additional settings are not necessary.

Rod probes

For rod probes with reference reflection the probe rod is delivered separately and has to be mounted as follows:


The joints between the individual rod segments are secured by the included Nord-Lock washers. Install the pre-assembled washers in pairs, cam face to cam face.



- A0014545
- 1. Screw the counter nut onto the connection thread (M10x1) of the gland. Take care that the chamfer is oriented to the gland.
- 2. Place a pair of Nord-Lock washers on the thread.
- 3. Screw the probe rod with the larger diameter onto the thread and fasten it hand-tight.
- 4. Place the second pair of Nord-Lock washers on the threaded bolt.
- 5. Screw the probe rod with the smaller diameter onto the threaded bolt and tighten it with 15 Nm (torque wrench/spanner AF14).
- After mounting the probe rod in the stilling well or bypass, check and if necessary correct the settings in the unpressurized state $\rightarrow \triangleq 100$.

6.2.4 Mounting the device

Mounting devices with thread



A0012528

Devices with mounting thread are screwed into a welding boss or a flange and are usually also secured with these.



- Tighten with the hexagonal nut only:
- Thread 3/4": Hexagonal wrench 36 mm
- Thread 1-1/2": Hexagonal wrench 55 mm
- Maximum permissible torque:
 - Thread 3/4": 45 Nm
 - Thread 1-1/2": 450 Nm
- Recommended torque when using the supplied aramid fibre seal and a process pressure of 40 bar (580 psi):
 - Thread 3/4": 25 Nm
 - Thread 1-1/2": 140 Nm
- When installing in metal containers, take care to ensure good metallic contact between the process connection and container.

Flange mounting


If a seal is used, be sure to use unpainted metal bolts to ensure good electrical contact between probe flange and process flange.

Mounting rope probes

NOTICE

Electrostatic discharges may damage the electronics.

► Earth the housing before lowering the rope into the vessel.



A0012852

When lowering the rope probe into the vessel, observe the following:

- Uncoil rope and lower it slowly and carefully into the vessel.
- Do not kink the rope.
- Avoid any backlash, since this might damage the probe or the vessel fittings.

6.2.5 Mounting the "Sensor remote" version

This section is only valid for devices of the version "Probe Design" = "Sensor remote" (feature 600, option MB/MC/MD).

For the version "Probe design" = "Sensor remote" the following is supplied:


- The probe with the process connection
- The electronics housing
- The mounting bracket for wall or pipe mounting of the electronics housing
- The connection cable (length as ordered). The cable has got one straight and one angled plug (90°). Depending on the local conditions the angled plug can be connected at the probe or at the electronics housing.

A CAUTION

The plugs of the connection cable may be damaged by mechanical stress.

- ▶ Mount the probe and the electronics housing tightly before connecting the cable.
- ► Lay the cable such that it is not exposed to mechanical stress. Minimum bending radius: 100 mm (4").
- ▶ When connecting the cable: Connect the straight plug before the angled one. Torque for both coupling nuts: 6 Nm.
- Probe, electronics and connection cable are adjusted to match each other. They are marked by a common serial number. Only components with the same serial number shall be connected to each other.
- If the measuring point is exposed to strong vibrations, an additional locking compound (e.g. Loctite 243) can be applied at the plug connectors.

Mounting the electronics housing




 $\blacksquare 11$ Mounting the electronics housing using the mounting bracket; dimensions: mm (in)

- A Wall mounting
- B Pipe mounting

Connecting the cable

Required tools:

Open-end wrench 18AF




 \blacksquare 12 Connecting the cable. There are the following possibilities:

- A Angled plug at the probe
- B Angled plug at the electronics housing
- C Length of the remote cable as ordered

6.2.6 Turning the transmitter housing

To provide easier access to the connection compartment or display module, the transmitter housing can be turned:




A0032242

- 1. Unscrew the securing screw using an open-ended wrench.
- 2. Rotate the housing in the desired direction.
- 3. Tighten the securing screw (1.5 Nm for plastic housing; 2.5 Nm for aluminum or stainless steel housing).

6.2.7 Turning the display


Opening cover



A002143

- 1. Loosen the screw of the securing clamp of the electronics compartment cover using an Allen key (3 mm) and turn the clamp 90 $^{\circ}$ counterclockwise.
- 2. Unscrew cover and check lid gasket, replace if necessary.


Turning the display module



A0036401

- 1. Pull out the display module with a gentle rotational movement.
- 2. Rotate the display module to the desired position: max. $8 \times 45^{\circ}$ in each direction.
- 3. Feed the coiled cable into the gap between the housing and main electronics module and plug the display module into the electronics compartment until it engages.

Closing electronics compartment cover



A0021451

- 1. Screw back firmly electronics compartment cover.
- 2. Turning securing clamp 90 ° clockwise and tighten the clamp with 2.5 Nm using the Allen key (3 mm).

6.3 Post-installation check


О	Is the device undamaged (visual inspection)?
0	Does the device conform to the measuring point specifications? For example: Process temperature Process pressure (refer to the chapter on "Material load curves" of the "Technical Information" document) Ambient temperature range Measuring range
0	Are the measuring point identification and labeling correct (visual inspection)?
0	Is the device adequately protected from precipitation and direct sunlight?
0	Are the securing screw and securing clamp tightened securely?

7 Electrical connection

7.1 Connection conditions

7.1.1 Terminal assignment

Terminal assignment 4-wire: 4-20 mA HART (90 to 253 V_{AC})



 \blacksquare 13 Terminal assignment 4-wire: 4-20 mA HART (90 to 253 V_{AC})


- 1 Connection 4-20 mA HART (active): terminals 3 and 4
- 2 Connection supply voltage: terminals 1 and 2
- 3 Terminal for cable screen

A CAUTION

To ensure electrical safety:

- ▶ Do not disconnect the protective connection.
- ▶ Disconnect the supply voltage before disconnecting the protective earth.
- Connect protective earth to the internal ground terminal (3) before connecting the supply voltage. If necessary, connect the potential matching line to the external ground terminal.
- In order to ensure electromagnetic compatibility (EMC): Do **not** only ground the device via the protective earth conductor of the supply cable. Instead, the functional grounding must also be connected to the process connection (flange or threaded connection) or to the external ground terminal.
- An easily accessible power switch must be installed in the proximity of the device. The power switch must be marked as a disconnector for the device (IEC/EN61010).


Terminal assignment PROFIBUS PA / FOUNDATION Fieldbus



 \blacksquare 14 Terminal assignment PROFIBUS PA / FOUNDATION Fieldbus

- A Without integrated overvoltage protection
- B With integrated overvoltage protection
- 1 Connection PROFIBUS PA / FOUNDATION Fieldbus: terminals 1 and 2, without integrated overvoltage protection
- 2 Connection switch output (Open Collector): terminals 3 and 4, without integrated overvoltage protection
- 3 Connection switch output (Open Collector): terminals 3 and 4, with integrated overvoltage protection
- 4 Connection PROFIBUS PA / FOUNDATION Fieldbus: terminals 1 and 2, with integrated overvoltage protection
- 5 Terminal for cable screen


Block diagram PROFIBUS PA / FOUNDATION Fieldbus



A00365

- 15 Block diagram PROFIBUS PA / FOUNDATION Fieldbus
- 1 Cable screen; observe cable specifications
- 2 Connection PROFIBUS PA / FOUNDATION Fieldbus
- 3 Measuring device
- 4 Switch output (open collector)

Connection examples for the switch output



For optimum interference immunity we recommend to connect an external resistor (internal resistance of the relay or Pull-up resistor) of $< 1000 \Omega$.

7.1.2 Cable specification

- Devices without integrated overvoltage protection
 Pluggable spring-force terminals for wire cross-sections 0.5 to 2.5 mm² (20 to 14 AWG)
- Devices with integrated overvoltage protection
 Screw terminals for wire cross-sections 0.2 to 2.5 mm² (24 to 14 AWG)
- For ambient temperature $T_{IJ} \ge 60 \,^{\circ}\text{C}$ (140 $^{\circ}\text{F}$): use cable for temperature $T_{IJ} + 20 \,^{\circ}\text{K}$.

FOUNDATION Fieldbus


Endress+Hauser recommends using twisted, shielded two-wire cables.

For further information on the cable specifications, see Operating Instructions BA00013S "FOUNDATION Fieldbus Overview", FOUNDATION Fieldbus Guideline and IEC 61158-2 (MBP).


7.1.3 **Device plug connectors**

For the versions with fieldbus plug connector (M12 or 7/8"), the signal line can be connected without opening the housing.

Pin assignment of the M12 plug connector



Pin assignment of the 7/8" plug connector



7.1.4 Power supply

PROFIBUS PA, FOUNDATION Fieldbus

"Power supply; Output" 1)	"Approval" ²⁾	Terminal voltage
E: 2-wire; FOUNDATION Fieldbus, switch output G: 2-wire; PROFIBUS PA, switch output	 Non-Ex Ex nA Ex nA[ia] Ex ic Ex ic[ia] Ex d[ia] / XP Ex ta / DIP CSA GP 	9 to 32 V ³⁾
	Ex ia / ISEx ia + Ex d[ia] / IS + XP	9 to 30 V ³⁾

- 1) Feature 020 of the product structure
- 2) Feature 010 of the product structure
- 3) Input voltages up to 35 V will not spoil the device.

Polarity sensitive	No
FISCO/FNICO compliant according to IEC 60079-27	Yes

7.1.5 Overvoltage protection

If the measuring device is used for level measurement in flammable liquids which requires the use of overvoltage protection according to DIN EN 60079-14, standard for test procedures 60060-1 (10 kA, pulse 8/20 μ s), an overvoltage protection module has to be installed.

Integrated overvoltage protection module

An integrated overvoltage protection module is available for 2-wire HART as well as PROFIBUS PA and FOUNDATION Fieldbus devices.

Product structure: Feature 610 "Accessory mounted", option NA "Overvoltage protection".

Technical data		
Resistance per channel	2 × 0.5 Ω max.	
Threshold DC voltage	400 to 700 V	
Threshold impulse voltage	< 800 V	
Capacitance at 1 MHz	< 1.5 pF	
Nominal arrest impulse voltage (8/20 μs)	10 kA	

External overvoltage protection module

HAW562 or HAW569 from Endress+Hauser are suited as external overvoltage protection.



For detailed information please refer to the following documents:

HAW562: TI01012KHAW569: TI01013K

7.2 Connecting the measuring device

WARNING


Risk of explosion!

- ► Observe applicable national standards.
- ► Comply with the specifications in the Safety Instructions (XA).
- ► Use specified cable glands only.
- ▶ Check to ensure that the power supply matches the information on the nameplate.
- ► Switch off the power supply before connecting the device.
- ► Connect the potential matching line to the outer ground terminal before applying the power supply.

Required tools/accessories:

- For devices with a cover lock: Allen key AF3
- Wire stripper
- When using stranded cables: One ferrule for every wire to be connected.


7.2.1 Opening connection compartment cover



A0021490


- 1. Loosen the screw of the securing clamp of the connection compartment cover using an Allen key (3 mm) and turn the clamp 90 ° clockwise.
- 2. Afterwards unscrew connection compartment cover and check lid gasket, replace if necessary.

7.2.2 Connecting



■ 18 Dimensions: mm (in)


- 1. Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 2. Remove the cable sheath.
- 3. Strip the cable ends over a length of 10 mm (0.4 in). In the case of stranded cables, also fit ferrules.
- 4. Firmly tighten the cable glands.
- 5. Connect the cable in accordance with the terminal assignment.



6. If using shielded cables: Connect the cable shield to the ground terminal.

7.2.3 Plug-in spring-force terminals

In the case of devices without integrated overvoltage protection, electrical connection is via plug-in spring-force terminals. Rigid conductors or flexible conductors with ferrules can be inserted directly into the terminal without using the lever, and create a contact automatically.




■ 19 Dimensions: mm (in)

To remove cables from the terminal:

- 1. Using a flat-blade screwdriver ≤ 3 mm, press down on the slot between the two terminal holes
- 2. while simultaneously pulling the cable end out of the terminal.

7.2.4 Closing connection compartment cover



A002149

- 1. Screw back firmly connection compartment cover.
- 2. Turning securing clamp 90 ° counterclockwise and tighten the clamp with 2.5 Nm (1.84 lbf ft) again using the Allen key (3 mm).

7.3 Post-connection check

Is the device or cable undamaged (visual check)?
Do the cables comply with the requirements ?
Do the cables have adequate strain relief?
Are all cable glands installed, securely tightened and leak-tight?
Does the supply voltage match the specifications on the nameplate?
Is the terminal assignment correct?

If required: Has protective ground connection been established ?
If supply voltage is present, is the device ready for operation and do values appear on the display module?
Are all housing covers installed and securely tightened?
Is the securing clamp tightened correctly?


8 Operation options

8.1 Overview

8.1.1 Local operation

Operation with	Pushbuttons	Touch Control	
Order code for "Display; Operation"	Option C "SD02"	Option E "SD03"	
Display	A0036312 4-line display	A0036313 4-line display	
elements		white background lighting; switches to red in event of device error	
	Format for displaying measured variables and status variables can be individually configured		
		nitted ambient temperature for the display: -20 to $+70$ °C (-4 to $+158$ °F) readability of the display may be impaired at temperatures outside the temperature e.	
Operating elements	local operation with 3 push buttons (⊕, ⊡, ₺)	\oplus , \Box , \blacksquare) external operation via touch control; 3 optical keys: \oplus , \Box , \blacksquare	
	Operating elements also accessible in various hazardous areas		
Additional functionality	Data backup function The device configuration can be saved in the display module.		
	Data comparison function The device configuration saved in the display module can be compared to the current device configuration.		
	Data transfer function The transmitter configuration can be transmitted to another device using the display module.		

8.1.2 Operation with remote display and operating module FHX50




■ 20 FHX50 operating options

- Display and operating module SD03, optical keys; can be operated through the glass of the cover
- 2 Display and operating module SD02, push buttons; cover must be removed

8.1.3 Remote operation

Via FOUNDATION Fieldbus




 \blacksquare 21 FOUNDATION Fieldbus system architecture with associated components

- 1 FFblue Bluetooth modem
- 2 Field Xpert SFX350/SFX370
- 3 DeviceCare/FieldCare
- 4 NI-FF interface card

IN	Industrial network
FF-HSE	High Speed Ethernet
FF-H1	FOUNDATION Fieldbus-H1
LD	Linking Device FF-HSE/FF-H1
PS	Bus Power Supply
SB	Safety Barrier
BT	Bus Terminator

DeviceCare/FieldCare via service interface (CDI)



DeviceCare/FieldCare via service interface (CDI)

- Service interface (CDI) of the instrument (= Endress+Hauser Common Data Interface)
- Commubox FXA291
- 2 3 $Computer\ with\ Device Care/Field Care\ operating\ tool$

70

8.2 Structure and function of the operating menu

8.2.1 Structure of the operating menu

Menu	Submenu / parameter	Meaning
	Language ¹⁾	Defines the operating language of the on-site display
Commissioning ²⁾		Launches the interactive wizard for guided commissioning. Additional settings generally do not need to be made in the other menus when the wizard is finished.
Setup	Parameter 1 Parameter N	Once values have been set for these parameters, the measurement should generally be completely configured.
	Advanced setup	Contains additional submenus and parameters: to adapt the device to special measuring conditions. to process the measured value (scaling, linearization). to configure the signal output.
Diagnostics	Diagnostic list	Contains up to 5 currently active error messages.
	Event logbook 3)	Contains the last 20 messages (which are no longer active).
	Device information	Contains information for identifying the device.
	Measured values	Contains all current measured values.
	Data logging	Contains the history of the individual measuring values.
	Simulation	Is used to simulate measured values or output values.
	Device check	Contains all parameters needed to check the measurement capability of the device.
	Heartbeat 4)	Contains all the wizards for the Heartbeat Verification and Heartbeat Monitoring application packages.
Expert 5) Contains all parameters of the device (including those that are already in one of the other menus). This menu is organized	System	Contains all higher-order device parameters that do not concern the measurement or measured value communication.
according to the function blocks of the device. The parameters of the Expert menu are described in:	Sensor	Contains all parameters needed to configure the measurement.
GP01015F (FOUNDATION Fieldbus)	Output	Contains all parameters needed to configure the switch output (PFS).

Menu	Submenu / parameter	Meaning
	Communication	Contains all parameters needed to configure the digital communication interface.
	Diagnostics	Contains all parameters needed to detect and analyze operational errors.

- 1) If operating via operating tools (e.g. FieldCare), the "Language" parameter is located under "Setup \rightarrow Advanced setup → Display"

 Only if operating via an FDT/DTM system only available with local operation
- 2)
- 3)
- 4) 5) only available if operating via DeviceCare or FieldCare
 On entering the "Expert" menu, an access code is always requested. If a customer specific access code has not been defined, "0000" has to be entered.

8.2.2 User roles and related access authorization

The two user roles **Operator** and **Maintenance** have different write access to the parameters if a device-specific access code has been defined. This protects the device configuration via the local display from unauthorized access $\rightarrow \blacksquare 73$.

Access authorization to parameters

User role	Read access		Write access	
	Without access code (from the factory)	With access code	Without access code (from the factory)	With access code
Operator	V	V	V	
Maintenance	V	V	V	V

If an incorrect access code is entered, the user obtains the access rights of the **Operator** role.



The user role with which the user is currently logged on is indicated by the **Access status display** parameter (for display operation) or **Access status tooling** parameter (for tool operation).

8.2.3 Data access - Security

Write protection via access code

Using the device-specific access code, the parameters for the measuring device configuration are write-protected and their values can no longer be changed via local operation.

Define access code via local display

- Navigate to: Setup → Advanced setup → Administration → Define access code
 Define access code
- 2. Define a max. 4-digit numeric code as an access code.
- 3. Repeat the same code in **Confirm access code** parameter.
 - ► The 🗈-symbol appears in front of all write-protected parameters.

Define access code via operating tool (e.g. FieldCare)

- 1. Navigate to: Setup \rightarrow Advanced setup \rightarrow Administration \rightarrow Define access code
- 2. Define a max. 4-digit numeric code as an access code.
 - **▶** Write protection is active.

Parameters that can always be changed

The write protection does not include certain parameters that do not affect the measurement. Despite the defined access code, they can always be modified, even if the other parameters are locked.

The device automatically locks the write-protected parameters again if a key is not pressed for 10 minutes in the navigation and editing view. The device locks the write-protected parameters automatically after 60 s if the user skips back to the measured value display mode from the navigation and editing view.



- If write access is activated via access code, it can be also be deactivated only via the access code → ₱ 74.
- \blacksquare In the "Description of Device Parameters" documents, each write-protected parameter is identified with the \blacksquare -symbol.

Disabling write protection via access code

If the \square -symbol appears on the local display in front of a parameter, the parameter is write-protected by a device-specific access code and its value cannot be changed at the moment using the local display $\rightarrow \square$ 73.

The locking of the write access via local operation can be disabled by entering the device-specific access code.

- 1. After you press E, the input prompt for the access code appears.
- 2. Enter the access code.
 - The \(\mathbb{O}\)-symbol in front of the parameters disappears; all previously write-protected parameters are now re-enabled.

Deactivation of the write protection via access code

Via local display

- Navigate to: Setup → Advanced setup → Administration → Define access code
 Define access code
- 2. Enter **0000**.
- 3. Repeat **0000** in **Confirm access code** parameter.
 - The write protection is deactivated. Parameters can be changed without entering an access code.

Via an operating tool (e.g. FieldCare)


- 1. Navigate to: Setup \rightarrow Advanced setup \rightarrow Administration \rightarrow Define access code
- 2. Enter **0000**.
 - The write protection is deactivated. Parameters can be changed without entering an access code.

Write protection via write protection switch

Unlike parameter write protection via a user-specific access code, this allows write access to the entire operating menu - except for the **"Contrast display" parameter** - to be locked.


The parameter values are now read only and cannot be edited any more (exception "Contrast display" parameter):

- Via local display
- Via FOUNDATION Fieldbus




A0021474

- 1. Loosen the securing clamp.
- 2. Unscrew the electronics compartment cover.
- 3. Pull out the display module with a gentle rotational movement. To make it easier to access the lock switch, attach the display module to the edge of the electronics compartment.



A0036086

- 4. Setting the write protection switch (WP) on the main electronics module to the **ON** position enables hardware write protection. Setting the write protection switch (WP) on the main electronics module to the **OFF** position (factory setting) disables hardware write protection.
 - If the hardware write protection is enabled: The Hardware locked option is displayed in the Locking status parameter. In addition, on the local display the
 ⑤-symbol appears in front of the parameters in the header of the operational display and in the navigation view.



If the hardware write protection is disabled: No option is displayed in the **Locking status** parameter. On the local display, the 🛍-symbol disappears from in front of the parameters in the header of the operational display and in the navigation view.

- 5. Feed the cable into the gap between the housing and main electronics module and plug the display module into the electronics compartment in the desired direction until it engages.
- 6. Reverse the removal procedure to reassemble the transmitter.

76

Enabling and disabling the keypad lock

The keypad lock makes it possible to block access to the entire operating menu via local operation. As a result, it is no longer possible to navigate through the operating menu or change the values of individual parameters. Users can only read the measured values on the operational display.

The keypad lock is switched on and off via the context menu.

Switching on the keypad lock

For the SD03 display only

The keypad lock is switched on automatically:

- If the device has not been operated via the display for > 1 minute.
- Each time the device is restarted.

To activate the keylock manually:

1. The device is in the measured value display.

Press E for at least 2 seconds.

- ► A context menu appears.
- 2. In the context menu select the **Keylock on** option.
 - ► The keypad lock is switched on.
- If the user attempts to access the operating menu while the keypad lock is active, the message **Keylock on** appears.

Switching off the keypad lock

1. The keypad lock is switched on.

Press E for at least 2 seconds.

- ► A context menu appears.
- 2. In the context menu select the **Keylock off** option.
 - ► The keypad lock is switched off.


Bluetooth® wireless technology

Signal transmission via Bluetooth® wireless technology uses a cryptographic technique tested by the Fraunhofer Institute

- The device is not visible via *Bluetooth*® wireless technology without the SmartBlue app
- Only one point-to-point connection between one sensor and one smartphone or tablet is established

8.3 Display and operating module

8.3.1 Display appearance



■ 23 Appearance of the display and operation module for on-site operation

- Measured value display (1 value max. size)
- 1.1 Header containing tag and error symbol (if an error is active)
- 1.2 Measured value symbols
- 1.3 Measured value
- 1.4 Unit
- 2 Measured value display (1 bargraph + 1 value)
- 2.1 Bargraph for measured value 1
- 2.2 Measured value 1 (including unit)
- 2.3 Measured value symbols for measured value 1
- 2.4 Measured value 2
- 2.5 Unit for measured value 2
- 2.6 Measured value symbols for measured value 2
- 3 Representation of a parameter (here: a parameter with selection list)
- 3.1 Header containing parameter name and error symbol (if an error is active)
- 3.2 Selection list; \square marks the current parameter value.
- 4 Input matrix for numbers
- 5 Input matrix for alphanumeric and special characters

78

Display symbols for the submenus

Symbol	Meaning
A0018367	Display/operation Is displayed: in the main menu next to the selection "Display/operation" in the header, if you are in the "Display/operation" menu
A0018364	Setup Is displayed: in the main menu next to the selection "Setup" in the header, if you are in the "Setup" menu
A0018365	Expert Is displayed: in the main menu next to the selection "Expert" in the header, if you are in the "Expert" menu
A0018366	Diagnostics Is displayed: ■ in the main menu next to the selection "Diagnostics" ■ in the header, if you are in the "Diagnostics" menu

Status signals

A0032902	"Failure" A device error is present. The measured value is no longer valid.
C	"Function check" The device is in service mode (e.g. during a simulation).
S	 "Out of specification" The device is operated: Outside of its technical specifications (e.g. during startup or a cleaning) Outside of the configuration carried out by the user (e.g. level outside configured span)
M A0032905	"Maintenance required" Maintenance is required. The measured value is still valid.

Display symbols for the locking state

Symbol	Meaning
A0013148	Display parameter Marks display-only parameters which can not be edited.
A0013150	 ■ In front of a parameter name: The device is locked via software and/or hardware. ■ In the header of the measured value screen: The device is locked via hardware.


Measured value symbols

Symbol	Meaning
Measured values	
~-	Level
A0032892	
A0032893	Distance
(-)	Current output
A0032908	
A	Measured current
A0032894	
(Terminal voltage
A0032895	
	Temperature of the electronics or the sensor
A0032896	
Measuring channels	
1	Measuring channel 1
A0032897	
2	Measuring channel 2
A0032898	
Status of the measured	value
A0018361	Status "Alarm" The measurment is interrupted. The output assumes the defined alarm value. A diagnostic message is generated.
A0018360	Status "Warning" The device continues measuring. A diagnostic message is generated.

8.3.2 Operating elements

Key	Meaning
	Minus key
A0018330	For menu, submenu Moves the selection bar upwards in a picklist.
	For text and numeric editor In the input mask, moves the selection bar to the left (backwards).
	Plus key
+	For menu, submenu Moves the selection bar downwards in a picklist.
A0018329	For text and numeric editor In the input mask, moves the selection bar to the right (forwards).
	Enter key
	For measured value display ■ Pressing the key briefly opens the operating menu. ■ Pressing the key for 2 s opens the context menu.
E)	 For menu, submenu Pressing the key briefly Opens the selected menu, submenu or parameter. Pressing the key for 2 s for parameter: If present, opens the help text for the function of the parameter.
	For text and numeric editor Pressing the key briefly Opens the selected group. Carries out the selected action. Pressing the key for 2 s confirms the edited parameter value.
	Escape key combination (press keys simultaneously)
— + +	For menu, submenu ■ Pressing the key briefly - Exits the current menu level and takes you to the next higher level. - If help text is open, closes the help text of the parameter. ■ Pressing the key for 2 s returns you to the measured value display ("home position").
	For text and numeric editor Closes the text or numeric editor without applying changes.
-+E	Minus/Enter key combination (press and hold down the keys simultaneously)
	Reduces the contrast (brighter setting).
++E A0032911	Plus/Enter key combination (press and hold down the keys simultaneously) Increases the contrast (darker setting).

8.3.3 Entering numbers and text



Input mask


The following input symbols are available in the input mask of the numeric and text editor:

Numeric editor symbols

Symbol	Meaning
0	Selection of numbers from 0 to 9.
9 A0013998	
A0016619	Inserts decimal separator at the input position.
A0016620	Inserts minus sign at the input position.
A0013985	Confirms selection.
A0016621	Moves the input position one position to the left.
X A0013986	Exits the input without applying the changes.
A0014040	Clears all entered characters.

Text editor symbols

Symbol	Meaning
ABCXYZ	Selection of letters from A to Z
Aa1 @	Toggle Between upper-case and lower-case letters For entering numbers For entering special characters



Correction symbols under \nearrow

Symbol	Meaning
C	Clears all entered characters.
A0032907	
-	Moves the input position one position to the right.
A0018324	
4	Moves the input position one position to the left.
A0018326	
₽ X	Deletes one character immediately to the left of the input position.
A0032906	

8.3.4 Opening the context menu


Using the context menu, the user can call up the following menus quickly and directly from the operational display:

- Setup
- Conf. backup disp.
- Env.curve
- Keylock on

Opening and closing the context menu

The user is in the operational display.

- 1. Press E for 2 s.
 - └ The context menu opens.



A0033110-EN

- 2. Press \Box + \pm simultaneously.
 - └ The context menu is closed and the operational display appears.


Calling up the menu via the context menu

- 1. Open the context menu.
- 2. Press ± to navigate to the desired menu.
- 3. Press **E** to confirm the selection.
 - ► The selected menu opens.

84

8.3.5 Envelope curve on the display and operating module

In order to assess the measuring signal, the envelope curve and - if a mapping has been recorded - the mapping curve can be displayed:



9 Integration into a FOUNDATION Fieldbus network

9.1 Device Description (DD)

You require the following to configure a device and integrate it into an FF network:

- An FF configuration program
- The Cff file (Common File Format: *.cff)
- The device description (DD) in one of the following formats
 - Device Description format 4: *sym, *ffo
 - Device Description format 5: *sy5, *ff5

Information on the device-specific DD

Manufacturer ID	452B48hex
Device Type	100Fhex
Device Revision	05hex
DD Revision	Information and files at:
CFF Revision	www.endress.comwww.fieldcommgroup.org

9.2 Integration into the FOUNDATION Fieldbus network

- For more in-depth information on integrating the device into the FF system, see the description for the configuration software used.
 - When integrating the field devices into the FF system, make sure you are using the right files. You can read out the required version by means of the Device Revision/ DEV REV and DD Revision/ DD REV parameters in the Resource Block.


The device is integrated into the FF network as follows:

- 1. Start the FF configuration program.
- 2. Download the Cff and device description files (*.ffo, *.sym (for format 4) *ff5, *sy5 (for format 5) to the system.
- 3. Configure the interface.
- 4. Configure the device for the measuring task and for the FF system.

9.3 Device identification and addressing

FOUNDATION Fieldbus identifies the device using its ID code (Device ID) and automatically assigns it a suitable field address. The identity code cannot be changed. The device appears in the network display once you have started the FF configuration program and integrated the device into the network. The blocks available are displayed under the device name.

If the device description has not yet been loaded, the blocks report "Unknown" or "(UNK)".



■ 24 Typical display in a configuration program after the connection has been established

- 1 Device name
- 2 Serial number

9.4 Block model

9.4.1 Blocks of the device software

The device has the following blocks:

- Resource Block (device block)
- Transducer Blocks
 - Setup Transducer Block (TRDSUP)
 - Advanced Setup Transducer Block (TRDASUP)
 - Display Transducer Block (TRDDISP)
 - Diagnostic Transducer Block (TRDDIAG)
 - Expert Configuration Transducer Block (TRDEXP)
 - Expert Information Transducer Block (TRDEXPIN)
 - Service Sensor Transducer Block (TRDSRVSB)
 - Service Information Transducer Block (TRDSRVIF)
 - Data Transfer Transducer Block (TRDHROM)
- Function Blocks
 - 2 Analog Input Blocks (AI)
 - 1 Discrete Input Block (DI)
 - 1 PID Block (PID)
 - 1 Arithmetic Block (AR)
 - 1 Signal Characterizer Block (SC)
 - 1 Input Selector Block (IS)
 - 1 Integrator Block (IT)
 - 1 Analog Alarm Block (AAL)

In addition to the pre-instantiated blocks already mentioned, the following blocks can also be instantiated:


- 5 Analog Input Blocks (AI)
- 2 Discrete Input Blocks (DI)
- 3 PID Blocks (PID)
- 3 Arithemetic Blocks (AR)
- 2 Signal Characterizer Blocks (SC)
- 5 Input Selector Blocks (IS)
- 3 Integrator Blocks (IT)
- 2 Analog Alarm Blocks (AAL)

Up to 20 blocks can be instantiated in the device altogether, including the blocks already instantiated. For instantiating blocks, see the appropriate Operating Instructions of the configuration program used.

Endress+Hauser Guideline BA00062S.

The guideline provides an overview of the standard function blocks that are described in FOUNDATION Fieldbus Specifications FF 890 - 894. It is designed to help operators use the blocks implemented in the Endress+Hauser field devices.

9.4.2 Block configuration when device is delivered



■ 25 Block configuration when device is delivered

S Sensor

PV Primary value: Level linearized

SV Secondary value: Distance

9.5 Assignment of the measured values (CHANNEL) in an AI Block

The input value of an Analog Input Block is defined by the **CHANNEL** parameter.

Channel	Measured value
0	Uninitialized
89	Measured capacitance
144	EOP shift

Channel	Measured value
145	Interface distance
172	Calculated DC value
211	Terminal voltage
212	Sensor debug
32785	Absolute EOP amplitude
32786	Absolute echo amplitude
32787	Absolute interface amplitude
32856	Distance
32885	Elektronic temperature
32938	Interface linearized
32949	Level linearized
33044	Relative echo amplitude
33045	Relative interface amplitude
33070	Noise of signal
33107	Upper interface thickness

9.6 Index tables of Endress+Hauser parameters

The following tables list the manufacturer-specific device parameters for the Resource Blocks. For the FOUNDATION Fieldbus parameters, see the document BA062S "Guidline - FOUNDATION Fieldbus Function Blocks", which can be downloaded from www.endress.com.

9.6.1 Setup Transducer Block

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BL K	Description
confirm_distance	Confirm distance	82	ENUM16	2	Static	х	oos	→ 🖺 175
filtered_dist_val	Distance	76	FLOAT	4	Dynamic			→ 🖺 170
interface_distance	Interface distance	79	FLOAT	4	Dynamic			→ 🖺 175
map_end_x	Present mapping	84	FLOAT	4	Dynamic			→ 🖺 176
mapping_end_point	Mapping end point	83	FLOAT	4	Static	х	AUTO	→ 🖺 177
record_map	Record map	86	ENUM16	2	Static	х	oos	→ 🖺 177
operating_mode	Operating mode	50	ENUM16	2	Static	х	OOS	→ 🖺 165
signal_quality	Signal quality	81	ENUM16	2	Dynamic			→ 🖺 171
medium_group	Medium group	55	ENUM16	2	Static	х	OOS	→ 🖺 166
tank_level	Tank level	66	ENUM16	2	Static	х	oos	→ 🖺 172
tank_type	Tank type	52	ENUM16	2	Static	х	OOS	→ 🖺 165
tube_diameter	Tube diameter	53	FLOAT	4	Static	х	OOS	→ 🖺 166
dc_value	DC value	68	ENUM16	2	Static	х	OOS	→ 🖺 173
distance_to_upper_connect ion	Distance to upper connection	67	FLOAT	4	Static	х	OOS	→ 🖺 172
empty_calibration	Empty calibration	56	FLOAT	4	Static	х	OOS	→ 🖺 167
full_calibration	Full calibration	57	FLOAT	4	Static	х	OOS	→ 🖺 168
distance_unit	Distance unit	51	ENUM16	2	Static	х	OOS	→ 🖺 165

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BL K	Description
interface	Interface	70	FLOAT	4	Dynamic			→ 🖺 174
level_unit	Level unit	58	ENUM16	2	Static	х	OOS	→ 🖺 186
output_unit_after_lineariza tion	Unit after linearization	62	ENUM16	2	Static			→ 🖺 198
level_linearized	Level linearized	64	FLOAT	4	Dynamic			→ 🖺 199
present_probe_length	Present probe length	87	FLOAT	4	Dynamic	х	AUTO	→ 🖺 208
level	Level	60	FLOAT	4	Dynamic			→ 🖺 169
interface_linearized	Interface linearized	73	FLOAT	4	Dynamic			→ 🖺 200
decimal_places_menu_ro	Decimal places	93	ENUM16	2	Static	х	AUTO	→ 🖺 219
locking_status	Locking status	96	BIT_ENU M16	2	Dynamic			→ 🖺 181
medium_type_ro	Medium type	92	ENUM16	2	Static	х	OOS	→ 🖺 183

9.6.2 Advanced Setup Transducer Block

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BLK	Description
calculated_dc_value	Calculated DC value	61	FLOAT	4	Dynamic			→ 🖺 191
blocking_distance	Blocking distance	55	FLOAT	4	Static	х	OOS	→ 🖺 186
dc_value_lower_medium	DC value lower medium	58	FLOAT	4	Static	х	OOS	→ 🖺 188
medium_type	Medium type	50	ENUM16	2	Static	х	OOS	→ 🖺 183
present_probe_length_ro	Present probe length	80	FLOAT	4	Dynamic	х	AUTO	→ 🖺 208
confirm_probe_length	Confirm probe length	79	ENUM16	2	Static	х	OOS	→ 🖺 209
process_property	Process property	52	ENUM16	2	Static	х	OOS	→ 🖺 184
advanced_process_conditio	Advanced process conditions	53	ENUM16	2	Static	х	OOS	→ 🖺 185
meas_upper_iface_thickne	Measured thickness upper layer	60	FLOAT	4	Dynamic			→ 🖺 191
manual_interface_thicknes	Manual thickness upper layer	59	FLOAT	4	Static	х	OOS	→ 🖺 190
medium_property	Medium property	51	ENUM16	2	Static	х	OOS	→ 🖺 183
use_calculated_dc_value	Use calculated DC value	62	ENUM16	2	Static	х	OOS	→ 🖺 192
linearization_type	Linearization type	71	ENUM16	2	Static	х	OOS	→ 🖺 197
activate_table	Activate table	70	ENUM16	2	Static	х	OOS	→ 🖺 203
table_mode	Table mode	69	ENUM16	2	Static	х	OOS	→ 🖺 201
custom_table_sel_level	Level	73	FLOAT	4	Static	х	OOS	→ 🖺 169
custom_table_sel_value	Customer value	74	FLOAT	4	Static	х	OOS	→ 🖺 203
unit_after_linearization	Unit after linearization	63	ENUM16	2	Static	х	OOS	→ 🖺 198
free_text	Free text	64	STRING		Static	х	AUTO	→ 🖺 199
diameter	Diameter	66	FLOAT	4	Static	х	OOS	→ 🖺 200
output_echo_lost	Output echo lost	76	ENUM16	2	Static	х	OOS	→ 🖺 205
intermediate_height	Intermediate height	67	FLOAT	4	Static	х	AUTO	→ 🖺 201
level_correction	Level correction	56	FLOAT	4	Static	х	OOS	→ 🖺 187
level_unit_ro	Level unit	54	ENUM16	2	Static	х	OOS	→ 🖺 186

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BLK	Description
assign_limit	Assign limit	82	ENUM16	2	Static	х	AUTO	→ 🖺 212
maximum_value	Maximum value	65	FLOAT	4	Static	х	OOS	→ 🖺 200
assign_diag_behavior	Assign diagnostic behavior	83	ENUM16	2	Static	х	AUTO	→ 🖺 212
value_echo_lost	Value echo lost	77	FLOAT	4	Static	х	OOS	→ 🖺 205
ramp_at_echo_lost	Ramp at echo lost	78	FLOAT	4	Static	х	OOS	→ 🖺 206
switch_output_failure_mod e	Failure mode	88	ENUM16	2	Static	х	AUTO	→ 🖺 215
switch_output_function	Switch output function	81	ENUM16	2	Static	х	AUTO	→ 🖺 211
switch_status	Switch status	89	ENUM16	2	Dynamic			→ 🖺 215
switch_off_delay	Switch-off delay	87	FLOAT	4	Static	х	AUTO	→ 🖺 215
switch_off_value	Switch-off value	86	FLOAT	4	Static	x	AUTO	→ 🖺 214
switch_on_delay	Switch-on delay	85	FLOAT	4	Static	х	AUTO	→ 🖺 214
switch_on_value	Switch-on value	84	FLOAT	4	Static	х	AUTO	→ 🖺 213
operating_mode_ro	Operating mode	95	ENUM16	2	Static	х	OOS	→ 🖺 165
table_number	Table number	68	UINT8	1	Static	х	OOS	→ 🖺 202
level_semiautomatic	Level	75	FLOAT	4	Dynamic			→ 🖺 203
assign_status	Assign status	91	ENUM16	2	Static	х	AUTO	→ 🖺 211
locking_status	Locking status	99	BIT_ENUM16	2	Dynamic			→ 🖺 181
decimal_places_menu	Decimal places menu	93	ENUM16	2	Static	х	AUTO	→ 🖺 222
distance_unit_ro	Distance unit	92	ENUM16	2	Static	х	OOS	→ 🖺 165

9.6.3 Display Transducer Block

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BLK	Description
access_status_display	Access status display	51	ENUM16	2	Static			→ 🖺 181
display_damping	Display damping	65	FLOAT	4	Static	х	AUTO	→ 🖺 220
display_interval	Display interval	64	FLOAT	4	Static	х	AUTO	→ 🖺 220
header	Header	66	ENUM16	2	Static	х	AUTO	→ 🖺 220
format_display	Format display	55	ENUM16	2	Static	х	AUTO	→ 🖺 217
number_format	Number format	69	ENUM16	2	Static	х	AUTO	→ 🖺 221
display_separator	Separator	68	ENUM16	2	Static	х	AUTO	→ 🖺 221
language	Language	54	ENUM16	2	Static	х	AUTO	→ 🖺 217
contrast_display	Contrast display	71	FLOAT	4	Static	х	AUTO	→ 🖺 223
header_text	Header text	67	STRING		Static	х	AUTO	→ 🖺 221
access_code_for_display	Enter access code	52	UINT16	2	Static	х	AUTO	→ 🖺 182
configuration_management	Configuration management	75	ENUM16	2	Static	х	AUTO	→ 🖺 224
decimal_places_1	Decimal places 1	57	ENUM16	2	Static	х	AUTO	→ 🖺 219
decimal_places_2	Decimal places 2	59	ENUM16	2	Static	х	AUTO	→ 🖺 219
decimal_places_3	Decimal places 3	61	ENUM16	2	Static	х	AUTO	→ 🖺 219
decimal_places_4	Decimal places 4	63	ENUM16	2	Static	х	AUTO	→ 🖺 219
last_backup	Last backup	74	STRING		Static	х	AUTO	→ 🖺 224
value_1_display	Value 1 display	56	ENUM16	2	Static	х	AUTO	→ 🖺 219

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BLK	Description
value_2_display	Value 2 display	58	ENUM16	2	Static	х	AUTO	→ 🖺 219
value_3_display	Value 3 display	60	ENUM16	2	Static	х	AUTO	→ 🖺 219
value_4_display	Value 4 display	62	ENUM16	2	Static	х	AUTO	→ 🖺 219
locking_status_display	Locking status	50	ENUM16	2	Static			→ 🖺 181
define_access_code	Define access code	53	UINT16	2	Static	х	AUTO	→ 🖺 227
comparison_result	Comparison result	76	ENUM16	2	Static	х	AUTO	→ 🖺 225
decimal_places_menu	Decimal places menu	70	ENUM16	2	Static	х	AUTO	→ 🖺 222
operating_time	Operating time	73	STRING		Dynamic			→ 🖺 224
operating_mode_ro	Operating mode	83	ENUM16	2	Static	х	OOS	→ 🖺 165
locking_status	Locking status	85	BIT_ENUM16	2	Dynamic			→ 🖺 181

9.6.4 Diagnostic Transducer Block

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BLK	Description
operating_time	Operating time	55	STRING		Dynamic			→ 🖺 224
diagnostics_1	Diagnostics	56	UINT32	4	Static			→ 🖺 232
diagnostics_2	Diagnostics 2	58	UINT32	4	Static			→ 🖺 232
diagnostics_3	Diagnostics 3	60	UINT32	4	Static			→ 🖺 232
diagnostics_4	Diagnostics 4	62	UINT32	4	Static			→ 🖺 232
diagnostics_5	Diagnostics 5	64	UINT32	4	Static			→ 🖺 232
operating_time_from_resta rt	Operating time from restart	54	STRING		Dynamic			→ 🖺 231
launch_signal	Launch signal	81	ENUM16	2	Dynamic			→ 🖺 250
start_device_check	Start device check	77	ENUM16	2	Static	х	AUTO	→ 🖺 249
interface_signal	Interface signal	82	ENUM16	2	Dynamic			→ 🖺 250
level_signal	Level signal	80	ENUM16	2	Dynamic			→ 🖺 250
simulation_device_alarm	Simulation device alarm	75	ENUM16	2	Static	х	OOS	→ 🖺 248
filter_options	Filter options	66	ENUM8	1	Static	х	AUTO	→ 🖺 233
previous_diagnostics	Previous diagnostics	52	UINT32	4	Static			→ 🖺 230
actual_diagnostics	Actual diagnostics	50	UINT32	4	Static			→ 🖺 230
assign_sim_meas	Assign measurement variable	71	ENUM16	2	Static	х	OOS	→ 🖺 247
sim_value_process_variabl	Process variable value	72	FLOAT	4	Static	х	OOS	→ 🖺 247
switch_output_simulation	Switch output simulation	73	ENUM16	2	Static	х	OOS	→ 🖺 247
sim_switch_status	Switch status	74	ENUM16	2	Static	х	OOS	→ 🖺 248
result_device_check	Result device check	78	ENUM16	2	Dynamic			→ 🖺 249
last_check_time	Last check time	79	STRING		Dynamic			→ 🖺 249
linearization_type	Linearization type	84	ENUM16	2	Static	х	OOS	→ 🖺 197
unit_after_linearization_ro	Unit after linearization	85	STRING		Static	х	AUTO	→ 🖺 198
decimal_places_menu	Decimal places menu	88	ENUM16	2	Static	х	AUTO	→ 🖺 222
level_unit_ro	Level unit	90	ENUM16	2	Static	х	OOS	→ 🖺 186
operating_mode_ro	Operating mode	91	ENUM16	2	Static	х	OOS	→ 🖺 165

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BLK	Description
assign_channel_1	Assign channel 1	92	ENUM16	2	Static	х	AUTO	→ 🖺 241
assign_channel_2	Assign channel 2	93	ENUM16	2	Static	х	AUTO	→ 🖺 241
assign_channel_3	Assign channel 3	94	ENUM16	2	Static	х	AUTO	→ 🖺 241
assign_channel_4	Assign channel 4	95	ENUM16	2	Static	х	AUTO	→ 🖺 241
clear_logging_data	Clear logging data	97	ENUM16	2	Static	х	AUTO	→ 🖺 242
logging_interval	Logging interval	96	FLOAT	4	Static	х	AUTO	→ 🖺 242
display_filter_options	Filter options	99	ENUM8	1	Static	х	AUTO	→ 🖺 233
locking_status	Locking status	108	BIT_ENUM16	2	Dynamic			→ 🖺 181
distance_unit_ro	Distance unit	89	ENUM16	2	Static	х	oos	→ 🖺 165

Expert Configuration Transducer Block 9.6.5



The parameters of the **Expert Configuration Transducer Block** are described in GP01015F: "Levelflex FMP5x - Description of Device Parameters - FOUNDATION Fieldbus"

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BLK
acknowledge_alarm	Acknowledge alarm	81	ENUM16	2	Static	х	AUTO
integration_time	Integration time	67	FLOAT	4	Static	х	OOS
result_self_check	Result self check	77	ENUM16	2	Dynamic		
start_self_check	Start self check	76	ENUM16	2	Static	х	AUTO
broken_probe_detection	Broken probe detection	75	ENUM16	2	Static	х	AUTO
gpc_mode	GPC mode	68	ENUM16	2	Static	х	OOS
reference_echo_threshold	Reference echo threshold	73	FLOAT	4	Static	х	OOS
const_gpc_factor	Const. GPC factor	74	FLOAT	4	Static	х	OOS
build_up_ratio	Build-up ratio	90	FLOAT	4	Dynamic		
build_up_threshold	Build-up thres.	91	FLOAT	4	Static	х	AUTO
delay_time_echo_lost	Delay time echo lost	78	FLOAT	4	Static	х	AUTO
empty_capacity	Empty capacity	92	FLOAT	4	Static	х	AUTO
external_pressure_selector	External pressure selector	69	ENUM16	2	Static	х	OOS
measured_capacity	Measured capacitance	89	FLOAT	4	Dynamic		
gas_phase_compens_factor	Gas phase compensation factor	70	FLOT	4	Static	х	OOS
in_safety_distance	In safety distance	80	ENUM16	2	Static	х	OOS
ratio_amplitude_interface_level	Ratio amplitude interface/level	86	FLOAT	4	Static	х	OOS
interface_criterion	Interface criterion	87	FLOAT	4	Dynamic		
control_measurement	Measurement	106	ENUM16	2	Static	х	AUTO
control_measurement	Control measurement	105	ENUM16	2	Static	х	AUTO
filter_dead_time	Dead time	66	FLOAT	4	Static	х	OOS
present_reference_distance	Present reference distance	72	FLOAT	4	Dynamic		
history_reset	History reset	83	ENUM16	2	Static	х	OOS
safety_distance	Safety distance	79	FLOAT	4	Static	х	OOS
history_learning_control	History learning	85	ENUM16	2	Static	х	AUTO
history_learning_control	History learning control	84	ENUM16	2	Static	х	AUTO
sensor_module	Sensor module	107	ENUM16	2	Static		

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BLK
evaluation_mode	Evaluation mode	82	ENUM16	2	Static	х	oos
thin_interface	Thin interface	88	ENUM16	2	Static	х	OOS
calculated_dc_value	Calculated DC value	59	FLOAT	4	Dynamic	х	AUTO
dc_value_expert	DC value	55	FLOAT	4	Static	х	OOS
distance_offset	Distance offset	60	FLOAT	4	Static	х	oos
level_limit_mode	Level limit mode	62	ENUM16	2	Static	х	oos
level_high_limit	High limit	63	FLOAT	4	Static	х	00S
level_low_limit	Low limit	64	FLOAT	4	Static	х	OOS
output_mode	Output mode	65	ENUM16	2	Static	х	00S
level_external_input_1	Level external input 1	93	ENUM16	2	Static	х	AUTO
level_external_input_2	Level external input 2	96	ENUM16	2	Static	х	AUTO
function_input_1_level	Function Input 1 Level	94	ENUM16	2	Static	х	AUTO
function_input_2_level	Function Input 2 Level	97	ENUM16	2	Static	х	AUTO
fixed_value_inp_1	Fixed value inp.1	95	FLOAT	4	Static	х	AUTO
fixed_value_inp_2	Fixed value inp.2	98	FLOAT	4	Static	х	AUTO
interface_external_input_1	Interface external input 1	99	ENUM16	2	Static	х	OOS
interface_external_input_2	Interface external input 2	102	ENUM16	2	Static	х	OOS
function_input_1_interface	Function input 1 interface	100	ENUM16	2	Static	х	OOS
function_input_2_interface	Function input 2 interface	103	ENUM16	2	Static	х	OOS
fixed_value_input_1_interface	Fixed value input 1 interface	101	FLOAT	4	Static	х	OOS
fixed_value_input_2_interface	Fixed value input 2 interface	104	FLOAT	4	Static	х	OOS
distance_unit_ro	Distance unit	53	ENUM16	2	Static	х	OOS
level_unit_ro	Level unit	61	ENUM16	2	Static	х	OOS
operating_mode_ro	Operating mode	54	ENUM16	2	Static	х	OOS
enter_access_code	Enter access code	52	UINT16	2	Static	х	AUTO
locking_status	Locking status	50	BIT_ENUM16	2	Dynamic		
access_status_tooling	Access status tooling	51	ENUM16	2	Static		
reference_distance	Reference distance	71	FLOAT	4	Static	х	00S
sw_option_active_overview	SW option active overview	110	BIT_ENUM32	4	Static		
decimal_places_menu	Decimal places menu	109	ENUM16	2	Static	х	AUTO
fieldbus_type	Fieldbus Type	111	ENUM8	1	Static		
interface_property_ro	Interface property	108	ENUM16	2	Static	х	oos
medium_type_ro	Medium type	112	ENUM16	2	Static	х	oos
eop_level_evaluation_ro	EOP level evaluation	113	ENUM16	2	Static	х	00S
sensor_type_ro	Sensor type	114	ENUM16	2	Static	х	OOS
calculated_dc_status_en	Status	58	ENUM8	1	Dynamic		

9.6.6 Expert Information Transducer Block

The parameters of the **Expert Information Transducer Block** are described in GP01015F: "Levelflex FMP5x - Description of Device Parameters - FOUNDATION Fieldbus"

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BLK
abs_echo_amp_val	Absolute echo amplitude	51	FLOAT	4	Dynamic		
abs_eop_amp_val	Absolute EOP amplitude	55	FLOAT	4	Dynamic		
absolute_interface_amplitude	Absolute interface amplitude	58	FLOAT	4	Dynamic		
application_parameter	Application parameter	74	ENUM16	2	Dynamic		
electronic_temp_value	Electronic temperature	66	FLOAT	4	Dynamic		
eop_shift_value	EOP shift	69	FLOAT	4	Dynamic		
found_echoes	Found echoes	71	ENUM16	2	Dynamic		
max_electr_temp	Max. electronics temperature	73	FLOAT	4	Dynamic	х	AUTO
time_max_electr_temp	Time max. electronics temperature	75	STRING		Dynamic		
measurement_frequency	Measurement frequency	76	FLOAT	4	Dynamic		
min_electr_temp	Min. electronics temperature	77	FLOAT	4	Dynamic	х	AUTO
time_min_electr_temp	Time min. electronics temperature	78	STRING		Dynamic		
rel_echo_amp_val	Relative echo amplitude	53	FLOAT	4	Dynamic		
relative_interface_amplitude	Relative interface amplitude	60	FLOAT	4	Dynamic		
reset_min_max_temp	Reset min./max. temp.	79	ENUM16	2	Static	х	AUTO
noise_signal_val	Noise of signal	63	FLOAT	4	Dynamic		
used_calculation	Used calculation	80	ENUM16	2	Dynamic		
tank_trace_state	Tank trace state	81	ENUM16	2	Dynamic		
max_draining_speed	Max. draining speed	82	FLOAT	4	Dynamic	х	AUTO
max_filling_speed	L max. fill speed	83	FLOAT	4	Dynamic	х	AUTO
time_max_level	Time max. level	84	STRING		Dynamic		
max_level_value	Max. level value	85	FLOAT	4	Dynamic	х	AUTO
time_min_level	Time min. level	86	STRING		Dynamic		
min_level_value	Min. level value	87	FLOAT	4	Dynamic	х	AUTO
reset_min_max	Reset min./max.	94	ENUM16	2	Static	х	AUTO
interf_max_drain_speed	I max. drain speed	88	FLOAT	4	Dynamic	х	AUTO
interf_max_fill_speed	I max. fill speed	89	FLOAT	4	Dynamic	х	AUTO
time_max_interface	Time max. interface	90	STRING		Dynamic		
max_interface_value	Max. interface value	91	FLOAT	4	Dynamic	х	AUTO
time_min_interface	Time min. interface	92	STRING		Dynamic		
min_interface_value	Min. interface value	93	FLOAT	4	Dynamic	х	AUTO
application_parameter	Application parameter	95	ENUM16	2	Dynamic		
operating_mode_ro	Operating mode	108	ENUM16	2	Static	х	OOS
temperature_unit	Temperature unit	72	ENUM16	2	Static	х	AUTO
activate_sw_option	Activate SW option	110	UINT32	4	Static	х	AUTO
target_echo_status	Status	56	ENUM8	1	Dynamic		
iface_target_echo_status	Status	61	ENUM8	1	Dynamic		
signal_noise_status	Status	64	ENUM8	1	Dynamic		
sens_temp_status	Status	67	ENUM8	1	Dynamic		
eop_shift_status	Status	70	ENUM8	1	Dynamic		
terminal_voltage_1	Terminal voltage 1	97	FLOAT	4	Dynamic		
calculated_dc_value	Calculated DC value	100	FLOAT	4	Dynamic	х	AUTO

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BLK
upper_interface_thickness	Upper interface thickness	103	FLOAT	4	Dynamic		
debug_value	Debug value	106	FLOAT	4	Dynamic	х	AUTO
sw_option_active_overview	SW option active overview	111	BIT_ENUM32	4	Static		
locking_status	Locking status	113	BIT_ENUM16	2	Dynamic		
decimal_places_menu_ro	Decimal places menu	109	ENUM16	2	Static	х	AUTO
linearization_type	Linearization type	104	ENUM16	2	Static	х	oos
eop_level_evaluation	EOP level evaluation	112	ENUM16	2	Static	х	OOS
access_status_tooling	Access status tooling	114	ENUM16	2	Static		
calculated_dc_status	Status	99	UINT8	1	Dynamic		
status_up_iface_thickness	Customized upper phase thickness status	102	UINT8	1	Dynamic		
debug_status		107	UINT8	1	Dynamic	х	AUTO

9.6.7 Service Sensor Transducer Block

The parameters of the **Service Sensor** Transducer Block can only be operated by authorized Endress+Hauser service personnel.

9.6.8 Service Information Transducer Block

The parameters of the **Service Information** Transducer Block can only be operated by authorized Endress+Hauser service personnel.

9.6.9 Data Transfer Transducer Block

The parameters of the **Data Transfer Transducer Block** are described in GP01015F: "Levelflex FMP5x - Description of Device Parameters - FOUNDATION Fieldbus"

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BLK
used_calculation	Used calculation	87	ENUM16	2	Dynamic		
bdt_cfg_rdwr_ctrl		101	UINT16	2	Static	х	AUTO
bdt_transferred_ctrl		102	BYTEARRAY		Static	х	AUTO
bdt_data_trans		103	BYTEARRAY		Static	х	AUTO
bdt_prepare		99	BYTEARRAY		Static	х	AUTO
bdt_status		100	BYTEARRAY		Static		
sw_option_active_overview	SW option active overview	98	BIT_ENUM32	4	Static		
digits_at_0_mVdB		90	FLOAT	4	Dynamic	х	AUTO
digits_per_mVdB		91	FLOAT	4	Dynamic	х	AUTO
actual_diagnostics	Actual diagnostics	97	UINT32	4	Static		
electric_probe_length	Electric probe length	92	FLOAT	4	Dynamic		
empty_calibration_ro	Empty calibration	93	FLOAT	4	Static	х	OOS
full_calibration_ro	Full calibration	94	FLOAT	4	Static	х	OOS
distance_unit_ro	Distance unit	95	ENUM16	2	Static	х	OOS
operating_mode_ro	Operating mode	88	ENUM16	2	Static	х	OOS
present_probe_length_ro	Present probe length	89	FLOAT	4	Dynamic	х	AUTO
trend_operation_hours		104	UINT32	4	Static		

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BLK
trend_package_size		105	UINT8	1	Static	х	AUTO
trend_storage_time	Trend storage time	106	UINT32	4	Static		
trend_sup_pack_size		107	UINT8	1	Static		
gpc_mode_ro	GPC mode	109	ENUM16	2	Static	х	OOS
eop_level_evaluation_ro	EOP level evaluation	110	ENUM16	2	Static	х	OOS
temperature_unit_ro	Temperature unit	111	ENUM16	2	Static	х	OOS
max_trend_entries		108	UINT16	2	Static		
line_mapping_point_number	Line mapping point number	126	UINT16	2	Static	х	AUTO
line_mapping_array_x	Line mapping array X	127	FLOAT	4	Static	х	AUTO
line_mapping_array_y	Line mapping array Y	128	FLOAT	4	Static	х	AUTO
mapping_end_point_ro	Mapping end point	125	FLOAT	4	Static	х	AUTO
mapping_start_point	Mapping start point	124	FLOAT	4	Static	х	AUTO
function_block_table		143	UINT32	4	Static		
custom_empty_value		112	FLOAT	4	Static		
custom_full_value		113	FLOAT	4	Static		
customized	Customized	121	UINT8	1	Static		
reset_ordered_configuration	Reset ordered configuration	122	ENUM16	2	Static	х	AUTO
empty_scale		114	FLOAT	4	Static	х	AUTO
eop_map_point_number		116	UINT16	2	Static	х	AUTO
factory_data_valid		123	UINT8	1	Static		
fieldbus_type	Fieldbus Type	144	ENUM8	1	Static		
full_scale		115	FLOAT	4	Static	х	AUTO
init_map_point_number		117	UINT16	2	Static	х	AUTO
max_not_assoc_track		118	UINT16	2	Static	х	AUTO
ref_max_dist	Ref max. dist.	119	FLOAT	4	Static	х	AUTO
ref_min_dist	Ref min. dist.	120	FLOAT	4	Static	х	AUTO
line_mapping_accuracy	Line mapping accuracy	130	FLOAT	4	Static	х	AUTO
mapping_curve_left_margin	Mapping curve left margin	131	FLOAT	4	Static	х	AUTO
device_calib_changed		133	ENUM16	2	Static	х	AUTO
echo_thresh_attenuat_const_ee	Threshold attenuation constant	134	FLOAT	4	Dynamic	х	AUTO
echo_threshold_far_ee		135	FLOAT	4	Static	х	AUTO
echo_thresh_inactive_len		137	FLOAT	4	Static	х	AUTO
echo_threshold_near_ee		136	FLOAT	4	Static	х	AUTO
present_probe_length_ee		138	FLOAT	4	Static	х	AUTO
reset_appl_para_chg_flags		139	ENUM16	2	Static	х	AUTO
reset_dyn_persistent		140	ENUM16	2	Static	х	AUTO
locking_status	Locking status	142	BIT_ENUM16	2	Dynamic		
decimal_places_menu	Decimal places menu	96	ENUM16	2	Static	х	AUTO
access_status_tooling	Access status tooling	141	ENUM16	2	Static		
level_linearized	Level linearized	147	FLOAT	4	Dynamic		
bdt_transferred_ctrl		197	UINT8	1	Static	х	AUTO
bdt_cfg_rdwr_ctrl		196	UINT16	2	Static	х	AUTO

9.7 Methods

The FOUNDATION Fieldbus Specification includes the use of methods to make device operation easier. A method is a sequence of interactive steps to be carried out in the specified order so as to configure certain device functions.

The following methods are available for the device:

Restart

This method is located in the Resource Block and directly prompts the setting of the **Device reset** parameter. This resets the device configuration to a defined state.

■ ENP Restart

This method is located in the Resource Block and directly prompts the setting of the parameters of the Electronic Name Plate (ENP).

Setup

This method is located in the SETUP Transducer Block and allows to set the most important parameters in this block for device configuration (measuring units, type of tank or vessel, type of medium, empty and full calibration).

Linearization

This method is located in the ADV_SETUP Transducer Block and allows to manage the linearization table by which the measured value is converted into volume, mass or flow.


Self Check

This method is located in the EXPERT_CONFIG Transducer Block and prompts the device self check parameters.

10 Commissioning via wizard

A wizard guiding the user through the initial setup is available in FieldCare and DeviceCare $^{3)}$.

- 1. Connect the device to FieldCare or DeviceCare $\rightarrow \triangleq 69$.
- 2. Open the device in FieldCare or DeviceCare.
 - ► The dashboard (home page) of the device appears:



- "Commissioning" button calls up the wizard.
- 3. Click on "Commissioning" to call up the wizard.
- 4. Enter or select the appropriate value for each parameter. These values are immediately written to the device.
- 5. Click "Next" to switch to the next page.
- 6. After finishing the last page, click "End of sequence" to close the wizard.
- If the wizard is cancelled before all necessary parameters have been set, the device may be in an undefined state. A reset to the default settings is recommended in this case.

³⁾ DeviceCare is available for download at www.software-products.endress.com. The download requires a registration in the Endress+Hauser software portal.

11 Commissioning via operating menu


11.1 Installation and function check

Make sure that all final checks have been completed before you start up your measuring point:

- Checklist "Post-installation check" → 🖺 58
- Checklist "Post-connection check" → 🖺 66

11.2 Setting the operating language

Factory setting: English or ordered local language



■ 26 Using the example of the local display

11.3 Checking the reference distance

This section is only valid for FMP54 with gas phase compensation (product structure: feature 540 "Application Package", option EF or EG).

Coax probes with gas phase compensation are calibrated on delivery. Rod probes, on the other hand, must be recalibrated after mounting: $\frac{1}{2} \left(\frac{1}{2} \right) = \frac{1}{2} \left(\frac{1}{2} \right) \left(\frac{1}{2} \right)$

After mounting the rod probe in the stilling well or bypass, check and - if necessary - correct the setting of the reference distance in the unpressurized state. Whilst doing so the


level should be at least 200 mm below the reference distance L_{ref} to achieve maximum accuracy.

Step	Parameter	Action
1	Expert → Sensor → Gas phase compensation → GPC mode	Select the On option, in order to activate gas phase compensation.
2	Expert → Sensor → Gas phase compensation → Present reference distance	Check whether the displayed reference distance matches the nominal value (300 mm or 550 mm, respectively; see the nameplate). If yes: nor further actions required. If no: continue with step 3.
3	Expert → Sensor → Gas phase compensation → Reference distance	Enter the value displayed in Present reference distance parameter.

For a detailed description of all parameters concerning the gas phase compensation see:

GP01015F, "Levelflex - Description of device parameters - FOUNDATION Fieldbus"

11.4 Configuration of a level measurement



 \blacksquare 27 Configuration parameters for level measurements in liquids

LN Length of probe

- *R* Reference point of the measurement
- D Distance
- L Level
- E Empty calibration (= Zero point)
- F Full calibration (= Span)
- If for rope probes the DC value is less than 7, then measurement is not possible in the area of the straining weight. In these cases, the maximum recommended value for the empty calibration E is LN 250 mm (LN 10 in).
- 1. Setup → Device tag
 - ► Enter tag for measuring point.
- 2. For devices with "interface measurement" application package:

Navigate to:Setup \rightarrow Operating mode

- ► Select **Level** option.
- 3. Navigate to: Setup → Distance unit
 - Select distance unit.
- 4. Navigate to: Setup → Tank type
 - ► Select tank type.
- 5. For Tank type = Bypass / pipe:

Navigate to: Setup \rightarrow Tube diameter

- Enter the diameter of the bypass or stilling well.
- 6. Navigate to: Setup → Medium group
 - ► Select medium group: (Water based (DC >= 4) or Others)
- 7. Navigate to: Setup → Empty calibration
 - ► Enter the distance E between the reference point R and the minimum level (0%).
- 8. Navigate to: Setup → Full calibration
 - ► Enter distance F between the minimum (0%) and maximum (100%) level.
- 9. Navigate to: Setup → Level
 - □ Displays the measured level L.

102

- 10. Navigate to: Setup \rightarrow Distance
 - └ Displays the distance D between the reference point R and the level L.
- 11. Navigate to: Setup → Signal quality
 - ► Displays the signal quality of the level echo.
- 12. For operation via local display:

Navigate to: Setup → Mapping → Confirm distance

- Compare the displayed distance to the real distance in order to start the recording of the mapping curve if required ⁴⁾.
- 13. For operation via operating tool:


Navigate to: Setup → Confirm distance

Compare the displayed distance to the real distance in order to start the recording of the mapping curve if required ⁴⁾.

⁴⁾ For FMP54 with gas phase compensation (product structure: feature 540 "Application Package", option EF or EG) a map must NOT be recorded.

11.5 Configuration of an interface measurement

Only devices with the respective software option can be used for interface measurements. This option is selected in the product structure: Feature 540 "Application package", option EB "Interface measurement".



■ 28 Configuration parameters for interface measurements

LN Length of probe

R Reference pioint of the measurement

DI "Interface distance" parameter (Distance from reference point to lower medium)

LI Interface

DL Distance

LL Level

UP Thickness upper layer

E "Empty calibration" parameter (= zero point)

F "Full calibration" parameter (= span)

1. Navigate to: Setup → Device tag

► Enter tag for measuring point.

2. Navigate to: Setup → Operating mode

► Select **Interface** option.

3. Navigate to: Setup → Distance unit

→ Select distance unit.

4. Navigate to: Setup → Tank type

► Select tank type.

5. For Tank type = Bypass / pipe:

Navigate to: Setup → Tube diameter

► Enter the diameter of the bypass or stilling well.

6. Navigate to: Setup → Tank level

Select tank level (**Fully flooded** or **Partially filled**)

7. Navigate to: Setup → Distance to upper connection

In bypasses: Enter distance from reference point R to lower edge of the upper connection; otherwise: Keep the factory setting

8. Navigate to: Setup → DC value

 \vdash Enter relative dielectric constant (ε_r) of the upper medium.

- 9. Navigate to: Setup → Empty calibration
 - ► Enter the distance E between the reference point R and the minimum level (0%).
- 10. Navigate to: Setup \rightarrow Full calibration
 - └ Enter distance F between the minimum (0%) and maximum (100%) level.
- 11. Navigate to: Setup \rightarrow Level
 - ightharpoonup Displays the measured level L_L.
- 12. Navigate to: Setup → Interface
 - ightharpoonup Displays the interface height L_I.
- 13. Navigate to: Setup → Distance
 - ightharpoonup Displays the distance D_L between the reference point R and the level L_L .
- 14. Navigate to: Setup → Interface distance
 - ► Displays the distance D_I between the reference point R and the interface L_I.
- 15. Navigate to: Setup \rightarrow Signal quality
 - ► Displays the signal quality of the level echo.
- 16. For operation via local display:

Navigate to: Setup \rightarrow Mapping \rightarrow Confirm distance

- Compare the displayed distance to the real distance in order to start the recording of the mapping curve if required ⁵⁾.
- 17. For operation via operating tool (e.g. FieldCare):

Navigate to: Setup → Confirm distance

Angezeigte Distanz mit tatsächlichem Wert vergleichen, um gegebenenfalls die Aufnahme einer Störechoausblendungskurve zu starten ⁵⁾.

⁵⁾ For FMP54 with gas phase compensation (product structure: feature 540 "Application Package", option EF or EG) a map must NOT be recorded.

11.6 Recording the reference curve

After the configuration of the measurement it is recommended to record the current envelope curve as a reference curve. The reference curve can be used later on in the process for diagnostic purposes. To record the reference curve use the **Save reference curve** parameter.

Navigation in the menu

Expert → Diagnostics → Envelope diagnostics → Save reference curve

Meaning of the options

■ No

No action

Yes

The current envelope curve is saved as reference curve.

- In devices which have been delivered with software version 01.00.zz, this submenu is only visible for the "Service" user role.
- The reference curve can only be displayed in the envelope curve diagram of FieldCare after it has been loaded from the device into FieldCare. This is performed by the "Load Reference Curve" function in FieldCare:



■ 29 The "Load Reference Curve" function

11.7 Configuration of the on-site display

11.7.1 Factory settings of the on-site display for level measurements

Parameter	Factory setting for devices with 1 current output	Factory setting for devices with 2 current outputs
Format display	1 value, max. size	1 value, max. size
Value 1 display	Level linearized	Level linearized
Value 2 display	Distance	Distance
Value 3 display	Current output 1	Current output 1
Value 4 display	None	Current output 2

11.7.2 Factory settings of the on-site display for interface measurements

Parameter	Factory setting for devices with 1 current output	Factory setting for devices with 2 current outputs
Format display	1 value, max. size	1 value, max. size
Value 1 display	Interface linearized	Interface linearized
Value 2 display	Level linearized	Level linearized
Value 3 display	Thickness upper layer	Current output 1
Value 4 display	Current output 1	Current output 2

11.7.3 Adjustment of the on-site display

The on-site display can be adjusted in the following menu: Setup \rightarrow Advanced setup \rightarrow Display

11.8 Configuration management

After commissioning, you can save the current device configuration, copy it to another measuring point or restore the previous device configuration. You can do so using the **Configuration management** parameter and its options.

Navigation path in the operating menu

Setup → Advanced setup → Configuration backup display → Configuration management

Meaning of the options

Cancel

No action is executed and the user exits the parameter.

Execute backup

A backup copy of the current device configuration in the HistoROM (built-in in the device) is saved to the display module of the device. The backup copy comprises the transmitter and sensor data of the device.

Restore

The last backup copy of the device configuration is copied from the display module to the HistoROM of the device. The backup copy comprises the transmitter and sensor data of the device.

Duplicate

The transmitter configuration is duplicated to another device using the transmitter display module. The following parameters, which characterize the individual measuring point are **not** included in the transmitted configuration:

Medium type

Compare

The device configuration saved in the display module is compared to the current device configuration of the HistoROM. The result of this comparison is displayed in the **Comparison result** parameter.

Clear backup data

The backup copy of the device configuration is deleted from the display module of the device.

- While this action is in progress, the configuration cannot be edited via the local display and a message on the processing status appears on the display.
- If an existing backup is restored to a different device using the **Restore** option, it may occur that some device functionalities are no longer available. In some cases even a device reset → 227 will not restore the original status..

In order to transmit a configuration to a different device, the **Duplicate** option should always be used.

108

11.9 Protection of the settings against unauthorized changes

There are two ways to protect the settings against unauthorized changes:

12 Commissioning (block-based operation)

12.1 Function check

Carry out a post-installation and a post-connection check as per the checklist before commissioning the device:

- "Post-installation check" checklist → 🖺 58
- "Post-connection check" checklist → 🖺 66

12.2 Block configuration

12.2.1 Preparatory steps

- 1. Switch on the device.
- 2. Note the DEVICE ID.
- 3. Open the configuration program.
- 4. Load Cff and device description files into the host system or the configuration program. Make sure you are using the right system files.
- 5. Identify the device using the **DEVICE_ID** (see Point 2). Assign the desired tag name to the device by means of the **Pd-tag/FF_PD_TAG** parameter.

12.2.2 Configuring the Resource Block

- 1. Open the Resource Block.
- 2. If necessary, disable the lock for device operation.
- 3. If necessary, change the block name. Factory setting: RS-xxxxxxxxxx (RB2)
- 4. If necessary, assign a description to the block by means of the **Tag Description/ TAG_DESC** parameter.
- 5. If necessary, change other parameters as per the requirements.

12.2.3 Configuring the Transducer Blocks

The measurement and the display module are configured using the Transducer Blocks. The general procedure is the same for all Transducer Blocks:

- 1. If necessary, change the block name.
- 2. Set the block mode to OOS by means of the **Block Mode/MODE_BLK** parameter, **TARGET** element.
- 3. Configure the device in accordance with the measuring task.
- 4. Set the block mode to **Auto** by means of the **Block Mode/MODE_BLK** parameter, **TARGET** element.
- The block mode must be set to **Auto** for the measuring device to function correctly.

12.2.4 Configuring the Analog Input Blocks

The device has 2 Analog Input Blocks that can be assigned as required to the various process variables.

Default settings		
Analog Input Block	CHANNEL	
AI 1	32949: Level linearized	
AI 2	32856: Distance	


- 1. If necessary, change the block name.
- Set the block mode to OOS by means of the Block Mode/MODE_BLK parameter, TARGET element.
- 4. Use the **Transducer Scale/XD_SCALE** parameter to select the desired unit and the block input range for the process variable → 🗎 111. Make sure that the unit selected suits the process variable selected. If the process variable does not suit the unit, the **Block Error/BLOCK_ERR** parameter reports **Block Configuration Error** and the block mode cannot be set to **Auto**.
- 5. Use the Linearization Type/L_TYPE parameter to select the type of linearization for the input variable (factory setting: Direct). Make sure that the settings for the Transducer Scale/XD_SCALE and Output Scale/ OUT_SCALE parameters are the same for the Direct linearization type. If the values and units do not match, the Block Error/BLOCK_ERR parameter reports Block Configuration Error and the block mode cannot be set to Auto.
- 6. Enter the alarm and critical alarm messages by means of the High High Limit/ HI_HI_LIM, High Limit/HI_LIM, Low Low Limit/LO_LO_LIM and Low Limit/ LO_LIM parameters. The limit values entered must be within the value range specified for the Output Scale/ OUT_SCALE parameter → □ 111.
- 7. Specify the alarm priorities by means of the High High Priority/HI_HI_PRI, High Priority/ HI_PRI, Low Low Priority/LO_LO_PRI and Low Priority/LO_PRI parameters. Reporting to the field host system only takes place with alarms with a priority greater than 2.
- Set the block mode to Auto using the Block Mode/MODE_BLK parameter, TARGET element. For this purpose, the Resource Block must also be set to the Auto block mode.

12.2.5 Additional configuration

- 1. Link the function blocks and output blocks.
- 2. After specifying the active LAS, download all the data and parameters to the field device.

12.3 Scaling of the measured value in an AI Block

If the type of linearisation **L_TYPE** = **indirect** has been selected in an AI block, the measured value can be scaled within the block. The input range is defined by the **XD_SCALE** parameter Through its **EU_0** and **EU_100** elements. This range is mapped linearly to the output ranged defined by the **OUT_SCALE** parameter through its **EU_0** and **EU_100** elements.



Scaling of the measured value in an AI Block

- If you have selected the **Direct** mode for the **L_TYPE** parameter, you cannot change the values and units for **XD_SCALE** and **OUT_SCALE**.
 - The **L_TYPE**, **XD_SCALE** and **OUT_SCALE** parameters can only be changed in the OOS block mode.

12.4 Language selection

Step	Block	Parameter	Action
1	DISPLAY (TRDDISP)	Language (language)	Select language ¹⁾ .
			Selection: 32805: Arabian 32824: Chinese simplified 32842: Czech 32881: Dutch 32888: English 32917: French 32920: German 32945: Italian 32946: Japanese 32948: Korean 33026: Polish 33027: Portuguese 33062: Russian 33083: Spanish 33103: Thai 33120: Vietnamese 33155: Bahasa 33166: Turkish

¹⁾ When ordering a device the set of available languages is defined. Refer to the product structure, feature 500 "Additional Operation Language".

12.5 Checking the reference distance

This section is only valid for FMP54 with gas phase compensation (product structure: feature 540 "Application Package", option EF or EG).

Coax probes with gas phase compensation are calibrated on delivery. Rod probes, on the other hand, must be recalibrated after mounting:

After mounting the rod probe in the stilling well or bypass, check and - if necessary - correct the setting of the reference distance in the unpressurized state. Whilst doing so the

level should be at least 200 mm below the reference distance L_{ref} to achieve maximum accuracy.


Step	Block	Parameter	Action	
1	EXPERT_CONFIG (TRDEXP)	GPC mode (gpc_mode)	Select the On (33006) option in order to activate gas phase compensation.	
2	EXPERT_CONFIG (TRDEXP)	Present reference distance (present_reference_dis tance)	Check whether the displayed reference	
3	EXPERT_CONFIG (TRDEXP)	Reference distance (reference_distance)	Enter the value indicated in "Present reference distance".	

For a detailed description of all parameters concerning the gas phase compensation see:

GP010151F, "Levelflex - Description of device parameters - FOUNDATION Fieldbus"

12.6 Configuration of a level measurement

The **Setup** method can also be used to configure the measurement. It is called up via the SETUP (TRDSUP) transducer block.



ightharpoonup 31 Configuration parameters for level measurements in liquids

 $LN = Length \ of \ probe$ $R = Reference \ point \ of \ the \ measurement$ D = Distance $E = Empty \ calibration \ (= Zero \ point)$ L = Level $F = Full \ calibration \ (= span)$

If for rope probes the DC value is less than 7, then measurement is not possible in the area of the straining weight. In these cases, the maximum allowed value for the empty calibration E is LN - 250 mm (LN - 10 in).


Step	Block	Parameter	Action
1	SETUP (TRDSUP)	Distance unit (distance_unit)	Select distance unit. Selection: 1010: m 1013: mm 1018: in 1019: ft
2	SETUP (TRDSUP)	Operating mode (operating_mode) 1)	Select 32949: Level.
3	SETUP (TRDSUP)	Tank type (tank_type)	Select tank type. Selection: 32816: Bypass / pipe 33288: Metallic 33302: Coaxial 33432: Twin rope 33433: Twin rod 33437: Rope centering disc metallic 33438: Rod centering disc metallic 33441: Non metallic 33444: Mounted outside
4	SETUP (TRDSUP)	Tube diameter (tube_diameter) 2)	Enter the diameter of the bypass or stilling well.

Step	Block	Parameter	Action
5	SETUP (TRDSUP)	Medium group (medium_group)	Select medium group. Selection: ■ 316: water based (DC>4) ■ 256: other (DC≥ 1.9) 3)
6	SETUP (TRDSUP)	Empty calibration (empty_calibration)	Enter the distance E between the reference point R and the minimum level (0%).
7	SETUP (TRDSUP)	Full calibration (full_calibration)	Enter distance F between the minimum (0%) and maximum (100%) level.
8	SETUP (TRDSUP)	Level (level)	Displays the measured level L.
9	SETUP (TRDSUP)	Distance (filtered_dist_val)	Displays the distance D between the reference point R and the level L.
10	SETUP (TRDSUP)	Signal quality (signal_quality)	Displays the signal quality of the level echo.
11	SETUP (TRDSUP)	Confirm distance (confirm_distance)	Compare the displayed distance to the real distance in order to start the recording of the mapping curve.
			Selection: 179: Manual map 32847: Delete all 32859: Distance ok 32860: Distance too big 32861: Distance too small 32862: Distance unknown 33100: Tank empty

- 1) only available for devices with "interface measurement" application package
- 2) only available for coated probes and "Tank type" = "Bypass/pipe"
- 3) If required, lower DCs can ben entered into the "DC value (dc_value)" parameter. However, for DC<1.6 the measuring range may be reduced; for details please contact Endress+Hauser.

12.7 Configuration of an interface measurement

- Only devices with the respective software option can be used for interface measurements. This option is selected in the product structure: Feature 540 "Application package", option EB "Interface measurement".
- The **Setup** method can also be used to configure the measurement. It is called up via the SETUP (TRDSUP) transducer block.



■ 32 Configuration parameters for interface measurements

R = Reference pioint of the measurement D_I = Distance of interface (Distance from reference point to lower medium)

 $E = Empty \ calibration \ (= zero \ point)$ $L_I = Interface \ level$

F = Full calibration (= span) D_L = Distance from reference point R to total level

 $LN = Length \ of \ probe$ $L_L = total \ level$

 $UP = Thickness \ of \ upper \ medium$

Schritt	Block	Parameter	Action
1	SETUP (TRDSUP)	Distance unit (distance_unit)	Select distance unit.
			Selection: ■ 1010: m ■ 1013: mm ■ 1018: in ■ 1019: ft
2	SETUP (TRDSUP)	Operating mode (operating_mode) 1)	Select 32938: Interface .
3	SETUP (TRDSUP)	Tank type (tank_type)	Select tank type.
			Selection: 32816: Bypass / pipe 33288: Metallic 33302: Coaxial 33432: Twin rope 33433: Twin rod 33437: Rope centering disc metallic 33438: Rod centering disc metallic 33441: Non metallic 33444: Mounted outside
4	SETUP (TRDSUP)	Tube diameter (tube_diameter) 2)	Enter the diameter of the bypass or stilling well.
5	SETUP (TRDSUP)	Tank level (tank_level)	Select tank level.
			Selection: 32919: Fully flooded (typical for bypass measurements) 33021: Partially filled (typical for measurements directly in tank)

Schritt	Block	Parameter	Action
6	SETUP (TRDSUP)	Distance to upper connection (distance_to_upper_connection)	 For measurements in bypasses: Enter the distance from the reference point R to the lower edge of the upper connection. Otherwise: Keep the factory setting.
7	SETUP (TRDSUP)	DC value (dc_value)	Enter dielectric constant of the upper medium.
8	SETUP (TRDSUP)	Empty calibration (empty_calibration)	Enter the distance E between the reference point R and the minimum level (0%).
9	SETUP (TRDSUP)	Full calibration (full_calibration)	Enter distance F between the minimum (0%) and maximum (100%) level.
10	SETUP (TRDSUP)	Level (level)	Displays the measured level L.
11	SETUP (TRDSUP)	Interface (interface)	Displays the interface height L _I .
12	SETUP (TRDSUP)	Distance (filtered_dist_val)	Displays the distance D between the reference point R and the level L.
13	SETUP (TRDSUP)	Interface distance (interface_distance)	Displays the distance D_{I} between the reference point R and the interface L_{I} .
14	SETUP (TRDSUP)	Signal quality (signal_quality)	Displays the signal quality of the level echo.
15	SETUP (TRDSUP)	Confirm distance (confirm_distance)	Compare the displayed distance to the real distance in order to start the recording of the mapping curve.
			Selection: 179: Manual map 32847: Delete all 32859: Distance ok 32860: Distance too big 32861: Distance too small 32862: Distance unknown 33100: Tank empty

- 1) only available for devices with "interface measurement" application package
- 2) only available for coated probes and "Tank type" = "Bypass/pipe"

12.8 Configuration of the on-site display

12.8.1 Factory settings of the on-site display for level measurements

Parameter	Factory setting for devices with 1 current output	Factory setting for devices with 2 current outputs
Format display	1 value, max. size	1 value, max. size
Value 1 display	Levele linearized	Levele linearized
Value 2 display	Distance	Distance
Value 3 display	Current output 1	Current output 1
Value 4 display	None	Current output 21

The on-site display can be adjusted in the **DISPLAY (TRDDISP)** transducer block.

12.8.2 Factory settings of the on-site display for interface measurements

Parameter	Factory setting for devices with 1 current output	Factory setting for devices with 2 current outputs
Format display	1 value, max. size	1 value, max. size
Value 1 display	Interface	Interface
Value 2 display	Level linearized	Level linearized
Value 3 display	Upper interface thickness	Current output 1
Value 4 display	Current output 1	Current output 2

The on-site display can be adjusted in the **DISPLAY (TRDDISP)** transducer block.

12.9 Configuration management

After commissioning, you can save the current device configuration, copy it to another measuring point or restore the previous device configuration. You can do so using the **Configuration management** parameter and its options.

Navigation path in the operating menu

Setup \rightarrow Advanced setup \rightarrow Conf.backup disp \rightarrow Config. managem.

Block operation

Block: **DISPLAY (TRDDISP)**

Parameter: Configuration management (configuration_management)

Functions of the parameter options

Options	Description
33097: Execute backup	A backup copy of the current device configuration in the HistoROM is saved to the display module of the device. The backup copy comprises the transmitter data of the device.
33057: Restore	The last backup copy of the device configuration is copied from the display module to the HistoROM of the device. The backup copy comprises the transmitter data of the device.
33838: Duplicate	The transmitter configuration from another device is duplicated to the device using the display module.
265: Compare	The device configuration saved in the display module is compared to the current device configuration of the HistoROM.
32848: Clear backup data	The backup copy of the device configuration is deleted from the display module of the device.

HistoROM


A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

- While this action is in progress, the configuration cannot be edited via the local display and a message on the processing status appears on the display.
- For devices with FOUNDATION Fieldbus communication, the **PD Tag** parameter is also transmitted when duplicating the parameter configuration. If required change **PD Tag** to the required value after duplicating the set.

12.10 Configuration of the event behavior according to the FOUNDATION Fieldbus specification FF912

The device complies with the FOUNDATION Fieldbus specification FF912. This has among other things - the following consequences:

- The diagnsotic category according to NAMUR recommendation NE107 is transmitted via the fieldbus in a manufacturer-independent form:
 - F: Failure
 - C: Function check
 - S: Out of specification
 - M: Maintenance required
- The diagnostic category of pre-defined groups of events can be adjusted by the user according to the requirements of the specific application.
- Certain events can be separated from their group and can be handled individually:
 - 941: Echo lost
 - 942: In safety distance
- Additional information and remedial measures are transmitted together with the event message via the fieldbus.
- The diagnostic messages according to FF912 are available in the host only if the **Multi-bit support** option has been activated in the **FEATURE_SEL** parameter of the Resource block. For reasons of compatibility, this option is **not** activated on delivery:



12.10.1 Groups of events

The diagnostic messages are classified into 16 groups according to the **source** and **severity** of the respective event. A **default diagnostic category** is allocated to each group. Each group is also represented by one bit of the allocation parameters.

Severity of the event	Default diagnostic category	Source of the event	Bit	Events within the group
Highest severity	Failure (F)	Sensor	Sensor F003: Broken probe detect F046: Build-up detected F083: Memory content F104: HF cable F105: HF cable F106: Sensor	F083: Memory contentF104: HF cableF105: HF cable
		Electronics 30	■ F242: Software incompatible ■ F252: Modules incompatible ■ F261: Electronic modules ■ F262: Module connecting ■ F270: Main electronic failure ■ F271: Main electronic failure ■ F272: Main electronic failure ■ F273: Main electronic failure ■ F275: I/O-Modul failure ■ F276: I/O module failure ■ F282: Datenspeicher ■ F283: Electronic memory ■ F311: Memory content	
		Configuration	29	 F410: Data transfer F411: Up-/download F435: Linearization F437: Configuration incompatible
		Process	28	 F803: Current loop 1 F825: Current loop 1 F936: EMC interference F941: Echo lost 1) F970: Linearization

1) This event can be removed from the group in order to define its behavior individually; see section "Configurable area".

Severity of the event	Default diagnostic category	Source of the event	Bit	Events within the group
High severity	Function check (C)	Sensor	27	not used in Levelflex
		Electronics	26	not used in Levelflex
		Configuration	25	 C411: Up-/download C431: Trim C484: Simulation failure mode C485: Simulation measured value C491: Simulation current output C585: Simulation distance
		Process	24	not used in Levelflex

Severity of the event	Default diagnostic category	Source of the event	Bit	Events within the group
Low severity	Out of specification (S)	Sensor	23	not used in Levelflex
		Electronics	22	not used in Levelflex

Severity of the event	Default diagnostic category	Source of the event	Bit	Events within the group
		Configuration	21	S441: Current output 1
		Process	20	 S801: Energy too low S825: Operating temperature S921: Change of reference S942: In safety distance ¹⁾ S943: In blocking distance S944: Level range S968: Level limited

1) This event can be removed from the group in order to define its behavior individually; see section "Configurable area".

Severity of the event	Default diagnostic category	Source of the event	Bit	Events within the group
Lowest severity	Maintenance required (M)	Sensor	19	not used in Levelflex
		Elektronics	18	 M270: Main electronics failure M272: Main electronics failure M311: Electronics failure
		Configuration	17	M438: Data set
		Process	16	M803: Current loop 1

12.10.2 Allocation parameters

The allocation of event categories to the event groups is controlled by the allocation parameters. They reside in the **RESOURCE (RB2)** block:

- **FD_FAIL_MAP**: for the **Failure (F)** event category
- FD CHECK MAP: for the Function check (C) event category
- FD_OFFSPEC_MAP: for the Out of specification (S) event category
- FD_MAINT_MAP: for the Maintenance required (M) event category

Each allocation parameter consists of 32 bits with the following meaning:

- **Bit 0:** reserved by the Fieldbus Foundation
- **Bits 1 to 15:** Configurable area; here, a number of predefined diagnostic events can be allocated irrespective of the group of events they belong to. In this case they are removed from their group and their bahavior can be configured individually. With Levelflex, the following parameters can be allocated to the configurable area:
 - 941: Echo lost
 - 942: In safety distance
- **Bits 16** ... **31:** Standard area; these bits are permanently allocated to a specific group of events. If a bit is set to **1**, the respective event category is assigned to the group.

The following table represents the default setting of the allocation parameters. In the default setting there is a unique relationship between the severity of the event and its category (i.e. its allocation parameter).

Default setting of the allocation parameters

		Standard area							Configurable area								
Severity of the event	Hig	jhest	seve	rity	Н	igh s	everi	ty	L	ow s	everi	ty	Lov	west	seve	rity	
Source of the event 1)	S	Е	С	P	S	Е	С	P	S	Е	С	P	S	Е	С	P	
Bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15 1
FD_FAIL_MAP	1	1	1	1	0	0	0	0	0	0	0	0	0	0	0	0	0
FD_CHECK_MAP	0	0	0	0	1	1	1	1	0	0	0	0	0	0	0	0	0
FD_OFFSPEC_MAP	0	0	0	0	0	0	0	0	1	1	1	1	0	0	0	0	0
FD_MAINT_MAP	0	0	0	0	0	0	0	0	0	0	0	0	1	1	1	1	0


1) S: Sensor; E: Electronics; C: Configuration; P: Process

In order to change the diagnostic behavior of a group of events, proceed as follows:

- 1. Open the allocation parameter to which the group is currently allocated.
- 2. Switch the bit of the group from **1** to **0**. In the case of operation via FieldCare this is done by deactivating the respective checkbox (see the example below).
- 3. Open the allocation to which the group is to be allocated.
- 4. Switch the bit of the group from **0** to **1**. In the case of operation via FieldCare this is done by activating the respective checkbox (see the example below).

Example

The **Highest severity / Configuration** group contains the messages **410**: **Data transfer**, **411**: **Up-/Download**, **435**: **Linearization** and **437**: **Configuration incompatible**. These messages are no longer to be classified as **Failure (F)** but as **Function check (C)**.



Use the FieldCare navigation window to navigate to the following screen: **Expert** → **Communication** → **Field diagnostics** → **Alarm detection enable**.



■ 33 Default state of the "Fail Map" and "Check Map" columns

Look for the **Configuration Highest Severity** group in the **Fail Map** column and deactivate the associated checkbox (A). Activate the respective checkbox in the **Check Map** column (B). Remember to confirm each change by pressing the Enter key.

Process Highest severity	Process Highest severity
Configuration Highest severity	Configuration Highest severity
Electronic Highest severity	Electronic Highest severity
✓ Sensor Highest severity	Sensor Highest severity

■ 34 Changed state of the "Fail Map" and "Check Map" columns

- Make sure that for each group the corresponding bit is set to **1** in at least one of the allocation parameters. Otherwise no event category is transmitted with the event message. As a consequence the message will not be recognized by the control system.
- The **Alarm detection enable** screen is used to configure the detection of diagnostic events but not the transmission of event messages to the bus. The latter is configured on the **Alarm broadcast enable** screen, which is operated exactly in the same way as the **Alarm detection enable** screen. Status information is only transmitted to the bus if the Resource Block is in the **Auto** mode.

12.10.3 Configurable area


An event category can be individually defined for the following parameters - irrespective of the group of events they belong to by default.

- **F941**: Echo lost
- **S942:** In safety distance

Prior to changing the event category, the event must be allocated to one of the bits 1 to 15. This is performed by the parameters **FF912 ConfigArea_1** to **FF912ConfigArea_15** in the **DIAGNOSTIC (TRDDIAG)** block. Thereafter, the selected bit can be switched from **0** to **1** in the desired allocation parameter.

Example

To change the category of error **942** "In safety distance" from **Out of specification (S)** (default), to **Function check (C)**, proceed as follows.



Use the FieldCare navigation window to navigate to the following screen: **Expert** → **Communication** → **Field diagnostics** → **Alarm detection enable**.



By default all **Configurable Area Bits** are set to **not used**.



Select one of these bits (in the example: Configurable Area Bit 1) and select **In safety distance** from the associated drop-down menu. Confirm the selection by pressing the Enter key.




Got to the **Offspec Map** column and activate the checkbox of the respective bit (in the example: **Configurable Area Bit 1**). Confirm the selection by pressing the Enter key.

A change of the error category of **In safety distance** does not affect an error which is already present. The new category is only assigned if a new error of this type occurs after the change.

12.10.4 Transmission of the event messages to the bus

Event priority

Event messages are only transmitted to the bus if their priority is between 2 and 15. Events of priority 1 are indicated on the display but not transmitted to the bus. Events of priority 0 are ignored. By default, the priority is 0 for all events. The priority can be adjusted individually for each allocation parameter. This is done by the following four priority parameters:



Suppression of individual events

For individual events, the transmission to the bus can suppressed by the use of a mask. The corresponding events will be displayed but not transmitted to the bus. In FieldCare, this mask can be found at $\mathbf{Expert} \to \mathbf{Communication} \to \mathbf{Field\ diagnostics} \to \mathbf{Alarm\ broadcast\ enable}$. This mask functions as a negative mask, which means that, if a field is marked, the corresponding events will \mathbf{not} be transmitted to the bus.

12.11 Protection of the settings against unauthorized changes

There are two ways to protect the settings against unauthorized changes:

- Via locking switch (hardware locking)
- Via operating menu (software locking)
- Via block operation:
 - Block: **DISPLAY (TRDDISP)**; parameter: **Define access code (define_access_code)**
 - Block: EXPERT_CONFIG (TRDEXP); parameter: Enter access code (enter_access_code)

13 Diagnostics and troubleshooting

13.1 General trouble shooting

13.1.1 General errors

Error	Possible cause	Remedial action
Device does not respond.	Supply voltage not connected.	Connect the correct voltage.
	The cables do not contact the terminals properly.	Ensure electrical contact between the cable and the terminal.
Values on the display invisible	Contrast setting is too weak or too strong.	 Increase contrast by pressing ± and E simultaneously. Decrease contrast by pressing □ and E simultaneously.
	The plug of the display cable is not connected correctly.	Connect the plut correctly.
	Display is defective.	Replace display.
"Communication error" is indicated	Electromagnetic interference	Check grounding of the device.
on the display when starting the device or connecting the display	Broken display cable or display plug.	Exchange display.
Duplicating of the parameters from one device to another via the display doesn't work. Only the "Save" and "Abort" options are available.	Display with backup is not recognized if no data backup has been performed at the device before.	Connect display (with the backup) and restart the device.
CDI communication does not work.	Wrong setting of the COM port on the computer.	Check the setting of the COM port on the computer and change it if necessary.
Device measures incorrectly.	Parametrization error	Check and adjust parameterization.

13.1.2 Parametrization errors

Parametrization errors for level measurements

Error	Possible cause	Remedial action
Measured value wrong	If measured distance(Setup → Distance) matches the real distance: Calibration error	 Check and adjust the Empty calibration parameter (→ ≦ 167) if necessary. Check and adjust the Full calibration parameter (→ ≦ 168) if necessary. Check and adjust linearization if necessary (Linearization submenu (→ ≦ 195)).
	If measured distance (Setup → Distance) does not match the real distance: An interference echo affects the measurement.	Perform mapping (Confirm distance parameter ($\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$
No change of the measured value when emptying/filling	An interference echo affects the measurement.	Perform mapping (Confirm distance parameter (→ 🖺 175)).
the tank	Build-up at the probe.	Clean the probe.
	Error in the echo tracking	Deactivate echo tracking: Expert → Sensor → Echo tracking → Evaluation mode = History off).
The diagnostic message Echo lost appears after switching on the supply voltage.	Echo threshold too high.	Check the Medium group parameter $(\rightarrow \boxminus 166)$. If necessary select a more detailed setting in the Medium property parameter $(\rightarrow \boxminus 183)$.
	Level echo suppressed.	Delete mapping and record new mapping curve if required (Record map parameter (→ 🖺 177)).
Device displays a level when the tank is empty.	Incorrect probe length	Carry out probe length correction (Confirm probe length parameter (→ 🖺 209)).
	Interference echo	Carry out mapping over entire probe while the tank is empty (Confirm distance parameter (→ 🖺 175)).
Wrong slope of the level in the entire measuring range	Wrong tank type selected.	Set Tank type parameter ($\Rightarrow \triangleq 165$) correctly.

Parametrization errors for interface measurements


Error	Possible cause	Remedial action
With the setting Tank level = Fully flooded When, the	The total level is detected outside the upper blocking distance.	Increase blocking distance (Blocking distance parameter (→ 🖺 186)).
measured interface level jumps to higher values during draining operations.		Set Tank level parameter (→ 🖺 172) = Partially filled .
With the setting Tank level = Partially filled , the measured total level jumps to lower values during filling operations.	The total level runs into the upper blocking distance.	Decrease blocking distance (Blocking distance parameter (→ 🖺 186)).
Wrong slope of the measured interface level	Wrong dielectric constant (DC value).	Enter correct dielectric constant (DC value) of the upper medium (DC value parameter ($\rightarrow \square$ 173)).
The measured values for the interface and the total level are identical	Echo threshold for the total level too high due to a wrong dielectric constant.	Enter correct dielectric constant (DC value) of the upper medium (DC value parameter (→ 🖺 173)).

Error	Possible cause	Remedial action
If the interface layers are thin, the total level jumps to the interface level.	The thickness of the upper medium is less than 60 mm (2.4 in).	Interface measurement is only possible if the thickness of the interface is greater than 60 mm (2.4 in).
The measured interface layer jumps.	Emulsion layer present.	Emulsion layers affect the measurement. Please contact Endress+Hauser.

13.2 Diagnostic information on local display

13.2.1 Diagnostic message

Faults detected by the self-monitoring system of the measuring device are displayed as a diagnostic message in alternation with the measured value display.



Status signals


A0032902	"Failure (F)" option A device error is present. The measured value is no longer valid.
C	"Function check (C)" option The device is in service mode (e.g. during a simulation).
S	 "Out of specification (S)" option The device is operated: Outside of its technical specifications (e.g. during startup or a cleaning) Outside of the configuration carried out by the user (e.g. level outside configured span)
M A0032905	"Maintenance required (M)" option Maintenance is required. The measured value is still valid.

Status symbol (symbol for event level)

8	"Alarm" status The measurement is interrupted. The signal outputs take on the defined alarm condition. A diagnostic message is generated.
Λ	"Warning" status The device continues to measure. A diagnostic message is generated.

Diagnostics event and event text

The fault can be identified using the diagnostics event. The event text helps you by providing information about the fault. In addition, the corresponding symbol is displayed before the diagnostics event.



If two or more diagnostic messages are pending simultaneously, only the message with the highest priority is shown. Additional pending diagnostic messages can be shown in the **Diagnostic list** submenu.




Past diagnostic messages that are no longer pending are shown as follows:

- On the local display:
- in the **Event logbook** submenu
- In FieldCare: via the "Event List /HistoROM" function.

Operating elements

Operating functions in menu, submenu				
+	Plus key Opens the message about the remedial measures.			
E	Enter key Opens the operating menu.			

13.2.2 Calling up remedial measures



A0029431-EN

- 35 Message for remedial measures
- 1 Diagnostic information
- 2 Short text
- 3 Service ID
- 4 Diagnostic behavior with diagnostic code
- 5 Operation time of occurrence
- 6 Remedial measures

The user is in the diagnostic message.

- 1. Press ± (①-Symbol).
 - **→ Diagnostic list** submenu opens.
- **2.** Select the desired diagnostic event with \pm or \Box and press \blacksquare .
 - └ The message for the remedial measures for the selected diagnostic event opens.
- 3. Press \Box + \pm simultaneously.
 - ► The message for the remedial measures closes.

The user is in the **Diagnostics** menu at an entry for a diagnostics event, e.g. in **Diagnostic list** submenu or in **Previous diagnostics**.

- 1. Press E.
 - └─ The message for the remedial measures for the selected diagnostic event opens.
- 2. Press \Box + \pm simultaneously.
 - ► The message for the remedial measures closes.

132


13.3 Diagnostic event in the operating tool

If a diagnostic event is present in the device, the status signal appears in the top left status in the operating tool along with the corresponding symbol for event level in accordance with NAMUR NE 107:

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)


A: Via the operating menu

- 1. Navigate to the **Diagnostics** menu.
 - In the **Actual diagnostics** parameter, the diagnostic event is shown with event text.
- 2. On the right in the display range, hover the cursor over the **Actual diagnostics** parameter.




A tool tip with remedial measures for the diagnostic event appears.

B: Via the "Create documentation" function




Select the "Create documentation" function.



Make sure "Data overview" is marked.

- 3. Click "Save as ..." and save a PDF of the protocol.
 - └ The protocol contains the diagnostic messages and remedy information.

C: Via the "Eventlist / Extended HistoROM" function



Select the "Eventlist / Extended HistoROM" function.



Select the "Load Eventlist" function.

The list of events, including remedy information, is shown in the "Data overview" window.

13.4 Diagnostic messages in the DIAGNOSTIC Transducer Block (TRDDIAG)

- The Actual diagnostics parameter displays the message with the highest priority. Every
 message is also output as per the FOUNDATION Fieldbus Specification by means of the
 XD_ERROR and BLOCK_ERROR parameters.
- A list of diagnostic messages is displayed in the **Diagnostics 1** to **Diagnostics 5** parameters. If more than 5 messages are currently active, only those with the highest priority are displayed.
- You can view a list of alarms which are no longer active (event log) via the Previous diagnostics parameter.

13.5 Diagnostic list

In the **Diagnostic list** submenu submenu, up to 5 currently pending diagnostic messages can be displayed. If more than 5 messages are pending, the messages with the highest priority are shown on the display.

Navigation path

 $Diagnostics \rightarrow Diagnostic\ list$

Calling up and closing the remedial measures

- 1. Press E.
 - └ The message for the remedial measures for the selected diagnostic event opens.
- 2. Press □ + ± simultaneously.
 - ► The message about the remedial measures closes.

13.6 Event logbook

13.6.1 Event history

A chronological overview of the event messages that have occurred is provided in the **Event list** submenu ⁶⁾.

Navigation path

Diagnostics \rightarrow Event logbook \rightarrow Event list

A maximum of 100 event messages can be displayed in chronological order.

Die Ereignishistorie umfasst Einträge zu:

- Diagnostic events
- Information events

In addition to the operation time of its occurrence, each event is also assigned a symbol that indicates whether the event has occurred or is ended:

- Diagnostic event
 - ⊕: Event has occurred
 - ⊖: Event has ended
- Information event
 - €: Event has occurred

Calling up and closing the remedial measures

- 1. Press E
 - ► The message for the remedial measures for the selected diagnostic event opens.
- 2. Press \Box + \pm simultaneously.
 - ► The message about the remedial measures closes.

13.6.2 Filtering the event logbook

Using the **Filter options** parameter, you can define which category of event messages is displayed in the **Event list** submenu.

Navigation path

Diagnostics \rightarrow Event logbook \rightarrow Filter options

Filter categories

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information

13.6.3 Overview of information events

Info number	Info name		
11000	(Device ok)		
I1089	Power on		
I1090	Configuration reset		
I1091	Configuration changed		


⁶⁾ This submenu is only available for operation via local display. In the case of operation via FieldCare, the event list can be displayed with the "Event List / HistoROM" functionality of FieldCare.

Info number	Info name			
I1092	Trend data deleted			
I1110	Write protection switch changed			
I1137	Electronic changed			
I1151	History reset			
I1154	Reset terminal voltage min/max			
I1155	Reset electronic temperature			
I1156	Memory error trend			
I1157	Memory error event list			
I1185	Display backup done			
I1186	Restore via display done			
I1187	Settings downloaded with display			
I1188	Display data cleared			
I1189	Backup compared			
I1256	Display: access status changed			
I1264	Safety sequence aborted			
I1335	Firmware changed			
I1397	Fieldbus: access status changed			
I1398	CDI: access status changed			
I1512	Download started			
I1513	Download finished			
I1514	Upload started			
I1515	Upload finished			

13.7 Firmware history

Date	Firmware	Modifications	Documentation (FMP51, FMP52, FMP54, FOUNDATION Fieldbus)		
	version		Operating Instructions	Description of Parameters	Technical Information
04.2012	01.00.zz	Original software	BA01052F/00/EN/01.12	GP01015F/00/EN/01.12	TI01001F/00/EN/15.12
05.2015	01.01.zz	 Support of SD03 additional languages HistoROM functionality enhanced "Advanced Diagnostic" function block integrated Improvements and bugfixes 	BA01052F/00/EN/03.15 BA01052F/00/EN/04.16 ¹⁾	GP01015F/00/EN/02.15	TI01001F/00/EN/19.15 TI01001F/00/EN/22.16 ¹⁾

1) Contains information on the Heartbeat wizards which are available in the latest DTM version for DeviceCare and FieldCare.



14 Maintenance

The measuring device requires no special maintenance.

14.1 Exterior cleaning

When exterior-cleaning the device, always use cleaning agents that do not attack the surface of the hosuing and the seals.

15 Repairs

15.1 General information on repairs

15.1.1 Repair concept

The Endress+Hauser repair concept assumes that the devices have a modular design and that repairs can be done by the Endress+Hauser service or specially trained customers.

Spare parts are contained in suitable kits. They contain the related replacement instructions.

For more information on service and spare parts, contact the Service Department at Endress+Hauser.

15.1.2 Repairs to Ex-approved devices

When carrying out repairs to Ex-approved devices, please note the following:

- Repairs to Ex-approved devices may only be carried out by trained personnel or by the Endress+Hauser Service.
- Comply with the prevailing standards, national Ex-area regulations, safety instructions (XA) and certificates.
- Only use original spare parts from Endress+Hauser.
- When ordering a spare part, please note the device designation on the nameplate. Only replace parts with identical parts.
- Carry out repairs according to the instructions. On completion of repairs, carry out the specified routine test on the device.
- Only Endress+Hauser Service may convert a certified device into a different certified variant.
- Document all repair work and conversions.

15.1.3 Replacement of an electronics module

If an electronics module has been replaced, it is not necessary to perform a new basic setup as the calibration parameters are stored in the HistoROM which is located in the housing. However, after exchanging the main electronics module it may be necessary to record a new mapping (interference echo suppression).

15.1.4 Replacement of a device

After a complete device or electronic module has been replaced, the parameters can be downloaded into the instrument again in one of the following ways:


- Via the display module
 Condition: The configuration of the old device has been saved in the display module
 →

 224.
- Via FieldCare
 Condition: The configuration of the old device has been saved to the computer via FieldCare.

You can continue to measure without carrying out a new setup. Only a linearization and a tank map (interference echo suppression) have to be recorded again.

15.2 Spare parts

- A few interchangeable measuring device components are identified by a spare part nameplate. This contains information about the spare part.
- The connection compartment cover of the device contains a spare part nameplate that includes the following information:
 - A list of the most important spare parts for the measuring device, including their ordering information.
 - The URL for the W@M Device Viewer (www.endress.com/deviceviewer):
 There, all spare parts for the measuring device are listed, including the order code, and can be ordered. If available, the corresponding Installation Instructions can also be downloaded there.



A001497

■ 36 Example for spare part nameplate in connection compartment cover

- Measuring device serial number:
 - Is located on the device and spare part nameplate.
 - Can be read out via the "Serial number" parameter in the "Device information" submenu.

15.3 Return

The measuring device must be returned if it is need of repair or a factory calibration, or if the wrong measuring device has been delivered or ordered. Legal specifications require Endress+Hauser, as an ISO-certified company, to follow certain procedures when handling products that are in contact with the medium.

To ensure safe, swift and professional device returns, please refer to the procedure and conditions for returning devices provided on the Endress+Hauser website at http://www.endress.com/support/return-material

15.4 Disposal


Observe the following notes during disposal:

- Observe valid federal/national regulations.
- Ensure proper separation and reuse of the device components.


16 Accessories

16.1 Device-specific accessories


16.1.1 Weather protection cover




16.1.2 Mounting bracket for the electronics housing




16.1.3 Extension rod / centering HMP40




16.1.4 Mounting kit, isolated




16.1.5 Centering star



Accessory Description Centering star PFA ■ \$\phi\$ 16.4 mm (0.65 in) 0 ■ Ø 37 mm (1.46 in) 2 A: ø16.4 (0.65) B: ø37 (1.46) can be used for ■ FMP51 ■ FMP52 ■ FMP54 A0014577 For 8 mm (0.3 in) probes For 12 mm (0.47 in) and 16 mm (0.63 in) probes The centering star is suitable for probes with a rod diameter of 8 mm (0.3 in), 12 mm (0.47 in) and 16 mm (0.63 in) (also coated rod probes) and can be used in pipes from DN40 (1½") up to DN50 (2"). See also Operating Instructions BA00378F/00/A2. Material: PFA ■ Admissible process temperature: -200 to +250 °C (-382 to +482 °F) Order code - Probe 8 mm (0.3 in): 71162453 - Probe 12 mm (0.47 in): 71157270 - Probe 16 mm (0.63 in): 71069065 The PFA centering star can also be ordered directly with the device (see the Levelflex product structure, feature 610 "Accessory mounted", option OE).



16.1.6 Remote display FHX50




1) This range is valid if option JN "Ambient temperature transmitter -50 °C (-58 °F)" has been selected in ordering feature 580 "Test, Certificate". If the temperature is permanently below -40 °C (-40 °F), failure rates may be increased.

Accessory

16.1.7 Overvoltage protection

Overvoltage protection for 2-wire-devices OVP10 (1 channel) OVP20 (2 channel)

Description



A0021734

Technical data

- Resistance per channel: 2 * 0.5 Ω_{max}
- Threshold DC voltage: 400 to 700 V
- Threshold impulse voltage: < 800 V
- Capacitance at 1 MHz: < 1.5 pF
- Nominal arrest impulse voltage (8/20 μs): 10 kA
- Suited for wire cross-sections: 0.2 to 2.5 mm² (24 to 14 AWG)

Ordering with device

The overvoltage protection module is preferably ordered with the device. See product structure, feature 610"Accessory mounted", option NA "Overvoltage protection". Separate ordering of the module is only necessary if a device is to retrofitted with the overvoltage protection.

Order code for retrofitting

- For 1-channel devices (feature 020, option A) OVP10: 71128617
- For 2-channel devices (feature 020, option B, C, E or G) OVP20:71128619

Hosuing lid for retrofitting

In order to keep the necessary safety distances, the housing lid needs to be replaced if the device is retrofitted with the overvoltage protection. Depending on the housing type, the order code of the suitable lid is as follows:

- GT18 housing: Lid 71185516
- GT19 housing: Lid 71185518
- GT20 housing: Lid 71185516

Restrictions for retrofitting

Depending on the approval of the transmitter the usage of the OVP module may be restricted. A device may only be retrofitted with an OVP module if the option NA (overvoltage protection) is quoted unter Optional Specifications in the Safety Instructions (XA) pertaining to the device.



For details refer to SD01090F.

16.1.8 Bluetooth module for HART devices

Accessory	Description
Bluetooth module	Quick and easy commissioning via SmartBlue (app) Quick and easy commissioning via SmartBlue (app) No additional tools or adapters required Signal curve via SmartBlue (app) Encrypted single point-to-point data transmission (tested by Fraunhofer institue) and password protected communication via Bluetooth® wireless technology Range under reference conditions: 10 m (33 t) When using the Bluetooth module the minimum supply voltage increases by up to 3 V. Ordering with device The Bluetooth module is preferably ordered with the device. See product structure, feature 610 "Accessory Mounted", option NF "Bluetooth". A separate order is only necessary in case of retrofitting. Order code for retrofitting Bluetooth module (BT10): 713777355 Restrictions in case of retrofitting Depending on the approval of the transmitter, application of the Bluetooth module may be restricted. A device may
	only be retrofitted with a Bluetooth module if the option <i>NF</i> (Bluetooth) is listed in the associated Safety Instructions (XA) under <i>Optional specifications</i> . For details refer to SD02252F.

16.2 Communication-specific accessories

Accessory	Description
Commubox FXA291	Connects Endress+Hauser field devices with CDI interface (= Endress+Hauser Common Data Interface) to the USB interface of a computer. Order code: 51516983 For details refer to Technical Information TI00405C

Accessory	Description
Field Xpert SFX350	Field Xpert SFX350 is a mobile computer for commissioning and maintenance. It enables efficient device configuration and diagnostics for HART and FOUNDATION fieldbus devices in the non-Ex area . For details, see Operating Instructions BA01202S

Accessory	Description
Field Xpert SFX370	Field Xpert SFX370 is a mobile computer for commissioning and maintenance. It enables efficient device configuration and diagnostics for HART and FOUNDATION fieldbus devices in the non-Ex area and the Ex area . For details, see Operating Instructions BA01202S

16.3 Service-specific accessories


Accessory	Description				
DeviceCare SFE100	Configuration tool for HART, PROFIBUS and FOUNDATION Fieldbus devices				
	Technical Information TI01134S				
	 DeviceCare is available for download at www.software-products.endress.com. The download requires a registration in the Endress+Hauser software portal. Alternatively, a DeviceCare DVD can be ordered with the device. Product structure: Feature 570 "Service", Option IV "Tooling DVD (DeviceCare Setup)". 				
FieldCare SFE500	FDT-based Plant Asset Management tool. Helps to configure and maintain all field devices of your plant. By supplying status information it also supports the diagnosis of the devices. Technical Information TI00028S				

16.4 System components

Accessory	Description
Graphic Data Manager Memograph M	The graphic data manager Memograph M provides information on all the relevant process variables. Measured values are recorded correctly, limit values are monitored and measuring points analyzed. The data are stored in the 256 MB internal memory and also on an SD card or USB stick.
	For details refer to Technical Information TI00133R and Operating Instructions BA00247R

17 Operating menu

17.1 Overview of the operating menu (display module)



			. 6. 150
	Record map		→ 🖺 178
	Distance		→ 🖺 178
► An	nalog inputs		
	► Analog input 1	to 5	→ 🖺 179
		Block tag	→ 🖺 179
		Channel	→ 🖺 179
		Process Value Filter Time	→ 🖺 180
► Ad	lvanced setup		→ 🖺 181
	Locking status		→ 🖺 181
	Access status displ	ay	→ 🖺 181
	Enter access code		→ 🖺 182
	► Level		→ 🖺 183
		Medium type	→ 🖺 183
		Medium property	→ 🖺 183
		Process property	→ 🖺 184
		Advanced process conditions	→ 🖺 185
		Level unit	→ 🖺 186
		Blocking distance	→ 🖺 186
		Level correction	→ 🖺 187
	► Interface		→ 🖺 188
		Process property	→ 🖺 188
		DC value lower medium	→ 🖺 188
		Level unit	→ 🖺 189
		Blocking distance	→ 🖺 189
		Blocking distance	→ 🖺 189

	Level correction	→ 🖺 190
	► Automatic DC calculation	→ 🗎 193
	Manual thickness upper layer	→ 🖺 193
	DC value	→ 🖺 193
	Use calculated DC value	→ 🖺 193
▶ Linea	rization	→ 🗎 195
	Linearization type	→ 🗎 197
	Unit after linearization	→ 🖺 198
	Free text	→ 🖺 199
	Maximum value	→ 🖺 200
	Diameter	→ 🖺 200
	Intermediate height	→ 🖺 201
	Table mode	→ 🖺 201
	► Edit table	
	Level	→ 🖺 203
	Customer value	→ 🖺 203
	Activate table	→ 🖺 203
► Safet	y settings	→ 🖺 205
	Output echo lost	→ 🖺 205
	Value echo lost	→ 🖺 205
	Ramp at echo lost	→ 🖺 206
	Blocking distance	→ 🖺 186

,	➤ Probe settings]	→ 🖺 208
		Droho grounded		→ 🖺 208
		Probe grounded		→ 🗏 208
		► Probe length co	rrection	→ 🖺 210
			Confirm probe length	→ 🖺 210
			Present probe length	→ 🖺 210
ı	➤ Switch output]	→ 🖺 211
		Switch output funct	ion	→ 🖺 211
		Assign status		→ 🖺 211
		Assign limit		→ 🖺 212
		Assign diagnostic b	ehavior	→ 🖺 212
		Switch-on value		→ 🖺 213
		Switch-on delay		→ 🖺 214
		Switch-off value		→ 🖺 214
		Switch-off delay		→ 🖺 215
		Failure mode		→ 🖺 215
		Switch status		→ 🖺 215
		Invert output signal	l	→ 🖺 215
•	▶ Display			→ 🖺 217
		Language		→ 🖺 217
		Format display		→ 🖺 217
		Value 1 to 4 display	7	→ 🖺 219
		Decimal places 1 to	4	→ 🖺 219
		Display interval		→ 🖺 220
		Display damping		→ 🖺 220
		Header		→ 🖺 220

			Header text		→ 🖺 221
			Separator		→ 🖺 221
			Number format		→ 🖺 221
			Decimal places men	nu	→ 🖺 222
			Backlight		→ 🖺 222
			Contrast display		→ 🖺 223
		► Configuration b	ackup display		→ 🖺 224
			Operating time	_	→ 🖺 224
			Last backup		→ 🖺 224
			Configuration man	agement	→ 🖺 224
			Comparison result		→ 🖺 225
		► Administration]	→ 🖺 227
			► Define access co	ode	→ 🖺 229
				Define access code	→ 🖺 229
				Confirm access code	→ 🖺 229
			Device reset		→ 🖺 227
M Di		٦	Device reser		→ 🖺 230
♥ Diagnostics					→ 🗏 230
	Actual diagnostics				→ 🖺 230
	Previous diagnostic	CS			→ 🖺 230
	Operating time from	m restart			→ 🖺 231
	Operating time				→ 🖺 224
	▶ Diagnostic list				→ 🖺 232
		Diagnostics 1 to 5			→ 🖺 232

		_		
► Event logbook				→ 🖺 233
	Filter options			→ 🖺 233
	► Event list			→ 🖺 233
► Device informat	ion			→ 🖺 234
	Device tag			→ 🖺 234
	Serial number			→ 🖺 234
	Firmware version			→ 🖺 234
	Device name			→ 🖺 235
	Order code			→ 🖺 235
	Extended order code	e 1 to 3		→ 🖺 235
► Measured value	S			→ 🖺 236
	Distance			→ 🖺 170
	Level linearized			→ 🖺 199
	Interface distance			→ 🖺 175
	Interface linearized			→ 🖺 200
	Thickness upper lay	er		→ 🖺 238
	Terminal voltage 1			→ 🖺 238
► Analog inputs				
	► Analog input 1 t	o 5		→ 🖺 238
		Block tag		→ 🖺 179
		Channel		→ 🖺 179
		Status		→ 🖺 240
		Value		→ 🖺 240
		Units index		→ 🖺 240

► Data logging		→ 🖺 241
	Assign channel 1 to 4	→ 🖺 241
	Logging interval	→ 🖺 242
	Clear logging data	→ 🖺 242
	▶ Display channel 1 to 4	→ 🖺 243
▶ Simulation		→ 🖺 246
	Assign measurement variable	→ 🖺 247
	Process variable value	→ 🖺 247
	Switch output simulation	→ 🖺 247
	Switch status	→ 🖺 248
	Simulation device alarm	→ 🖺 248
► Device check		→ 🖺 249
	Start device check	→ 🖺 249
	Result device check	→ 🖺 249
	Last check time	→ 🖺 249
	Level signal	→ 🖺 250
	Launch signal	→ 🖺 250
	Interface signal	→ 🖺 250

17.2 Overview of the operating menu (operating tool)

≯ Setup			→ 🖺 165
	Operating mode		→ 🖺 165
	Distance unit		→ 🖺 165
	Tank type		→ 🖺 165
	Tube diameter		→ 🖺 166
	Medium group		→ 🖺 166
	Empty calibration		→ 🖺 167
	Full calibration		→ 🖺 168
	Level		→ 🖺 169
	Distance		→ 🖺 170
	Signal quality		→ 🖺 171
	Tank level		→ 🖺 172
	Distance to upper connection		→ 🖺 172
	DC value		→ 🖺 173
	Interface		→ 🖺 174
	Interface distance		→ 🖺 175
	Confirm distance		→ 🖺 175
	Present mapping		→ 🖺 176
	Mapping end point		→ 🖺 177
	Record map		→ 🖺 177
	► Analog inputs		
	► Analog input 1 t	o 5	→ 🖺 179
		Block tag	→ 🖺 179

		Channel	→ 🖺 179
		Process Value Filter Time	→ 🖺 180
► Advanced setup)		→ 🖺 181
	Locking status		→ 🖺 181
	Access status tool	ing	→ 🖺 181
	Enter access code		→ 🖺 182
	► Level		→ 🖺 183
		Medium type	→ 🖺 183
		Medium property	→ 🖺 183
		Process property	→ 🖺 184
		Advanced process conditions	→ 🖺 185
		Level unit	→ 🖺 186
		Blocking distance	→ 🖺 186
		Level correction	→ 🖺 187
	► Interface		→ 🖺 188
		Process property	→ 🖺 188
		DC value lower medium	→ 🖺 188
		Level unit	→ 🖺 189
		Blocking distance	→ 🖺 189
		Level correction	→ 🖺 190
		Manual thickness upper layer	→ 🖺 190
		Measured thickness upper layer	→ 🖺 191
		DC value	→ 🖺 191
		Calculated DC value	→ 🖺 191
		Use calculated DC value	→ 🖺 192
L			

► Linearization		→ 🖺 195
	Linearization type	→ 🖺 197
	Unit after linearization	→ 🖺 198
	Free text	→ 🖺 199
	Level linearized	→ 🖺 199
	Interface linearized	→ 🖺 200
	Maximum value	→ 🖺 200
	Diameter	→ 🖺 200
	Intermediate height	→ 🖺 201
	Table mode	→ 🖺 201
	Table number	→ 🖺 202
	Level	→ 🖺 203
	Level	→ 🖺 203
	Customer value	→ 🖺 203
	Activate table	→ 🖺 203
► Safety settings		→ 🖺 205
	Output echo lost	→ 🖺 205
	Value echo lost	→ 🖺 205
	Ramp at echo lost	→ 🖺 206
	Blocking distance	→ 🖺 186
► Probe settings		→ 🖺 208
	Probe grounded	→ 🖺 208
	Present probe length	→ 🖺 208
	Confirm probe length	→ 🖺 209

► Switch output		→ 🖺 211
	Switch output function	→ 🖺 211
	Assign status	→ 🖺 211
	Assign limit	→ 🖺 212
	Assign diagnostic behavior	→ 🖺 212
	Switch-on value	→ 🖺 213
	Switch-on delay	→ 🖺 214
	Switch-off value	→ 🗎 214
	Switch-off delay	→ 🖺 215
	Failure mode	→ 🖺 215
	Switch status	→ 🖺 215
	Invert output signal	→ 🖺 215
► Display		→ 🖺 217
	Language	→ 🖺 217
	Format display	→ 🖺 217
	Value 1 to 4 display	→ 🖺 219
	Decimal places 1 to 4	→ 🖺 219
	Display interval	→ 🖺 220
	Display damping	→ 🖺 220
	Header	→ 🖺 220
	Header text	→ 🗎 221
	Separator	→ 🖺 221
	Number format	→ 🖺 221
	Decimal places menu	→ 🖺 222

			Backlight		→ 🖺 222
			Contrast display		→ 🗎 223
		► Configuration ba	ackup display		→ 🖺 224
			Operating time		→ 🖺 224
			Last backup		→ 🖺 224
			Configuration mana	gement	→ 🖺 224
			Backup state		→ 🖺 225
			Comparison result		→ 🖺 225
		► Administration			→ 🖺 227
			Define access code		→ 🖺 229
			Device reset		→ 🖺 227
억 Diagnostics					→ 🖺 230
	Actual diagnostics				→ 🖺 230
	Timestamp				→ 🖺 230
	Previous diagnostic	S			→ 🖺 230
	Timestamp				→ 🖺 231
	Operating time from	n restart			→ 🗎 231
	Operating time				→ 🖺 224
	► Diagnostic list				→ 🖺 232
		Diagnostics 1 to 5			→ 🖺 232
		Timestamp 1 to 5			→ 🖺 232
	► Device informat	ion			→ 🖺 234
		Device tag			→ 🖺 234
		Serial number			→ 🖺 234
		Firmware version			→ 🖺 234

	Device name		→ 🖺 235
	Order code		→ 🖺 235
	Extended order code	e 1 to 3	→ 🖺 235
► Measured value	es		→ 🖺 236
	Distance		→ 🖺 170
	Level linearized		→ 🖺 199
	Interface distance		→ 🖺 175
	Interface linearized		→ 🖺 200
	Thickness upper laye	rer	→ 🖺 238
	Terminal voltage 1		→ 🖺 238
► Analog inputs			
	► Analog input 1 to	о 5	→ 🖺 238
		Block tag	→ 🖺 179
		Channel	→ 🖺 179
		Status	→ 🖺 240
		Value	→ 🖺 240
		Units index	→ 🖺 240
► Data logging			→ 🖺 241
	Assign channel 1 to	9 4	→ 🖺 241
	Logging interval		→ 🖺 242
	Clear logging data		→ 🖺 242
▶ Simulation			→ 🖺 246
	Assign measuremen	nt variable	→ 🖺 247
	Process variable valu	ue	→ 🖺 247
	Switch output simul	lation	→ 🖺 247

	Switch status	→ 🖺 248
	Simulation device alarm	→ 🖺 248
▶ Device check		→ 🖺 249
	Start device check	→ 🖺 249
	Result device check	→ 🖺 249
	Last check time	→ 🖺 249
	Level signal	→ 🖺 250
	Launch signal	→ 🖺 250
	Interface signal	→ 🖺 250
► Heartbeat		→ 🖺 251

"Setup" menu 17.3



- 🚹 🗟 : Marks the navigation path to the parameter via the display and operating module.
 - ☐: Marks the navigation path to the parameter via an operating tool (e.g. FieldCare).
 - 🗈 : Marks parameters which can be locked via the software locking.

■ ■ Setup Navigation

Operating mode		^
Navigation	Setup → Operating mode	
Prerequisite	The device has the "interface measurement" application package (available for FMP51, FMP52, FMP54) $^{7)}$.	
Description	Select operating mode.	
Selection	 Level Interface with capacitance * Interface * 	
Factory setting	FMP51/FMP52/FMP54: Level	

Distance unit		
Navigation		
Description	Length unit for distance calculation.	

Selection SI units **US** units ■ mm ■ ft ■ in m

Factory setting m

Tank type

Navigation

Prerequisite Medium type ($\rightarrow = 183$) = Liquid

Endress+Hauser

Product structure: Feature 540 "Application Package", Option EB "Interface measurement"

Visibility depends on order options or device settings

Description Select tank type.

Selection • Metallic

- Bypass / pipeNon metallicMounted outside
- Coaxial

Factory setting Depending on the probe

Additional information• Depending on the probe some of the options mentioned above may not be available or

there may be additional options.

• For coax probes and probes with metallic center washer **Tank type** parameter corresponds to the type of probe and cannot be changed.

Navigation $\blacksquare \Box$ Setup \rightarrow Tube diameter

Prerequisite \blacksquare Tank type (\rightarrow \blacksquare 165) = Bypass / pipe

■ The probe is coated.

Description Specify diameter of bypass or stilling well.

User entry 0 to 9.999 m

Factory setting 0.0384 m

Medium group	
--------------	--

Navigation $\blacksquare \square$ Setup \rightarrow Medium group

Prerequisite ■ For FMP51/FMP52/FMP54/FMP55: Operating mode (→ 🖺 165) = Level

■ Medium type (→ 🖺 183) = Liquid

Description Select medium group.

Selection • Others

■ Water based (DC >= 4)

Factory setting Others

Additional information This parameter roughly specifies the dielectric constant (DC) of the medium. For a more

detailed definition of the DC use the **Medium property** parameter ($\rightarrow \blacksquare 183$).

The **Medium group** parameter presets the **Medium property** parameter ($\rightarrow \implies 183$) as follows:

Medium group	Medium property (→ 🖺 183)
Others	Unknown
Water based (DC >= 4)	DC 4 7

- The **Medium property** parameter can be changed at a later point of time. However, when doing so, the **Medium group** parameter retains its value. Only the **Medium property** parameter is relevant for the signal evaluation.
- The measuring range may be reduced for small dielectric constants. For details refer to the Technical Information (TI) of the respective device.


Navigation Setup → Empty calibration

Description Distance process connection to min. level.


Depending on the probe User entry

Factory setting Depending on the probe

Additional information



Empty calibration (E) for level measurements in liquids



■ 41 Empty calibration (E) for interface measurements

In the case of interface measurements the **Empty calibration** parameter is valid for both, the total and the interface level.

Full calibration


Navigation $\blacksquare \blacksquare$ Setup \rightarrow Full calibration

Description Span: max. level - min level.


User entry Depending on the probe

Factory setting Depending on the probe

Additional information



■ 42 Full calibration (F) for level measurements in liquids



■ 43 Full calibration (F) for interface measurements

In the case of interface measurements the **Full calibration** parameter is valid for both, the total and the interface level.

Level


Navigation

Setup → Level


Description

Displays measured level L_L (before linearization).

Additional information



■ 44 Level in case of liquid measurements



■ 45 Level in case of interface measurements

■ The unit is defined in the **Level unit** parameter ($\rightarrow \blacksquare 186$).

■ In case of interface measurements, this parameter always refers to the total level.


Distance

Navigation


Description

Displays the measured distance D_L between the reference point (lower edge of the flange or threaded connection) and the level.

Additional information



■ 46 Distance for liquid measurements



47 Distance for interface measurements

The unit is defined in the **Distance unit** parameter ($\rightarrow \triangleq 165$).

Signal quality

Navigation

Description

Displays the signal quality of the evaluated echo.

Additional information

Meaning of the display options

Strong

The evaluated echo exceeds the threshold by at least 10 mV.

Medium

The evaluated echo exceeds the threshold by at least 5 mV.


Weak

The evaluated echo exceeds the threshold by less than 5 mV.

No signal

The device does not find a usable echo.

The signal quality indicated in this parameter always refers to the currently evaluated echo: either the level/interface echo ⁸⁾ or the end-of-probe echo. To differentiate between these two, the quality of the end-of-probe echo is always displayed in brackets.



- F941, for Output echo lost (\rightarrow 🗎 205) = Alarm.
- S941, if another option has been selected in **Output echo lost** (\rightarrow **\stackrel{\triangle}{=} 205**).

⁸⁾ Of these two echos the one with the lower quality is indicated.

Tank level

Prerequisite Operating mode (→ 🖺 165) = Interface

Description Specify whether the tank or bypass is completely flooded or not.

Selection Partially filled

Fully flooded

Factory setting Partially filled

Additional information


Meaning of the options

Partially filled

The device searches for 2 echo signals, one for the interface and one for the total level.

Fully flooded

The device searches for the interface level only. With this setting it is essential that the upper level signal always is within the upper blocking distance (UB) in order to avoid that it is evaluated by mistake.



- 1 Partially filled
- 2 Fully flooded
- UB Upper blocking distance

Distance to upper connection

Navigation $\blacksquare \Box$ Setup \rightarrow Distance to upper connection

Prerequisite The device has the "Interface measurement" application package ⁹⁾.


User entry 0 to 200 m

⁹⁾ Product structure: Feature 540 "Application Package", Option EB "Interface measurement"

Factory setting

- For Tank level (→ 🖺 172) = Partially filled: 0 mm (0 in)
- For Tank level ($\rightarrow \implies$ 172) = Fully flooded: 250 mm (9.8 in)

Additional information



Dependence on the "Tank level" parameter

- Tank level (→ 🗎 172) = Partially filled: In this case the **Distance to upper connection** parameter does not influence the measurement. Thus, the default setting needs not to be changed.
- Tank level (→ 🗎 172) = Fully flooded: In this case enter the distance D_U between the reference point and the lower edge of the upper connection.

DC value		

Navigation \blacksquare Setup \rightarrow DC value

Prerequisite The device has the "interface measurement" application package ¹⁰⁾.


Description Specify relative dielectric constant ε_r of the upper medium (DC₁).

User entry 1.0 to 100

Factory setting 2.0

¹⁰⁾ Product structure: Feature 540 "Application Package", Option EB "Interface measurement"

Additional information



DC1 Relative dielectric constant of the upper medium.


A0013183

- For dielectric constants (DC values) of many media commonly used in various industries refer to:
 - the Endress+Hauser DC manual (CP01076F)
 - the Endress+Hauser "DC Values App" (available for Android and iOS)

Interface

Prerequisite Operating mode (→ 🖺 165) = Interface or Interface with capacitance

Additional information



The unit is defined in the **Level unit** parameter ($\rightarrow \triangleq 186$).

Interface distance


Navigation Setup → Interface distance

Prerequisite Operating mode (→ 🖺 165) = Interface or Interface with capacitance

Description Displays the measured distance D_I between the reference point (lower edge of flange or

threaded connection) and the interface.

Additional information



The unit is defined in the **Distance unit** parameter ($\Rightarrow \triangleq 165$).

Confirm distance

Navigation Setup → Confirm distance

Description Specify, whether the measured distance matches the real distance.

Depending on the selection the device automatically sets the range of mapping.

Selection Manual map

- Distance ok
- Distance unknown
- Distance too small
- Distance too big
- Tank empty
- Delete map

Distance unknown **Factory setting**

Visibility depends on order options or device settings

Additional information

Meaning of the options

Manual map

To be selected if the range of mapping is to be defined manually in the **Mapping end point** parameter ($\Rightarrow \implies 177$). In this case it is not necessary to confirm the distance.

■ Distance ok

To be selected if the measured distance matches the actual distance. The device performs a mapping.

■ Distance unknown

To be selected if the actual distance is unknown. A mapping can not be performed in this case.

■ Distance too small

To be selected if the measured distance is smaller than the actual distance. The device searches for the next echo and returns to the **Confirm distance** parameter. The distance is recalculated and displayed. The comparison must be repeated until the displayed distance matches the actual distance. After this, the recording of the map can be started by selecting **Distance ok**.

■ Distance too big ¹¹⁾

To be selected if the measured distance exceeds the actual distance. The device adjusts the signal evaluation and returns to the **Confirm distance** parameter. The distance is recalculated and displayed. The comparison must be repeated until the displayed distance matches the actual distance. After this, the recording of the map can be started by selecting **Distance ok**.

Tank empty

To be selected if the tank is completely empty. The device records a mapping covering the complete measuring range.

Factory map

To be selected if the present mapping curve (if one exists) is to be deleted. The device returns to the **Confirm distance** parameter and a new mapping can be recorded.

- When operating via the display module, the measured distance is displayed together with this parameter for reference purposes.
- For interface measurements the distance always refers to the toatal level (not the interface level).
- If the teaching procedure with the **Distance too small** option or the **Distance too big** option is quit before the distance has been confirmed, a map is **not** recorded and the teaching procedure is reset after 60 s.
- For FMP54 with gas phase compensation (product structure: feature 540 "Application Package", option EF or EG) a map must **not** be recorded.

Present mapping

Navigation

 \square Setup \rightarrow Present mapping

Description

Indicates up to which distance a mapping has already been recorded.

¹¹⁾ Only available for "Expert \rightarrow Sensor \rightarrow Echo tracking \rightarrow **Evaluation mode** parameter" = "Short time history" or "Long time history"

Mapping end point

Prerequisite Confirm distance (→ 🗎 175) = Manual map or Distance too small

Description Specify new end of the mapping.

User entry 0 to 200 000.0 m

Factory setting 0.1 m

Additional information This parameter defines up to which distance the new mapping is to be recorded. The

distance is measured from the reference point, i.e. from the lower edge of the mounting

flange or the threaded connection.

For reference purposes the **Present mapping** parameter ($\rightarrow \triangleq 176$) is displayed together with this parameter. It indicates up to which distance a mapping has already

been recorded.

Record map

Prerequisite Confirm distance (→ 🗎 175) = Manual map or Distance too small

Description Start recording of the map.

Selection • No

Record mapDelete map

Factory setting No

Additional information Meaning of the options

No

The map is not recorded.

Record map

The map is recorded. After the recording is completed, the new measured distance and the new mapping range appear on the display. When operating via the local display, these values must be confirmed by pressing \square .

■ Delete map

The mapping (if one exists) is deleted and the device displays the recalculated measured distance and the mapping range. When operating via the local display, these values must be confirmed by pressing \square .

17.3.1 "Mapping" wizard

- The **Mapping** wizard is only available when operating via the local display. When operating via an operating tool, all parameters concerning the mapping are located directly in the **Setup** menu (→ ≅ 165).
- In the **Mapping** wizard two parameters are displayed simultaneously on the display module at any one time. The upper parameter can be edited, whereas the lower parameter is displayed for reference purposes only.

Navigation

■ Setup → Mapping

Confirm distance		
Navigation	Setup → Mapping → Confirm distance	
Description	→ 🖺 175	
Mapping end point		â
Navigation	Setup → Mapping → Mapping end point	
Description	→ 🖺 177	
Record map		â
Navigation	Setup → Mapping → Record map	
Description	→ 🖺 177	
Distance		
Navigation	Setup → Mapping → Distance	
Description	→ 🖺 170	

17.3.2 "Analog input 1 to 5" submenu

There is an **Analog inputs** submenu for every AI block of the device. The AI block is used to configure the measured value transmission to the bus.

Only the most basic properties of the AI block can be configured in this submenu. For a detailed configuration of the AI blocks refer to the **Expert** menu.

Navigation $\blacksquare \blacksquare$ Setup \rightarrow Analog inputs \rightarrow Analog input 1 to 5

Block tag		
Navigation	Setup → Analog inputs → Analog input 1 to 7 → Block tag	
Description	Defined to be unique throughout the control system at one plant site. The tag may be changed using the FB_Tag service.	
Factory setting		
Channel		
Navigation		
Description	Use this function to select the input value that should be processed in the Analog Input function block.	
Selection	Uninitialized Level linearized Absolute echo amplitude Absolute EOP amplitude Absolute interface amplitude Distance Electronic temperature EOP shift Interface linearized Interface distance Measured capacitance Relative echo amplitude Relative interface amplitude Relative interface amplitude Terminal voltage Thickness upper layer Calculated DC value Analog output adv. diagnostics 2 Analog output adv. diagnostics 1	

Uninitialized

Factory setting

^{*} Visibility depends on order options or device settings

Process Value Filter Time

Navigation Setup \rightarrow Analog input 1 to 7 \rightarrow Process Value Filter Time

Description Use this function to enter the filter time specification for the filtering of the unconverted

input value (PV).

User entry Positive floating-point number

Factory setting 0 s

Additional information Factory setting

If the value 0 s is entered, filtering will not be performed.

17.3.3 "Advanced setup" submenu

Navigation \square Setup \rightarrow Advanced setup

Locking status

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Locking status

Description Indicates the write protection with the highest priority that is currently active.

User interface ■ Hardware locked

Temporarily locked

Additional information

Meaning and priorities of the types of write protection

■ Hardware locked (priority 1)

The DIP switch for hardware locking is activated on the main electronics module. This locks write access to the parameters.

SIL locked (priority 2)

The SIL mode is activated. Writing access to the relevant parameters is denied.

WHG locked (priority 3)

The WHG mode is activated. Writing access to the relevant parameters is denied.

Temporarily locked (priority 4)

Write access to the parameters is temporarily locked on account of internal processes in progress in the device (e.g. data upload/download, reset etc.). The parameters can be modified as soon as the processes are complete.

On the display module, the a-symbol appears in front of parameters that cannot be modified since they are write-protected.

Access status tooling

Navigation \square Setup \rightarrow Advanced setup \rightarrow Access status tooling

Description Shows the access authorization to the parameters via the operating tool.

Additional information The access authorization can be changed via the **Enter access code** parameter $(\Rightarrow \triangleq 182)$.

If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the **Locking status** parameter ($\rightarrow \implies 181$).

Access status display

Navigation extstyle extstyle

Prerequisite The device has a local display.

Description

Indicates access authorization to parameters via local display.

Additional information

- The access authorization can be changed via the **Enter access code** parameter $(\rightarrow \stackrel{\triangle}{=} 182)$.
- If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the **Locking status** parameter ($\rightarrow \implies 181$).

Enter access code

Navigation

Description

Enter access code to disable write protection of parameters.

User entry

0 to 9999

Additional information

- If an incorrect access code is entered, the user retains his current access authorization.
- The write protection affects all parameters marked with the not symbol in this document. On the local display, the not symbol in front of a parameter indicates that the parameter is write-protected.
- If no key is pressed for 10 min, or the user switches from the navigation and editing mode back to the measured value display mode, the device automatically locks the writeprotected parameters after another 60 s.
- Please contact your Endress+Hauser Sales Center if you lose your access code.

"Level" submenu

The **Level** submenu ($\rightarrow \triangleq 183$) is only visible for **Operating mode** ($\rightarrow \triangleq 165$) = **Level**

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Level

Medium type

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Level \rightarrow Medium type

Description Specify type of medium.

User interface • Liquid

Solid

Factory setting FMP50, FMP51, FMP52, FMP53, FMP54, FMP55: Liquid

Additional information The Solid option is only available for Operating mode (→ 🗎 165) = Level

This parameter determines the value of several other parameters and strongly influences the complete signal evaluation. Therefore, it is strongly recommended **not to change** the factory setting.

Medium property

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Level \rightarrow Medium property

Prerequisite • Operating mode (\rightarrow 🗎 165) = Level

■ EOP level evaluation ≠ Fix DC

Description Specify relative dielectric constant ε_r of the medium.

Selection ■ Unknown

DC 1.4 ... 1.6DC 1.6 ... 1.9

■ DC 1.6 ... 1.9
■ DC 1.9 ... 2.5

■ DC 2.5 ... 4

■ DC 2.5 ... 9

■ DC 7 ... 15

■ DC > 15

Factory setting Dependent on Medium type ($\rightarrow \triangleq 183$) and Medium group ($\rightarrow \triangleq 166$).

Additional information

Dependency on "Medium type" and "Medium group"

Medium type (→ 🗎 183)	Medium group (→ 🖺 166)	Medium property	
Solid		Unknown	
Liquid	Water based (DC >= 4)	DC 4 7	
	Others	Unknown	

- For dielectric constants (DC values) of many media commonly used in various industries refer to:
 - the Endress+Hauser DC manual (CP01076F)
 - the Endress+Hauser "DC Values App" (available for Android and iOS)
- For **EOP level evaluation** = **Fix DC**, the exact dielectric constant has to be entered into the **DC value** parameter (→ 🖺 173). Therefore, the **Medium property** parameter is not available in this case.

Process property	
------------------	--

Navigation

Description

Specify typical rate of level change.

Selection

For "Medium type" = "Liquid"

- Very fast > 10 m (400 in)/min
- Fast > 1 m (40 in)/min
- Standard < 1 m (40in) /min
- \blacksquare Medium < 10 cm (4in) /min
- Slow < 1 cm (0.4in) /min
- No filter / test

For "Medium type" = "Solid"

- Very fast > 100 m (333 ft) /h
- Fast > 10 m (33 ft) /h
- Standard < 10 m (33 ft) /h
- Medium < 1 m (3ft) /h
- Slow < 0.1 m (0.3ft) /h
- No filter / test

Factory setting

Standard < 1 m (40in) /min

Additional information

The device adjusts the signal evaluation filters and the damping of the output signal to the typical rate of level change defined in this parameter:

For "Operating mode" = "Level" and "Medium type" = "Liquid"

Process property	Step response time / s
Very fast > 10 m (400 in)/min	5
Fast > 1 m (40 in)/min	5
Standard < 1 m (40in) /min	14
Medium < 10 cm (4in) /min	39
Slow < 1 cm (0.4in) /min	76
No filter / test	< 1

For "Operating mode" = "Level" and "Medium type" = "Solid"

Process property	Step response time / s	
Very fast > 100 m (333 ft) /h	37	
Fast > 10 m (33 ft) /h	37	
Standard < 10 m (33 ft) /h	74	
Medium < 1 m (3ft) /h	146	
Slow < 0.1 m (0.3ft) /h	290	
No filter / test	< 1	

For "Operating mode" = "Interface" or "Interface with capacitance"

Process property	Step response time / s	
Very fast > 10 m (400 in)/min	5	
Fast > 1 m (40 in)/min	5	
Standard < 1 m (40in) /min	23	
Medium < 10 cm (4in) /min	47	
Slow < 1 cm (0.4in) /min	81	
No filter / test	2.2	

Advanced process conditions

Prerequisite

Navigation

Operating mode ($\rightarrow \triangleq 165$) = Level

Description

Specify additional process conditions (if required).

Selection

- None
- Oil/Water condensate
- Probe near tank bottom
- Build up
- Foam (>5cm/0,16ft)

Factory setting

None

Additional information

Meaning of the options

Oil/Water condensate (only Medium type = Liquid)

Makes sure that in the case of two-phase media only the total level is detected (example: oil/condensate application).

■ Probe near tank bottom (only for Medium type = Liquid)

Improves the empty detection, especially if the probe is mounted close to the tank bottom.

Build up

Enables a safe empty-detection even if the end-of-probe signal has shifted due to build-up.

• Foam (>5cm/0,16ft) (only for Medium type = Liquid)

Optimizes the signal evaluation in applications with foam formation. \\

Level unit

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Level \rightarrow Level unit

Description Select level unit.

Selection $SI \ units$ $US \ units$ $\bullet \ \%$

■ mm

Factory setting %

Additional information The level unit may differ from the distance unit defined in the **Distance unit** parameter $(\rightarrow \implies 165)$:

- The unit defined in the Distance unit parameter is used for the basic calibration (Empty calibration (→ 167) and Full calibration (→ 168).
- The unit defined in the **Level unit** parameter is used to display the (unlinearized) level.

Blocking distance

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Level \rightarrow Blocking distance

Description Specify upper blocking distance UB.

User entry 0 to 200 m

Factory setting ■ For coax probes: 0 mm (0 in)

• For rod and rope probes up to 8 m (26 ft): 200 mm (8 in)

• For rod and rope probes above 8 m (26 ft): 0.025 * Sondenlänge

For FMP51/FMP52/FMP54 with the **Interface measurement** application package $^{12)}$ and for FMP55:

100 mm (3.9 in) for all antenna types

Additional information

Signals in the upper blocking distance are only evaluated if they have been outside the blocking distance when the device was switched on and move into the blocking distance due to a level change during operation. Signals which are already in the blocking distance when the device is switched on, are ignored.


This behavior is only valid if the following two conditions are met:

- Expert → Sensor → Echo tracking → Evaluation mode = Short time history or Long time history)
- Expert → Sensor → Gas phase compensation → GPC mode= On, Without correction or External correction

If one of these conditions is not met, signals in the blocking distance will always be ignored.

If required, a different behavior for signals in the blocking distance can be defined by the Endress+Hauser service.

¹²⁾ Ordering feature 540 "Application Package", option EB "Interface measurement"



■ 48 Blocking distance (UB) for liquid measurements

Level correction

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Level \rightarrow Level correction

Description Specify level correction (if required).

User entry -200 000.0 to 200 000.0 %

Factory setting 0.0 %

Additional information The value specified in this parameter is added to the measured level (before linearization).

"Interface" submenu

Navigation $\blacksquare \blacksquare$ Setup \rightarrow Advanced setup \rightarrow Interface

Process property

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Interface \rightarrow Process property

Description Specify typical rate of change for the interface position.

Selection ■ Fast > 1 m (40 in)/min

Standard < 1 m (40in) /min
 Medium < 10 cm (4in) /min
 Slow < 1 cm (0.4in) /min

■ No filter / test

Factory setting Standard < 1 m (40in) /min

Additional information

The device adjusts the signal evaluation filters and the damping of the output signal to the typical rate of level change defined in this parameter:

Process property	Step response time / s	
Fast > 1 m (40 in)/min	5	
Standard < 1 m (40in) /min	15	
Medium < 10 cm (4in) /min	40	
Slow < 1 cm (0.4in) /min	74	
No filter / test	2.2	

DC value lower medium	
-----------------------	--

Navigation Setup \rightarrow Advanced setup \rightarrow Interface \rightarrow DC value lower medium

Prerequisite Operating mode (→ 🖺 165) = Interface or Interface with capacitance

Description Specify the relative dielectric ocnstant ε_r of the lower medium.

User entry 1 to 100

Factory setting 80.0

Additional information

- For dielectric constants (DC values) of many media commonly used in various industries refer to:
 - the Endress+Hauser DC manual (CP01076F)
 - the Endress+Hauser "DC Values App" (available for Android and iOS)

The factory setting, ε_r = 80, is valid for water at 20 °C (68 °F).

188

Level unit

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Interface \rightarrow Level unit

Description Select level unit.

Selection SI units US units

%ftmin

■ mm

Factory setting %

Additional information The level unit may differ from the distance unit defined in the **Distance unit** parameter

(→ 🖺 165):

■ The unit defined in the **Distance unit** parameter is used for the basic calibration (**Empty calibration** ($\rightarrow \boxminus 167$) and **Full calibration** ($\rightarrow \boxminus 168$).

■ The unit defined in the **Level unit** parameter is used to display the (unlinearized) level and interface position.

Blocking distance

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Interface \rightarrow Blocking distance

Description Specify upper blocking distance UB.

User entry 0 to 200 m

Factory setting ■ For coax probes: 100 mm (3.9 in)

• For rod and rope probes up to 8 m (26 ft): 200 mm (8 in)


• For rod and rope probes above 8 m (26 ft): 0.025 * length of probe

Additional information

Echoes from within the blocking distance are not taken into account in the signal evaluation. The upper blocking distance is used

• to suppress interference echoes at the top end of the probe.

• to suppress the echo of the total level in the case of flooded bypasses.



A001322

- 1 Suppression of interference echoes at the top end of the probe.
- 2 Suppression of the level signal in case of a flooded bypass.
- UB Upper blocking distance

Level correction	
------------------	--

Navigation $\blacksquare \blacksquare$ Setup \rightarrow Advanced setup \rightarrow Interface \rightarrow Level correction

Description Specify level correction (if required).

User entry -200 000.0 to 200 000.0 %

Factory setting 0.0 %

Additional information The value specified in this parameter is added to the measured total and interface levels

(before linearization).

Manual thickness upper layer

Navigation \square Setup \rightarrow Advanced setup \rightarrow Interface \rightarrow Manual thickness upper layer


Description Specify the manually determined interface thickness UP (i.e. the thickness of the upper

medium).

User entry 0 to 200 m

Factory setting 0 m

Additional information



UP Interface thickness (= thickness of upper medium)

On the local display, the measured interface thickness is indicated together with the manual interface thickness. By comparing these two values the device can automatically adjust the dielectric constant of the upper medium.

Measured thickness u	ipper layer	
Navigation		
Description	Displays the measured interface thickness. (Thickness UP of the upper medium).	
DC value		
Navigation		
Description	Displays relatvie dielectric constant $\epsilon_{\rm r}$ of the upper medium (DC $_{\!1})$ before correction.	
Calculated DC value		
Navigation		
Description	Displays calculated (i.e. corrected) relative dielectric constant $\epsilon_{\rm r}$ (DC1) of the upper medium.	

Use calculated DC value		
Navigation		
Description	Specify whether the calculated dielectric constant is to be used.	
Selection	Save and exitCancel and exit	
Factory setting	Cancel and exit	

Additional information

Meaning of the options

Save and exit

The calculated constant is assumed to be the correct one.

Cancel and exit

The calculated dielectric constant is rejected; the previous dielectric constant remains active.

On the local display, the **Calculated DC value** parameter (\Rightarrow \triangleq 191) is displayed together with this parameter.


192

"Automatic DC calculation" wizard

- The **Automatic DC calculation** wizard is only available when operating via the local display. When operating via an operating tool, all parameters concerning the automatic DC calculation are located directly in the **Interface** submenu (→ 🖺 188)
- In the **Automatic DC calculation** wizard two parameters are displayed simultaneously on the display module at any one time. The upper parameter can be edited, whereas the lower parameter is displayed for reference purposes only.

Manual thickness upper la	ayer		
Navigation		Setup \rightarrow Advanced setup \rightarrow Interface \rightarrow Automatic DC calculation \rightarrow Manual thickness upper layer	
Description	→ 🖺	190	
DC value			A
Navigation		$Setup \to Advanced \ setup \to Interface \to Automatic \ DC \ calculation \to DC \ value$	
Description	→ 🖺	191	
Use calculated DC value			
Navigation		Setup \rightarrow Advanced setup \rightarrow Interface \rightarrow Automatic DC calculation \rightarrow Use calculation DC value	ited
Description	→ 🖺	192	

"Linearization" submenu




€ 49 Linearization: Transformation of the level and (if relevant) the interface height into a volume or weight; the transformation is dependent on the shape of the vessel.

- Selection of linearization type and unit 1
- Configuration of the linearization 2
- Α
- Linearization type ($\rightarrow \triangleq 197$) = None Linearization type ($\rightarrow \triangleq 197$) = Linear В
- Linearization type ($\rightarrow = 197$) = Table С
- D *Linearization type* ($\rightarrow \equiv 197$) = *Pyramid bottom*
- Linearization type ($\rightarrow \square 197$) = Conical bottom Ε
- F *Linearization type* ($\rightarrow \square 197$) = *Angled bottom*
- Linearization type ($\rightarrow = 197$) = Horizontal cylinder G
- *Linearization type* ($\rightarrow \equiv 197$) = *Sphere* Н
- For "Operating mode (→ 🖺 165)" = "Interface" or "Interface with capacitance": Interface before linearization Ι (measured in distance units)
- For "Operating mode ($\rightarrow \cong 165$)" = "Interface" or "Interface with capacitance": Interface after linearization (corresponds to volume or weight)
- Level before linearization (measured in distance units) L
- L' Level linearized ($\rightarrow riangleq 199$) (corresponds to volume or weight)
- Maximum value (→ 🖺 200) Μ
- Diameter ($\rightarrow \stackrel{\cdot}{\cong} 200$) d
- Intermediate height ($\rightarrow \equiv 201$) h

Structure of the submenu on the display module

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Linearization



Structure of the submenu in an operating tool (e.g. FieldCare)

Navigation \square Setup \rightarrow Advanced setup \rightarrow Linearization

► Linearization		
	Linearization type	→ 🖺 197
	Unit after linearization	→ 🖺 198
	Free text	→ 🖺 199
	Level linearized	→ 🖺 199
	Interface linearized	→ 🖺 200
	Maximum value	→ 🖺 200
	Diameter	→ 🖺 200
	Intermediate height	→ 🖺 201
	Table mode	→ 🖺 201
	Table number	→ 🖺 202
	Level	→ 🖺 203
	Level	→ 🖺 203
	Customer value	→ 🖺 203
	Activate table	→ 🖺 203

Description of parameters

Navigation

Linearization type

Navigation

Description Select linearization type.


Selection None

- Linear
- Table
- Pyramid bottom
- Conical bottom
- Angled bottom
- Horizontal cylinder
- Sphere

Factory setting

None

Additional information



■ 50 Linearization types

- Α None
- В Table
- С Pyramid bottom
- D Conical bottom
- Е Angled bottom
- F Sphere
- Horizontal cylinder

Endress+Hauser 197

A0021476

Meaning of the options

None

The level is transmitted in the level unit without linearization.

Linear

The output value (volume/weight) is directly proportional to the level L. This is valid, for example, for vertical cylinders. The following additional parameters have to be specified:

- Unit after linearization ($\rightarrow \equiv 198$)
- **Maximum value (→ 🗎 200)**: Maximum volume or weight

Table

The relationship between the measured level L and the output value (volume/weight) is given by a linearization table consisting of up to 32 pairs of values "level - volume" or "level - weight", respectively. The following additional parameters have to be specified:

- Unit after linearization (→ 🗎 198)
- Table mode (→ 🗎 201)
- For each table point: **Level** (\rightarrow $\stackrel{\triangle}{=}$ 203)
- For each table point: **Customer value** (→ **203**)

Pyramid bottom

The output value corresponds to the volume or weight in a silo with pyramid bottom. The following additional parameters have to be specified:

- Unit after linearization (→ 🗎 198)
- **Maximum value** (→ **200**): Maximum volume or weight
- **Intermediate height (→ \Beta 201)**: The height of the pyramid

Conical bottom

The output value corresponds to the volume or weight in a tank with conical bottom. The following additional parameters have to be specified:

- Unit after linearization (→ 🖺 198)
- Maximum value (→ 🖺 200): Maximum volume or weight
- **Intermediate height (→ □ 201)**: The height of the conical part of the tank

Angled bottom

The output value corresponds to the volume or weight in a silo with an angled bottom. The following additional parameters have to be specified:

- Unit after linearization (→ 🖺 198)
- **Maximum value (→ 🖺 200)**: Maximum volume or weight
- **Intermediate height (→ □ 201)**: Height of the angled bottom

Horizontal cylinder

The output value corresponds to the volume or weight in a horizontal cylinder. The following additional parameters have to be specified:

- **Maximum value (→ 🖺 200)**: Maximum volume or weight

Sphere

The output value corresponds to the volume or weight in a spherical tank. The following additional parameters have to be specified:

- Unit after linearization (→ 🗎 198)
- Maximum value (→ 🖺 200): Maximum volume or weight
- Diameter (→ 🖺 200)

Unit after linearization

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Unit after linearization

Prerequisite Linearization type ($\rightarrow \triangle 197$) $\neq \text{None}$

Description Select unit of the lineaized value.

198

SelectionSI unitsUS unitsImperial units■ STon■ lbimpGal

UsGal

ft³

- kg ■ cm³
- dm³
- m³
 hl

■ t

- h
- 1 ■ %

Custom-specific units

Free text

Factory setting %

Additional information The selected unit is only used to be indicated on the display. The measured value is **not** transformed according to the selected unit.

It is also possible to configure a distance-to-distance linearization, i.e. a transformation from the level unit to a different distance unit. To do so, select the **Linear** linearization mode. In order to define the new level unit, select the **Free text** option in the **Unit after linearization** parameter and enter the required unit into the **Free text** parameter ($\rightarrow \implies 199$).

Free text

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Free text

Prerequisite Unit after linearization (→ 🗎 198) = Free text

Description Enter unit symbol.

User entry Up to 32 alphanumerical characters (letters, numbers, special characters)

Factory setting Free text

Level linearized

Navigation Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Level linearized

Description Displays linearized level.

Additional information The unit is defined by the **Unit after linearization** parameter $\rightarrow \triangleq 198$.

• For interface measurements, this parameter always refers to the total level.

Interface linearized		
Navigation		
Prerequisite	Operating mode (→ 🗎 165) = Interface or Interface with capacitance	
Description	Displays the linearized interface height.	
Additional information	The unit is defined in the Unit after linearization parameter $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $	

Maximum value		
Navigation		
Prerequisite	Linearization type (→ 🗎 197) has one of the following values: ■ Linear ■ Pyramid bottom ■ Conical bottom ■ Angled bottom ■ Horizontal cylinder ■ Sphere	
User entry	-50 000.0 to 50 000.0 %	
Factory setting	100.0 %	
Diameter		Ê
Navigation		
Prerequisite	Linearization type (→ 🗎 197) has one of the following values:Horizontal cylinderSphere	
User entry	0 to 9 999.999 m	

Additional information The unit is defined in the **Distance unit** parameter ($\Rightarrow \triangleq 165$).

2 m

Factory setting

Intermediate height

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Intermediate height


Prerequisite Linearization type (\rightarrow $\stackrel{\triangle}{=}$ 197) has one of the following values:

Pyramid bottomConical bottomAngled bottom

User entry 0 to 200 m

Factory setting 0 m

Additional information



H Intermediate height

The unit is defined in the **Distance unit** parameter ($\rightarrow \equiv 165$).

Table mode

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Table mode

Prerequisite Linearization type (→ 🖺 197) = Table

Description Select editing mode of the linearization table.

Selection • Manual

Semiautomatic *
Clear table
Sort table

Factory setting Manual

^{*} Visibility depends on order options or device settings

Additional information

Meaning of the options

Manual

The level and the associated linearized value are entered manually for each linearization point.

Semiautomatic

The level is measured by the device for each linearization point. The associated linearized value is entered manually.

Clear table

Deletes the existing linearization table.

Sort table

Rearranges the linerization points into an ascending order.

Conditions the linearization table must meet:

- The table may consist of up to 32 pairs of values "Level Linearized Value".
- The table must be monotonic (monotonically increasing or decreasing).
- The first linearization point must refer to the minimum level.
- The last linearization point must refer to the maximum level.
- Before entering a linearization table, the values for **Empty calibration** ($\rightarrow \triangle 167$) and **Full calibration** ($\rightarrow \triangle 168$) must be set correctly.

If values of the table need to be changed after the full or empty calibration have been changed, a correct evaluation is only ensured if the existing table is deleted and the complete table is entered again. To do so delete the existing table (**Table mode** $(\rightarrow \boxtimes 201)$ = **Clear table**). Then enter a new table.

How to enter the table

■ Via FieldCare

The table points can be entered via the **Table number** (\rightarrow \cong **202**), **Level** (\rightarrow \cong **203**) and **Customer value** (\rightarrow \cong **203**) parameters. As an alternative, the graphic table editor may be used: Device Operation \rightarrow Device Functions \rightarrow Additional Functions \rightarrow Linearization (Online/Offline)

Via local display

Select the **Edit table** submenu to call up the graphic table editor. The table is displayed and can be edited line by line.

The factory setting for the level unit is "%". If you want to enter the linearization table in physical units, you must select the appropriate unit in the **Level unit** parameter $(\rightarrow \ \)$ 186) beforehand.

Table number			
Navigation		Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Table number	
Prerequisite	Linea	Linearization type (→ 🖺 197) = Table	
Description	Selec	Select table point you are going to enter or change.	
User entry	1 to 3	1 to 32	
Factory setting	1		

202

Level (Manual)

Navigation \square Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Level

Prerequisite ■ Linearization type (→ 🖺 197) = Table

■ Table mode (→ 🖺 201) = Manual

Description Enter level value of the table point (value before linearization).

User entry Signed floating-point number

Factory setting 0 %

Level (Semiautomatic)

Navigation \square Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Level

Prerequisite ■ Linearization type (→ 🗎 197) = Table

■ Table mode (→ 🖹 201) = Semiautomatic

Description Displays measured level (value before linearization). This value is transmitted to the table.

Customer value

Navigation \square Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Customer value

Prerequisite Linearization type (→ 🖺 197) = Table

Description Enter linearized value for the table point.

User entry Signed floating-point number

Factory setting 0 %

Activate table

Navigation $\blacksquare \blacksquare$ Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Activate table

Prerequisite Linearization type ($\rightarrow = 197$) = Table

Description Activate (enable) or deactivate (disable) the linearization table.

Selection • Disable

■ Enable

Factory setting

Disable

Additional information

Meaning of the options

Disable

The measured level is not linearized.

If **Linearization type** (\rightarrow \rightleftharpoons **197)** = **Table** at the same time, the device issues error message F435.

■ Enable

The measured level is linearized according to the table.

When editing the table, the **Activate table** parameter is automatically reset to **Disable** and must be reset to **Enable** after the table has been entered.

204

"Safety settings" submenu

Navigation $\blacksquare \blacksquare$ Setup \rightarrow Advanced setup \rightarrow Safety settings

Output echo lost

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Safety settings \rightarrow Output echo lost

Description Output signal in case of a lost echo.

Selection • Last valid value

Ramp at echo lostValue echo lost

Alarm

Factory setting Last valid value

Additional information Meaning of the options

Last valid value

The last valid value is kept in the case of a lost echo.

Ramp at echo lost ¹³⁾

In the case of a lost echo the output value is continously shifted towards 0% or 100%. The slope of the ramp is defined in the **Ramp at echo lost** parameter ($\rightarrow \stackrel{\triangle}{=} 206$).

Value echo lost ¹³⁾

In the case of a lost echo the output assumes the value defined in the **Value echo lost** parameter ($\Rightarrow \triangleq 205$).

Alarm

In the case of a lost echo the device generates an alarm; see the Failure mode parameter

Value echo lost

Navigation $\blacksquare \square$ Setup \rightarrow Advanced setup \rightarrow Safety settings \rightarrow Value echo lost

Prerequisite Output echo lost $(\rightarrow \triangle 205) =$ Value echo lost

Description Output value in case of a lost echo

User entry 0 to 200 000.0 %

Factory setting 0.0 %

Additional information Use the unit which has been defined for the measured value output:

■ without linearization: **Level unit** (→ 🖺 186)

¹³⁾ Only visible if "Linearization type ($\rightarrow = 197$)" = "None"

Ramp at echo lost

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Safety settings \rightarrow Ramp at echo lost

Prerequisite Output echo lost (→ 🖺 205) = Ramp at echo lost


Description Slope of the ramp in the case of a lost echo

User entry Signed floating-point number

Α

Factory setting 0.0 %/min

Additional information



- *B* Ramp at echo lost ($\rightarrow \triangle 206$) (positive value)

Delay time echo lost

- *C* Ramp at echo lost ($\Rightarrow \triangleq 206$) (negative value)
- The unit for the slope of the ramp is "percentage of the measuring range per minute" (%/min).
- For a negative slope of the ramp: The measured value is continuously decreased until it reaches 0%.
- For a positive slope of the ramp: The measured value is continuously increased until it reaches 100%.

Blocking distance

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Safety settings \rightarrow Blocking distance

Description Specify upper blocking distance UB.

User entry 0 to 200 m

Factory setting ■ For coax probes: 0 mm (0 in)

• For rod and rope probes up to 8 m (26 ft): 200 mm (8 in)

■ For rod and rope probes above 8 m (26 ft): 0.025 * Sondenlänge

For FMP51/FMP52/FMP54 with the **Interface measurement** application package ¹⁴⁾ and for FMP55:

100 mm (3.9 in) for all antenna types


Additional information

Signals in the upper blocking distance are only evaluated if they have been outside the blocking distance when the device was switched on and move into the blocking distance due to a level change during operation. Signals which are already in the blocking distance when the device is switched on, are ignored.

- **T**
 - This behavior is only valid if the following two conditions are met:
 - Expert → Sensor → Echo tracking → Evaluation mode = Short time history or Long time history)
 - Expert → Sensor → Gas phase compensation → GPC mode= On, Without correction or External correction

If one of these conditions is not met, signals in the blocking distance will always be ignored.

If required, a different behavior for signals in the blocking distance can be defined by the Endress+Hauser service.



■ 51 Blocking distance (UB) for liquid measurements

¹⁴⁾ Ordering feature 540 "Application Package", option EB "Interface measurement"

Probe grounded

"Probe settings" submenu

The **Probe settings** submenu helps to ensure that the end of probe signal within the envelope curve is correctly assigned by the evaluation algorithm. The assignment is correct if the length of probe indicated by the device matches the acutal length of the probe. The automatic probe length correction can only be performed if the probe is installed in the vessel and is completely uncovered (no medium). For partially filled vessels and if the probe length is known, select **Confirm probe length** (\Rightarrow 209) = **Manual input** in order to enter the value manually.

- If a mapping (interference echo suppression) has been recorded after shortening the probe, it is no longer possible to perform an automatic probe length correction. In this case there are two options:
 - Delete the map using the **Record map** parameter ($\rightarrow \boxminus 177$) before performing the automatic probe length correction. After the probe length correction, a new map can be recorded using the **Record map** parameter ($\rightarrow \boxminus 177$).
 - Alternative: Select **Confirm probe length (→ 🖺 209) = Manual input** and enter the probe length manually into the **Present probe length** parameter → 🖺 208.
- An automatic probe length correction is only possible after the correct option has been selected in the **Probe grounded** parameter ($\rightarrow \triangleq 208$).

Navigation $\blacksquare \blacksquare$ Setup \rightarrow Advanced setup \rightarrow Probe settings

-		
Navigation		
Prerequisite	Operating mode (→ 🖺 165) = Level	
Description	Specify whether the probe is grounded.	
Selection	■ No ■ Yes	
Factory setting	No	
Present probe length		
Navigation		
Description	 In most cases: Displays the length of the probe according to the currently measured end-of-probe signal. For Confirm probe length (→ ≜ 209) = Manual input: Enter actual length of probe. 	
User entry	0 to 200 m	
Factory setting	4 m	

Confirm probe length **Navigation** Setup \rightarrow Advanced setup \rightarrow Probe settings \rightarrow Confirm probe length

Select, whether the value displayed in the **Present probe length** parameter $\rightarrow \triangleq 208$ matches the actual length of the probe. Based on this input, the device performs a probe

length correction.

Selection ■ Probe length OK

- Probe length too small
- Probe length too big ■ Probe covered
- Manual input
- Probe length unknown

Probe length OK **Factory setting**

Additional information

Description

Meaning of the options

Probe length OK

To be selected if the indicated length is correct. An adjustment is not required. The device quits the sequence.

Probe length too small

To be selected if the displayed length is smaller than the actual length of the probe. A different end of probe signal is allocated and the newly calculated length is displayed in the **Present probe length** parameter $\rightarrow \implies$ 208. This procedure has to be repeated until the displayed value matches the actual length of the probe.

■ Probe length too big

To be selected if the displayed length is bigger than the actual length of the probe. A different end of probe signal is allocated and the newly calculated length is indicated in the **Present probe length** parameter $\rightarrow \triangleq 208$. This procedure has to be repeated until the displayed value matches the actual length of the probe.

■ Probe covered

To be selected if the probe is (partially or completely) covered. A probe length correction is impossible in this case. The device guits the sequence.

Manual input

To be selected if no automatic probe length correction is to be performed. Instead, the actual length of the probe must be entered manually into the **Present probe length** parameter $\rightarrow \triangleq 208^{15}$.

Probe length unknown

To be selected if the acutal length of the probe is unknown. A probe length correction is impossible in this case and the device guits the sequence.

When operated via FieldCare, the Manual input option needs not to be selected explicitly. In FieldCare the length of the probe can always be edited

"Probe length correction" wizard

The **Probe length correction** wizard is only available when operating via the local display. When operating via an operating tool, all parameters concerning the probe length correction are located directly in the **Probe settings** submenu ($\rightarrow \square$ 208).

Navigation

correction

Confirm probe length		
Navigation	Setup → Advanced setup → Probe settings → Probe length correction → probe length	Confirm
Description	→ 🖺 209	
Present probe length		
Navigation	Setup → Advanced setup → Probe settings → Probe length correction → probe length	Present
Description	→ 🖺 208	

"Switch output" submenu

Navigation $\blacksquare \blacksquare$ Setup \rightarrow Advanced setup \rightarrow Switch output

Switch output function

Navigation Setup \rightarrow Advanced setup \rightarrow Switch output \rightarrow Switch output function

Description Select function for switch output.

Selection • Off

■ On

Diagnostic behavior

■ Limit

Digital Output

Factory setting Off

Additional information Meaning of the options

Off

The output is always open (non-conductive).

On

The output is always closed (conductive).

Diagnostic behavior

The output is normally closed and is only opened if a diagnostic event is present. The **Assign diagnostic behavior** parameter ($\rightarrow \stackrel{\triangle}{=} 212$) determines for which type of event the output is opened.

Limit

The output is normally closed and is only opened if a measured variable exceeds or falls below a defined limit. The limit values are defined by the following parameters:

- Switch-on value (→ 🖺 213)
- Switch-off value (→

 214)
- Digital Output

The switching state of the output tracks the output value of a DI function block. The function block is selected in the **Assign status** parameter ($\rightarrow \stackrel{\triangle}{=} 211$).

The **Off** and **On** options can be used to simulate the switch output.

Assign status

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Switch output \rightarrow Assign status

Prerequisite Switch output function (→ 🖺 211) = Digital Output

¹⁶⁾ Ordering feature 020 "Power supply; Output", option B, E or G

Selection

- Off
- Digital output AD 1
- Digital output AD 2
- Digital output 1
- Digital output 2
- Digital output 3
- Digital output 4
- Digital output 5
- Digital output 6
- Digital output 7
- Digital output 8

Factory setting

Off

Additional information

The **Digital output AD 1** and **Digital output AD 2** options refer to the Advanced Diagnostic Blocks. A switch signal generated in these blocks can be transmitted via the switch output.

Assign limit

Navigation

Prerequisite

Switch output function ($\rightarrow \stackrel{\triangle}{=} 211$) = Limit

Selection

- Off
- Level linearized
- Distance
- Interface linearized *
- Interface distance *
- Thickness upper layer *
- Terminal voltage
- Electronic temperature
- Measured capacitance
- Relative echo amplitude
- Relative interface amplitude *
- Absolute echo amplitude
- Absolute interface amplitude *

Factory setting

Off

Assign diagnostic behavior

Navigation

Setup → Advanced setup → Switch output → Assign diagnostic behavior

Prerequisite

Switch output function (→ 🖺 211) = Diagnostic behavior

Description

Select diagnostic behavior for switch output.

212

^{*} Visibility depends on order options or device settings

Selection Alarm

Alarm or warning

Warning

Factory setting Alarm

Switch-on value

Navigation

Prerequisite Switch output function ($\rightarrow \stackrel{\triangle}{=} 211$) = Limit

Description Enter measured value for the switch-on point.

User entry Signed floating-point number


Factory setting

Additional information

The switching behavior depends on the relative position of the Switch-on value and Switch-off value parameters:

Switch-on value > Switch-off value


- The output is closed if the measured value is larger than **Switch-on value**.
- The output is opened if the measured value is smaller than **Switch-off value**.



- Switch-on value Α
- Switch-off value
- Output closed (conductive)
- Output opened (non-conductive)

Switch-on value < Switch-off value

- The output is closed if the measured value is smaller than **Switch-on value**.
- The output is opened if the measured value is larger than **Switch-off value**.



- A Switch-on value
- B Switch-off value
- C Output closed (conductive)
- D Output opened (non-conductive)

Switch-on delay	
9	

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Switch output \rightarrow Switch-on delay

Prerequisite • Switch output function (\Rightarrow \triangleq 211) = Limit

■ Assign limit (→ 🖺 212) ≠ Off

Description Define delay for the switch-on of status output.

User entry 0.0 to 100.0 s

Factory setting 0.0 s

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Switch output \rightarrow Switch-off value

Prerequisite Switch output function (→ 🖺 211) = Limit

Description Enter measured value for the switch-off point.

User entry Signed floating-point number

Factory setting 0

Additional information The switching behavior depends on the relative position of the **Switch-on value** and

Switch-off value parameters; description: see the Switch-on value parameter

Switch-off delay

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Switch output \rightarrow Switch-off delay

Prerequisite • Switch output function ($\rightarrow \stackrel{\triangle}{=} 211$) = Limit

■ Assign limit (→ 🖺 212) ≠ Off

Description Define delay for the switch-off of status output.

User entry 0.0 to 100.0 s

Factory setting 0.0 s

Failure mode

Navigation $\blacksquare \blacksquare$ Setup \rightarrow Advanced setup \rightarrow Switch output \rightarrow Failure mode

Prerequisite Switch output function (→ 🖺 211) = Limit or Digital Output

Description Define output behavior in alarm condition.

Selection • Actual status

OpenClosed

Factory setting Open

Additional information

Switch status

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Switch output \rightarrow Switch status

Description Shows the current switch output status.

Invert output signal

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Switch output \rightarrow Invert output signal

Description Invert the output signal.

Selection ■ No

Yes

Factory setting No

Additional information

Meaning of the options

No

The behavior of the switch output is as described above.

Yes

The states **Open** and **Closed** are inverted as compared to the description above.

"Display" submenu

The **Display** submenu is only visible if a display module is connected to the device.

Navigation

Language

Navigation

Description Set display language.

Selection ■ English

Deutsch

Français ■ Español

■ Italiano

Nederlands

Portuguesa

■ Polski

■ русский язык (Russian) *

Svenska

Türkçe

■ 中文 (Chinese) *

■ 日本語 (Japanese) *

■ 한국어 (Korean) *
■ Bahasa Indonesia *

■ tiếng Việt (Vietnamese) *

čeština (Czech)

Factory setting The language selected in feature 500 of the product structure.

If no language has been selected: English

Additional information

Format display

Navigation

Description Select how measured values are shown on the display.

Selection ■ 1 value, max. size

■ 1 bargraph + 1 value

■ 2 values

■ 1 value large + 2 values

4 values


Factory setting 1 value, max. size

Visibility depends on order options or device settings


Additional information




■ 52 "Format display" = "1 value, max. size"




■ 53 "Format display" = "1 bargraph + 1 value"



■ 54 "Format display" = "2 values"



🖪 55 "Format display" = "1 value large + 2 values"



■ 56 "Format display" = "4 values"

- The **Value 1 to 4 display** $\rightarrow \cong$ 219 parameters specify which measured values are shown on the display and in which order.
 - If more measured values are specified than the current display mode permits, the values alternate on the device display. The display time until the next change is configured in the **Display interval** parameter ($\rightarrow \implies 220$).

Value 1 to 4 display	T .	
Navigation		
Description	Select the measured value that is shown on the local display.	
Selection	 Level linearized Distance Interface linearized * 	

Thickness upper layer
Terminal voltage
Electronic temperature
Measured capacitance

■ Interface distance

Analog output adv. diagnostics 1Analog output adv. diagnostics 2

Analog output 1
Analog output 2
Analog output 3
Analog output 4
Analog output 5
Analog output 6

Analog output 6Analog output 7Analog output 8

Factory setting

For level measurements

■ Value 1 display: Level linearized

■ Value 2 display: Distance

■ Value 3 display: Current output 1

■ Value 4 display: None

For interface measurements and one current output

Value 1 display: Interface linearizedValue 2 display: Level linearized

- value 2 display. Level illiearized

Value 3 display: Thickness upper layer

■ Value 4 display: Current output 1

For interface measurements and two current outputs

Value 1 display: Interface linearized
 Value 2 display: Level linearized

■ Value 2 display: Level linearized

■ Value 3 display: Current output 1

■ Value 4 display: Current output 2

Decimal places 1 to 4

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Decimal places 1

Description Select the number of decimal places for the display value.

Visibility depends on order options or device settings

Selection ■ x

x.xx.xxx.xxx

x.xxxx

Factory setting x.xx

Additional information The setting does not affect the measuring or computational accuracy of the device.

Display interval

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Display interval

Description Set time measured values are shown on display if display alternates between values.

User entry 1 to 10 s

Factory setting 5 s

Additional information This parameter is only relevant if the number of selected measuring values exceeds the

number of values the selected display format can display simultaneously.

Display damping

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Display damping

Description Set display reaction time to fluctuations in the measured value.

User entry 0.0 to 999.9 s

Factory setting 0.0 s

Header

Navigation $\blacksquare \blacksquare$ Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Header


Description Select header contents on local display.

Selection ■ Device tag

• Free text

Factory setting Device tag

Additional information



1 Position of the header text on the display

Meaning of the options

Device tag

Is defined in the **Device tag** parameter

■ Free text

Is defined in the **Header text** parameter ($\Rightarrow \triangleq 221$)

Header text

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Header text

Prerequisite Header (→ 🗎 220) = Free text

Description Enter display header text.

Factory setting ------

Additional information The number of characters which can be displayed depends on the characters used.

Description Select decimal separator for displaying numerical values.

Selection • .

Separator

Navigation

■ ,

Factory setting .

Number format

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Number format

Description Choose number format for the display.

Selection • Decimal

• ft-in-1/16"

Endress+Hauser

Factory setting Decimal

Additional information The **ft-in-1/16"** option is only valid for distance units.

Decimal places menu

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Decimal places menu

Description Select number of decimal places for the representation of numbers within the operating

menu.

Selection ■ x

■ X.X

X.XXX.XXX

X.XXXX

Factory setting x.xxxx

Additional information • Is only valid for numbers in the operating menu (e.g. **Empty calibration**, **Full**

calibration), but not for the measured value display. The number of decimal places for the measured value display is defined in the **Decimal places 1 to 4** \Rightarrow \cong 219

parameters.

• The setting does not affect the accuracy of the measurement or the calculations.

Backlight

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Backlight

Prerequisite The device has the SD03 local display (with optical keys).

Description Switch the local display backlight on and off.

Selection • Disable

Enable

Factory setting Disable

Additional information Meaning of the options

Disable

Switches the backlight off.

Enable

Switches the backlight on.

Regardless of the setting in this parameter the backlight may be automatically switched off by the device if the supply voltage is too low.

Contrast display

Navigation

Description Adjust local display contrast setting to ambient conditions (e.g. lighting or reading angle).

20 to 80 % User entry

Factory setting Dependent on the display.

Additional information

Setting the contrast via push-buttons:
■ Darker: press the ⑤ ⑥ buttons simultaneously.

■ Brighter: press the 🕒 📵 buttons simultaneously.

"Configuration backup display" submenu

This submenu is only visible if a display module is connected to the device.

The configuration of the device can be saved to the display module at a certain point of time (backup). The saved configurateion can be restored to the device if required, e.g. in order to bring the device back into a defined state. The configuration can also be transferred to a different device of the same type using the display module.

Configurations can only be exchanged between devices which are in the same operating mode (see the **Operating mode** parameter ($\rightarrow \triangleq 165$)).

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Configuration backup display

Operating time	
Navigation	
Description	Indicates how long the device has been in operation.
Additional information	Maximum time 9 999 d (≈ 27 years)
Last backup	
Navigation	Setup → Advanced setup → Configuration backup display → Last backup
Description	Indicates when the last data backup was saved to the display module.

Configuration management

Description Select action for managing the device data in the display module.

Selection • Cancel

- Execute backup
- Restore
- Duplicate
- Compare
- Clear backup data
- Display incompatible

Factory setting Cancel

Additional information

Meaning of the options

Cancel

No action is executed and the user exits the parameter.

Execute backup

A backup copy of the current device configuration in the HistoROM (built-in in the device) is saved to the display module of the device.

Restore

The last backup copy of the device configuration is copied from the display module to the HistoROM of the device.

Duplicate

The transmitter configuration is duplicated to another device using the transmitter display module. The following parameters, which characterize the individual measuring point are **not** included in the transmitted configuration:

Medium type

Compare

The device configuration saved in the display module is compared to the current device configuration of the HistoROM. The result of this comparison is displayed in the **Comparison result** parameter ($\rightarrow \implies 225$).

Clear backup data

The backup copy of the device configuration is deleted from the display module of the device.

- While this action is in progress, the configuration cannot be edited via the local display and a message on the processing status appears on the display.
- If an existing backup is restored to a different device using the **Restore** option, it may occur that some device functionalities are no longer available. In some cases even a device reset will not restore the original status.

In order to transmit a configuration to a different device, the **Duplicate** option should always be used.

Backup state			
Navigation			
Description	Displays which backup action is currently in progress.		
Comparison result			
Navigation			
Description	Comparison between present device data and display backup.		

Additional information

Meaning of the display options

Settings identical

The current device configuration of the HistoROM is identical to the backup copy in the display module.

Settings not identical

The current device configuration of the HistoROM is not identical to the backup copy in the display module.

■ No backup available

There is no backup copy of the device configuration of the HistoROM in the display module.

Backup settings corrupt

The current device configuration of the HistoROM is corrupt or not compatible with the backup copy in the display module.

Check not done

The device configuration of the HistoROM has not yet been compared to the backup copy in the display module.

■ Dataset incompatible

The data sets are incompatible and can not be compared.

- To start the comparison, set **Configuration management** ($\rightarrow \triangleq 224$) = **Compare**.
- If the transmitter configuration has been duplicated from a different device by Configuration management (→ 🗎 224) = Duplicate, the new device configuration in the HistoROM is only partially identical to the configuration stored in the display module: Sensor specific properties (e.g. the mapping curve) are not duplicated. Thus, the result of the comparison will be Settings not identical.

"Administration" submenu

Navigation \square Setup \rightarrow Advanced setup \rightarrow Administration

Navigation Setup \rightarrow Advanced setup \rightarrow Administration \rightarrow Define access code

Description Define release code for write access to parameters.

User entry 0 to 9 999

Factory setting 0

Additional information

- If the factory setting is not changed or 0 is defined as the access code, the parameters are not write-protected and the configuration data of the device can then always be modified. The user is logged on in the *Maintenance* role.
- The write protection affects all parameters marked with the symbol in this document. On the local display, the symbol in front of a parameter indicates that the parameter is write-protected.
- Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the **Enter access code** parameter $(\rightarrow \implies 182)$.
- Please contact your Endress+Hauser Sales Center if you lose your access code.
- For display operation: The new access code is only valid after it has been confirmed in the **Confirm access code** parameter ($\rightarrow \cong 229$).

Device reset		
Device reset		(

Navigation \square Setup \rightarrow Advanced setup \rightarrow Administration \rightarrow Device reset

Selection • Cancel

To fieldbus defaults

■ To factory defaults

■ To delivery settings

Of customer settingsTo transducer defaults

Restart device

• Nestart devi

Factory setting Cancel

Additional information

Meaning of the options

Cancel

No action

■ To factory defaults

All parameters are reset to the order-code specific factory setting.

■ To delivery settings

All parameters are reset to the delivery setting. The delivery setting may differ from the factory default if customer specific settings have been ordered.

This option is only visible if customer specific settings have been ordered.

Of customer settings

All customer parameters are reset to their factory setting. Service parameters, however, remain unchanged.

■ To transducer defaults

Every measurment-related parameter is reset to its factory setting. Service parameters and communication-related parameters, however, remain unchanged.

Restart device

The restart resets every parameter which is stored in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.

"Define access code" wizard

0

Factory setting

The **Define access code** wizard is only available when operating via the local display. When operating via an operating tool, the **Define access code** parameter is located directly in the **Administration** submenu. The **Confirm access code** parameter is not available for operation via operating tool.

Navigation

 $\mathsf{Setup} \to \mathsf{Advanced} \ \mathsf{setup} \to \mathsf{Administration} \to \mathsf{Define} \ \mathsf{access}$ code

Define access code		a
Navigation		
Description	→ 🗎 227	
Confirm access code		a
Navigation	Setup → Advanced setup → Administration → Define access code → Confirm acces code	S
Description	Confirm the entered access code.	
User entry	0 to 9999	

17.4 "Diagnostics" menu

Actual diagnostics			
Navigation	□ Diagnostics → Actual diagnostics		
Description	Displays current diagnostic message.		
Additional information	The display consists of: Symbol for event behavior Code for diagnostic behavior Operating time of occurrence Event text		
	If several messages are active at the same time, the messages with the highest priority is displayed.		
	Information on what is causing the message, and remedy measures, can be viewed via the ① symbol on the display.		
Timestamp			
Navigation	□ Diagnostics → Timestamp		
Previous diagnostics			
Navigation	□ Diagnostics → Previous diagnostics		
Description	Displays the last diagnostic message which has been active before the current message.		
Additional information	The display consists of:		

Timestamp

Navigation \square Diagnostics \rightarrow Timestamp

Operating time from restart

Description Displays the time the device has been in operation since the last device restart.

Operating time

Navigation \Box Diagnostics \rightarrow Operating time

Description Indicates how long the device has been in operation.

Additional information *Maximum time*

9999 d (≈ 27 years)

17.4.1 "Diagnostic list" submenu

Navigation \square Diagnostics \rightarrow Diagnostic list

Diagnostics 1 to 5

Navigation \Box Diagnostics \rightarrow Diagnostic list \rightarrow Diagnostics 1

Description Display the current diagnostics messages with the highest to fifth-highest priority.

Additional information The display consists of:

- Symbol for event behaviorCode for diagnostic behavior
- Operating time of occurrence
- Event text

Timestamp 1 to 5

Navigation □ Diagnostics → Diagnostic list → Timestamp

17.4.2 "Event logbook" submenu



The **Event logbook** submenu is only available when operating via the local display. When operating via FieldCare, the event list can be displayed in the FieldCare function "Event List / HistoROM".

Navigation

■ Diagnostics → Event logbook

Filter options

Navigation

Selection

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

Factory setting

All

Additional information



- This parameter is only used for operation via the local display.
- The status signals are categorized according to NAMUR NE 107.

"Event list" submenu

The **Event list** submenu displays the history of past events of the category selected in the **Filter options** parameter ($\rightarrow \implies 233$). A maximum of 100 events are displayed in chronological order.

The following symbols indicate whether an event has occurred or has ended:

- ①: Event has occurred
- 🕒: Event has ended
- Information on what is causing the message, and remedy instructions, can be viewed via the ①-button.

Display format

- For event messages in category I: information event, event text, "recording event" symbol and time the event occurred
- For event messages in category F, M, C, S (status signal): diagnostics event, event text, "recording event" symbol and time the event occurred

Navigation \square Diagnostics \rightarrow Event logbook \rightarrow Event list

17.4.3 "Device information" submenu

Device tag			
Navigation		Diagnostics → Device information → Device tag	
		Diagnostics \rightarrow Device information \rightarrow Device tag	
Description	Ente	er tag for measuring point.	
Factory setting	FMP5x		
Serial number			
Navigation		Diagnostics → Device information → Serial number	
		Diagnostics \rightarrow Device information \rightarrow Serial number	
Additional information	i	Uses of the serial number ■ To identify the device quickly, e.g. when contacting Endress+Hauser. ■ To obtain specific information on the device using the Device Viewer:	

Firmware version		
Navigation	 □ Diagnostics → Device information → Firmware version □ Diagnostics → Device information → Firmware version 	
User interface	xx.yy.zz	
Additional information	For firmware versions differing only in the last two digits ("zz") there is no difference concerning functionality or operation.	

The serial number is also indicated on the nameplate.

www.endress.com/deviceviewer

Device name			
Navigation		Diagnostics \rightarrow Device information \rightarrow Device name	
		Diagnostics \rightarrow Device information \rightarrow Device name	
Order code			
Navigation		$Diagnostics \rightarrow Device\ information \rightarrow Order\ code$	
		Diagnostics \rightarrow Device information \rightarrow Order code	
Additional information	The order code is generated from the extended roder code, which defines all device features of the product structure. In contrast, the device features can not be read directly from the order code.		
Extended order code 1 to 3			
Navigation		Diagnostics \rightarrow Device information \rightarrow Extended order code 1	
		${\tt Diagnostics} \rightarrow {\tt Device} \ {\tt information} \rightarrow {\tt Extended} \ {\tt order} \ {\tt code} \ 1$	
Description	Display the three parts of the extended order code.		
Additional information	The extended order code indicates the version of all the features of the product structure and thus uniquely identifies the device.		

17.4.4 "Measured values" submenu

Navigation $\blacksquare \Box$ Diagnostics \rightarrow Measured values

Distance


Navigation

 \square Diagnostics \rightarrow Measured values \rightarrow Distance


Description

Displays the measured distance D_L between the reference point (lower edge of the flange or threaded connection) and the level.

Additional information



 \blacksquare 57 Distance for liquid measurements



■ 58 Distance for interface measurements

The unit is defined in the **Distance unit** parameter ($\rightarrow \triangleq 165$).

Level linearized

Navigation \blacksquare Diagnostics \rightarrow Measured values \rightarrow Level linearized

Description Displays linearized level.

Additional information The unit is defined by the **Unit after linearization** parameter $\rightarrow \triangleq 198$.

• For interface measurements, this parameter always refers to the total level.


Interface distance

Navigation \blacksquare Diagnostics \rightarrow Measured values \rightarrow Interface distance

Prerequisite Operating mode (→ 🖺 165) = Interface or Interface with capacitance

threaded connection) and the interface.

Additional information



A00132

The unit is defined in the **Distance unit** parameter ($\rightarrow \triangleq 165$).

Interface linearized

Navigation \blacksquare Diagnostics \rightarrow Measured values \rightarrow Interface linearized

Prerequisite Operating mode (→ 🖺 165) = Interface or Interface with capacitance

Description Displays the linearized interface height.

Additional information The unit is defined in the **Unit after linearization** parameter $\rightarrow \triangleq 198$.

Thickness upper layer

Navigation


Prerequisite

Operating mode (→ 🖺 165) = Interface or **Interface with capacitance**

Description

Displays the upper interface thickness (UP).

Additional information



UP Thickness upper layer

i

Terminal voltage 1

Navigation

□ Diagnostics → Measured values → Terminal voltage 1

17.4.5 "Analog input 1 to 5" submenu

There is an **Analog inputs** submenu for every AI block of the device. The AI block is used to configure the measured value transmission to the bus.

Only the most basic properties of the AI block can be configured in this submenu. For a detailed configuration of the AI blocks refer to the **Expert** menu.

Naviaation	Diagnostics \rightarrow Analog inputs \rightarrow Analog input 1 to 5
Ινανιααιιοπ	Diadrostics > Ariatod libuts > Ariatod libut 1 to 5

Block tag		
Navigation		
Description	Defined to be unique throughout the control system at one plant site. The tag may be changed using the FB_Tag service.	
Factory setting		
Channel		
Navigation		
Description	Use this function to select the input value that should be processed in the Analog Input function block.	
Selection	 Uninitialized Level linearized Absolute echo amplitude Absolute EOP amplitude Absolute interface amplitude* Distance Electronic temperature EOP shift Interface linearized* Interface distance* Measured capacitance Relative echo amplitude Relative interface amplitude* Noise of signal Terminal voltage Thickness upper layer* Calculated DC value* Analog output adv. diagnostics 2 Analog output adv. diagnostics 1 	

Uninitialized

Factory setting

^{*} Visibility depends on order options or device settings

Status		
Navigation		
Description	Indicates the status of the output of the AI block according to the FOUNDATION Fieldbus specification.	
Value		
Navigation		
Description	Indicates the output value of the AI block.	
Units index		
Navigation		
Description	Indicates the unit of the output value.	

17.4.6 "Data logging" submenu

Navigation $\blacksquare \square$ Diagnostics \rightarrow Data logging

Assign channel 1 to 4

Navigation

□ Diagnostics → Data logging → Assign channel 1 to 4

Selection

- Off
- Level linearized
- Distance
- Unfiltered distance
- Interface linearized '
- Interface distance
- Unfiltered interface distance
- Thickness upper layer ⁷
- Terminal voltage
- Electronic temperature
- Measured capacitance
- Absolute echo amplitude
- Relative echo amplitude
- Absolute interface amplitude *
- Relative interface amplitude
- Absolute EOP amplitude
- EOP shift
- Noise of signal
- Calculated DC value *
- Analog output adv. diagnostics 1
- Analog output adv. diagnostics 2
- Analog output 1
- Analog output 2
- Analog output 3
- Analog output 4

Factory setting

Off

Additional information

A total of 1000 measured values can be logged. This means:

- 1000 data points if 1 logging channel is used
- 500 data points if 2 logging channels are used
- 333 data points if 3 logging channels are used
- 250 data points if 4 logging channels are used

If the maximum number of data points is reached, the oldest data points in the data log are cyclically overwritten in such a way that the last 1000, 500, 333 or 250 measured values are always in the log (ring memory principle).



The logged data are deleted if a new option is selected in this parameter.

^{*} Visibility depends on order options or device settings

Logging interval

Navigation

- Diagnostics \rightarrow Data logging \rightarrow Logging interval
- Diagnostics \rightarrow Data logging \rightarrow Logging interval

User entry

1.0 to 3600.0 s

Factory setting

30.0 s

Additional information

This parameter defines the interval between the individual data points in the data log, and thus the maximum loggable process time T_{log} :

- If 1 logging channel is used: T $_{log}$ = 1000 \cdot t $_{log}$
- If 2 logging channels are used: $T_{log} = 500 \cdot t_{log}$
- If 3 logging channels are used: T log = 333 · t log
 If 4 logging channels are used: T log = 250 · t log

Once this time elapses, the oldest data points in the data log are cyclically overwritten such that a time of T $_{log}$ always remains in the memory (ring memory principle).

Example

When using 1 logging channel

- $T_{log} = 1000 \cdot 1 \text{ s} = 1000 \text{ s} \approx 16.5 \text{ min}$
- $T_{log} = 1000 \cdot 10 \text{ s} = 1000 \text{ s} \approx 2.75 \text{ h}$
- $T_{log} = 1000 \cdot 80 \text{ s} = 80000 \text{ s} \approx 22 \text{ h}$
- $T_{log} = 1000 \cdot 3600 \text{ s} = 3600000 \text{ s} \approx 41 \text{ d}$

Clear logging data	

The logged data are deleted if this parameter is changed.

Navigation

- Diagnostics → Data logging → Clear logging data
- Diagnostics → Data logging → Clear logging data

Selection

- Cancel
- Clear data


Factory setting

Cancel

"Display channel 1 to 4" submenu

The **Display channel 1 to 4** submenus are only available for operation via the local display. When operating via FieldCare, the logging diagram can be displayed in the FieldCare function "Event List / HistoROM".

The **Display channel 1 to 4** submenus invoke a diagram of the logging history of the respective channel.



- x-axis: depending on the number of selected channels, 250 to 1000 measured values of a process variable are displayed.
- y-axis: covers the approximate measured value span and constantly adapts this to the measurement.
- To return to the operating menu, press \pm and \Box simultaneaously.

Navigation

□ Diagnostics → Data logging → Display channel 1 to 4

17.4.7 "Simulation" submenu

The **Simulation** submenu is used to simulate specific measuring values or other conditions. This helps to check the correct configuration of the device and connected control units.


Conditions which can be simulated

Condition to be simulated	Associated parameters
Specific value of a process variable	 Assign measurement variable (→ 🖺 247) Process variable value (→ 🖺 247)
Specific state of the switch output	 Switch output simulation (→ □ 247) Switch status (→ □ 248)
Existence of an alarm	Simulation device alarm (\rightarrow 🖺 248)

Enable/disable simulation


The simulation of measured values can be enabled or disabled via a hardware switch (SIM switch) at the electronics. Simulating a measured value is only possible if the SIM switch is in the ON position.

The switch output can always be simulated, irrespective of the position of the SIM switch.



- 1. Loosen the securing clamp.
- 2. Unscrew the housing cover.

- 3. Pull out the display module with a gentle rotation movement. To make it easier to access the SIM switch, attach the display module to the edge of the electronics compartment.
 - └ Display module is attached to the edge of the electronics compartment.




A0013909

- 4. SIM switch in the **ON** position: measured values can be simulated. SIM switch in the **OFF** position (factory setting): Simulation of measured values is disabled.
- 5. Feed the spiral cable into the gap between the housing and main electronics module and plug the display module into the electronics compartment in the desired direction until it engages.
- 6. Screw the electronics compartment cover closed and tighten the securing clamp.

Structure of the submenu

Navigation \blacksquare Expert \rightarrow Diagnostics \rightarrow Simulation



Description of parameters

Navigation $\blacksquare \blacksquare$ Expert \rightarrow Diagnostics \rightarrow Simulation

Assign measurement variable

Navigation \blacksquare Expert \rightarrow Diagnostics \rightarrow Simulation \rightarrow Assign measurement variable

Selection ■ Off

Level

■ Interface

■ Level linearized

■ Interface linearized

■ Thickness linearized

Factory setting Off

Additional information

■ The value of the variable to be simulated is defined in the **Process variable value** parameter ($\rightarrow \triangleq 247$).

■ If **Assign measurement variable** ≠ **Off**, a simulation is active. This is indicated by a diagnotic message of the *Function check (C)* category.

Process variable value

Navigation \blacksquare Expert \rightarrow Diagnostics \rightarrow Simulation \rightarrow Process variable value

Prerequisite Assign measurement variable (→ 🗎 247) ≠ Off

User entry Signed floating-point number

Factory setting 0

Additional information Downstream measured value processing and the signal output use this simulation value. In

this way, users can verify whether the measuring device has been configured correctly.

Switch output simulation

Navigation \blacksquare Expert \rightarrow Diagnostics \rightarrow Simulation \rightarrow Switch output simulation

Description Switch the simulation of the switch output on and off.

Selection ■ Off

■ On

Visibility depends on order options or device settings

Factory setting

Off

Switch status

Navigation $\blacksquare \Box$ Expert \rightarrow Diagnostics \rightarrow Simulation \rightarrow Switch status

Prerequisite Switch output simulation ($\rightarrow \triangleq 247$) = On

Description Select the status of the status output for the simulation.

Selection ■ Open ■ Closed

Factory setting Open

Additional information The switch status assumes the value defined in this parameter. This helps to check correct

operation of connected control units.

Simulation device alarm

Navigation \blacksquare Expert \rightarrow Diagnostics \rightarrow Simulation \rightarrow Simulation device alarm

Description Switch the device alarm on and off.

Selection ■ Off

On

Factory setting Off

Additional information When selecting the **On** option, the device generates an alarm. This helps to check the

correct output behavior of the device in the case of an alarm.

An active simulation is indicated by the diagnostic message **⊗C484 Simulation failure**

mode.

Diagnostic event simulation

Navigation $\blacksquare \blacksquare$ Expert \rightarrow Diagnostics \rightarrow Simulation \rightarrow Diagnostic event simulation

Description Select a diagnostic event to simulate this event.

Factory setting Off

Additional information When operated via the local display, the selection list can be filtered according to the event

categories (Diagnostic event category parameter).

17.4.8 "Device check" submenu

Navigation \Box Diagnostics \rightarrow Device check

Start device check

Navigation $\blacksquare \Box$ Diagnostics \rightarrow Device check \rightarrow Start device check

Description Start a device check.

Selection ■ No

Yes

Factory setting No

Additional information In the case of a lost echo a device check can not be performed.

Result device check

Navigation Diagnostics \rightarrow Device check \rightarrow Result device check

Description Displays the result of the device check.

Additional information

Meaning of the display options

Installation ok

Measurement possible without restrictions.

Accuracy reduced

A measurement is possible. However, the measuring accuracy may be reduced due to the signal amplitudes.

■ Measurement capability reduced

A measurement is currently possible. Howerver, there is the risk of an echo loss. Check the mounting position of the device and the dielectric constant of the medium.

Check not done

No device check has been performed.

Last check time

Navigation $\blacksquare \Box$ Diagnostics \rightarrow Device check \rightarrow Last check time

Description Displays the operating time at which the last device check has been performed.

		•
Ι ΔττΔΙ	CIA	nol
Level	SIU	mai

Navigation

Prerequisite Device check has been performed.

Description Displays result of the device check for the level signal.

User interface Check not done

■ Check not OK

■ Check OK

Additional information

For **Level signal** = **Check not OK**: Check the mounting position of the device and the dielectric constant of the medium.

Launch signal

Navigation

Prerequisite Device check has been performed.

Description Displays result of the display check for the launch signal.

User interface Check not done

> ■ Check not OK ■ Check OK

Additional information

For **Launch signal** = **Check not OK**: Check the mounting position of the device. In non-

metallic vessels use a metal plate or a metal flange.

Interface signal

Navigation

Prerequisite ■ Operating mode (→ 🗎 165) = Interface or Interface with capacitance

Device check has been performed.

Description Displays result of the device check for the interface signal.

User interface Check not done

■ Check not OK

■ Check OK

17.4.9 "Heartbeat" submenu

The **Heartbeat** submenu is only available via **FieldCare** or **DeviceCare**. It contains the wizards which are part of the **Heartbeat Verification** and **Heartbeat Monitoring** application packages.

Detailed description SD01872F

Navigation \square Diagnostics \rightarrow Heartbeat

Index

A	D	
Access authorization to parameters	Data logging (Submenu)	241
Read access	DC value (Parameter) 173, 191,	193
Write access	DC value lower medium (Parameter)	188
Access code	Decimal places 1 (Parameter)	219
Incorrect input	Decimal places menu (Parameter)	222
Access status display (Parameter) 181	Declaration of Conformity	. 13
Access status tooling (Parameter) 181	Define access code	. 73
Accessories	Define access code (Parameter) 227,	229
Communication specific	Define access code (Wizard)	229
Device specific	Designated use	. 12
Service specific	Device check (Submenu)	249
Activate table (Parameter) 203	Device information (Submenu)	234
Actual diagnostics (Parameter) 230	Device name (Parameter)	235
Administration (Submenu)	Device replacement	
Advanced process conditions (Parameter) 185	Device reset (Parameter)	
Advanced setup (Submenu)	Device tag (Parameter)	234
Analog input 1 to 5 (Submenu) 179, 238	Diagnostic event	
Application	In the operating tool	
Residual risk	Diagnostic event simulation (Parameter)	
Assign channel 1 to 4 (Parameter) 241	Diagnostic events	
Assign diagnostic behavior (Parameter) 212	Diagnostic list	
Assign limit (Parameter)	Diagnostic list (Submenu)	
Assign measurement variable (Parameter) 247	Diagnostic message	130
Assign status (Parameter) 211	Diagnostics	
Automatic DC calculation (Wizard) 193	Symbols	
D	Diagnostics (Menu)	
B	Diagnostics 1 (Parameter)	
Backlight (Parameter)	Diagnostics event	
Backup state (Parameter)	Diameter (Parameter)	200
Block tag (Parameter)	DIP switch	
Blocking distance (Parameter) 186, 189, 206	see Write protection switch	
Bypass	Disable simulation	
С	Display (Submenu)	
Calculated DC value (Parameter)	Display and operating module FHX50	
CE mark	Display channel 1 to 4 (Submenu)	
Channel (Parameter)	Display damping (Parameter)	
Cleaning	Display module	
Clear logging data (Parameter)	Display module	
Coax probe	Display symbols for the locking state	
Design	Disposal	
Coax probes	Distance (Parameter)	
Bending strength	Distance to upper connection (Parameter)	
Shortening	Distance unit (Parameter)	
Comparison result (Parameter)	Document	100
Configuration backup display (Submenu) 224	Function	6
Configuration management (Parameter) 224	Document function	
Configuration of a level measurement 102, 114	Bottanene ranetaon	0
Configuration of an interface measurement 104, 115	E	
Confirm access code (Parameter)	Electronics housing	
Confirm distance (Parameter) 175, 178	Design	. 20
Confirm probe length (Parameter) 209, 210	Empty calibration (Parameter)	
Context menu	Enable simulation	
Contrast display (Parameter)	Enter access code (Parameter)	
Customer value (Parameter) 203	Envelope curve display	

Event history	Level (Parameter)
Explanation	Level correction (Parameter)
Symbols	Level linearized (Parameter)
Event list (Submenu)	Level measurement configuration 102, 114
Event logbook (Submenu)	Level signal (Parameter)
Event text	Level unit (Parameter)
Events list	Linearization (Submenu)
Extended order code 1 (Parameter)	Linearization type (Parameter)
Exterior cleaning	Local display
External mounting	see Diagnostics message see In alarm condition
F	Locking status (Parameter)
Failure mode (Parameter) 215	Logging interval (Parameter)
FHX50 69	bogging interval (1 arameter)
Filter options (Parameter)	M
Filtering the event logbook	Maintenance
Firmware version (Parameter)	Manage device configuration 108, 118
Flange	Manual thickness upper layer (Parameter) 190, 193
Format display (Parameter)	Mapping (Wizard)
Free text (Parameter)	Mapping end point (Parameter) 177, 178
Full calibration (Parameter)	Maximum value (Parameter) 200
·	Measured materials
G	Measured thickness upper layer (Parameter) 191
Gas phasen compensation	Measured value symbols 80
Mounting the probe rod 52	Measured values (Submenu) 236
	Medium group (Parameter) 166
Н	Medium property (Parameter)
Hardware write protection	Medium type (Parameter)
Header (Parameter)	Menu
Header text (Parameter)	Diagnostics
Heartbeat (Submenu)	Setup
Heat insulation 47	Mounting position for level measurements 24
HistoROM (description)	
Housing	N
Design	Non-metallic vessels
Turning	Number format (Parameter)
I	0
Input mask	_
Interface (Parameter)	Operating elements
Interface (Submenu)	Diagnostics message
Interface distance (Parameter)	Operating module
Interface linearized (Parameter) 200, 237	Operating module
Interface measurement configuration 104, 115	Operating time (Parameter)
Interface signal (Parameter)	Operating time from restart (Parameter)
Internediate height (Parameter)	Operational safety
Invert output signal (Parameter)	
mivert output signar (i arameter)	Output echo lost (Parameter)
K	Overvoltage protection
Keypad lock	General information 63
Disabling	Р
Switching on	Present mapping (Parameter)
	Present probe length (Parameter)
L	Previous diagnostics (Parameter)
Language (Parameter)	Probe grounded (Parameter)
Language selection	Probe length correction (Wizard)
Last backup (Parameter)	Probe settings (Submenu)
Last check time (Parameter)	Process property (Parameter)
Launch signal (Parameter)	Process Value Filter Time (Parameter)
,	1 10ccss value tille tillie (i arailleter) 100

Process variable value (Parameter)	Advanced setup
R	Configuration backup display
Ramp at echo lost (Parameter) 206	Data logging
Read access	Device information
Record map (Parameter)	
Registered trademarks	Diagnostic list
Remedial measures	Display
	Display channel 1 to 4
Closing 132	Event list
Closing	Event logbook
Remote operation	Events list
Repair concept	Heartbeat
Replacing a device	Interface
Requirements for personnel	Level
Result device check (Parameter)	Linearization 195, 196, 197
Return	Measured values
Rod probe	Probe settings
Design	Safety settings
Rod probes	Simulation
Bending strength	Switch output
Shortening	Switch output (Submenu) 211
Rope probe	Switch output function (Parameter) 211
Design	Switch output simulation (Parameter) 247
Rope probes	Switch status (Parameter) 215, 248
Shortening	Switch-off delay (Parameter) 215
Tensile load	Switch-off value (Parameter) 214
S	Switch-on delay (Parameter) 214
	Switch-on value (Parameter) 213
Safety instructions	Symbols
Basic	For correction
Safety Instructions (XA)	In the text and numeric editor 82
Safety settings (Submenu)	System components
Securing coax probes	
Securing rod probes	T
Securing rope probes	Table mode (Parameter) 201
Seilsonden	Table number (Parameter) 202
Montage	Tank level (Parameter)
Separator (Parameter)	Tank type (Parameter)
Serial number (Parameter) 234	Terminal voltage 1 (Parameter) 238
Service interface (CDI)	Thickness upper layer (Parameter) 238
Setting the operating language	Threaded connection
Settings	Timestamp (Parameter) 230, 231, 232
Manage device configuration 108, 118	Tools
Operating language 100	Transmitter
Setup (Menu)	Turning the display
Signal quality (Parameter)	Turning the display module 57
SIM switch	Transmitter housing
Simulation (Submenu) 246, 247	Turning
Simulation device alarm (Parameter) 248	Tube diameter (Parameter) 166
Spare parts	Turning the display
Nameplate	Turning the display module
Start device check (Parameter) 249	J 1 J
Status (Parameter)	U
Status signals	Underground tanks 42
Stilling well	Unit after linearization (Parameter) 198
Störungsbehebung	Units index (Parameter)
Submenu	Use calculated DC value (Parameter) 192, 193
Administration	, , , , , , , , , , , , , , , , , , , ,

V
Value (Parameter)
Value 1 display (Parameter) 219
Value echo lost (Parameter) 205
W
W@M Device Viewer
Wizard
Automatic DC calculation 193
Define access code
Mapping
Probe length correction 210
Workplace safety
Write access
Write protection
Via access code
Via write protection switch
Write protection switch



www.addresses.endress.com